**Onerbl 98b6b0b9-9dee-4cad-8ac8-a3a44e937122**

# Onerbl 5V AC/DC Adapter Instruction Manual

Compatible with weBoost Home MultiRoom and Destination RV Cell Phone Signal Boosters

## 1. Product Overview

The Onerbl 5V AC/DC Adapter is designed to provide reliable power to your compatible weBoost cell phone signal booster. This adapter converts standard AC wall power into the necessary DC power for your device, ensuring optimal performance. It is manufactured with high-quality materials and tested for compatibility and safety.
This power supply is suitable for various weBoost models, including 470144, 470144R, WB470144, 460059 Home MultiRoom, 470159 Destination RV Cell Phone Signal Boosters, and 5G Ready models 850018, 850025.

## 2. Safety Information

- **Do not expose to liquids:** Keep the adapter away from water or excessive moisture.
- **Indoor use only:** This adapter is intended for indoor use in dry locations.
- **Proper ventilation:** Ensure adequate ventilation around the adapter to prevent overheating. Do not cover the adapter.
- **Correct voltage:** Only connect the adapter to power outlets providing the specified input voltage (AC 100-240V).
- **Avoid damage:** Do not use the adapter if the cord or plug is damaged. Do not attempt to open or repair the adapter.
- **Children and pets:** Keep the adapter and its cables out of reach of children and pets.

## 3. Package Contents

Verify that your package contains the following items:

- Onerbl 5V AC/DC Adapter Unit

- AC Power Cord



Image: The Onerbl 5V AC/DC Adapter unit, showing its dimensions and the attached DC output cable. The total cable length is approximately 127.8 inches, with the adapter body measuring 4.2 inches in length. The AC input cord is 79.3 inches long, and the DC output cord is 44.3 inches long.





Image: The detachable AC power cord, featuring a two-prong plug for wall outlets and a two-slot connector for the adapter unit.

## 4. Setup

Follow these steps to set up your Onerbl AC/DC Adapter:

1. **Connect the AC Power Cord:** Insert the two-slot connector of the AC power cord firmly into the AC input port on the Onerbl adapter unit.
2. **Connect to Signal Booster:** Plug the DC output connector (the round barrel connector) from the Onerbl adapter into the power input port of your weBoost cell phone signal booster. Ensure a secure connection.
3. **Plug into Wall Outlet:** Insert the two-prong plug of the AC power cord into a standard electrical wall outlet (AC 100-240V, 50/60Hz).
4. **Verify Power:** The adapter typically has an indicator light (often blue) that illuminates when power is supplied. Confirm this light is on. Your weBoost signal booster should also power on.



Image: The Onerbl AC/DC Adapter unit plugged into a wall outlet, with the blue indicator light visible, demonstrating a successful power connection.

## 5. Operating Instructions

Once properly set up, the Onerbl AC/DC Adapter operates automatically. It provides continuous power to your connected weBoost signal booster as long as it is plugged into a live electrical outlet.

- **Power On:** The adapter begins supplying power immediately upon being plugged into an active wall outlet.
- **Power Off:** To turn off power to your signal booster, simply unplug the adapter from the wall outlet.
- **Continuous Operation:** The adapter is designed for continuous operation to ensure your signal booster remains active.

## 6. Maintenance

The Onerbl AC/DC Adapter requires minimal maintenance to ensure its longevity and safe operation.

- **Cleaning:** Disconnect the adapter from the power outlet before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and

extreme temperatures. Avoid tightly coiling the cables.

- **Inspection:** Periodically inspect the adapter and cables for any signs of damage, such as frayed wires, bent pins, or cracks in the casing. If damage is found, discontinue use immediately.

## 7. Troubleshooting

If you encounter issues with your Onerbl AC/DC Adapter, refer to the following common problems and solutions:

- **No Power Indicator Light:**
  - Ensure the adapter is firmly plugged into a working wall outlet. Test the outlet with another device.
  - Check that the AC power cord is securely connected to the adapter unit.
  - Verify that the DC output connector is fully inserted into your signal booster.
- **Signal Booster Not Powering On:**
  - Confirm the adapter's power indicator light is on.
  - Ensure your signal booster is compatible with a 5V power supply.
  - If the adapter is working but the booster is not, the issue may lie with the signal booster itself. Refer to your booster's manual.
- **Adapter Overheating:**
  - Unplug the adapter immediately.
  - Ensure it is not covered or placed in an enclosed space. Allow for proper airflow.
  - If overheating persists, discontinue use and contact support.

If these steps do not resolve the issue, please contact customer support.

## 8. Specifications

| | |
|---|---|
| **Input Voltage** | AC 100-240V, 50/60Hz |
| **Output Voltage** | 5V |
| **Compatibility** | weBoost 470144, 470144R, WB470144, 460059, 470159, 850018, 850025 |
| **Color** | Black |
| **Item Weight** | 0.176 ounces (approx. 5 Grams) |
| **Manufacturer** | Shenzhen Waweis Technology Co., Ltd |

## 9. Warranty and Support

Onerbl AC adapters are manufactured to high-quality standards. For specific warranty information, please refer to the product packaging or the retailer's return policy at the time of purchase. If you require technical assistance or have questions regarding your adapter, please contact the seller or Onerbl customer support through the platform where the product was purchased.