Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl ADP-48D12

onerbl 12V AC/DC Adapter Instruction Manual

For Gawfolk GF320D, GF320A, GF270C, GF270D, GF270E, GF270F Monitors

1. Introduction

This manual provides instructions for the safe and effective use of your onerbl 12V AC/DC Adapter. This adapter is designed to provide power to compatible devices, including Gawfolk GF320D, GF320A, GF270C, GF270D, GF270E, and GF270F monitors, as well as other devices requiring a 12VDC power supply with a barrel connector.



Image 1: The onerbl 12V AC/DC Adapter, including the main adapter unit and the detachable AC power cord.

2. Safety Information

Please read and understand all safety instructions before using this product. Failure to follow these instructions may result in electric shock, fire, or damage to the product or connected devices.

- **Input Voltage:** This adapter is designed for AC 100-240V, 50/60Hz input. Do not connect to power sources outside this range.
- **Protection Features:** The adapter includes built-in Over Voltage Protection and Over Heat Protection to safeguard your devices.
- **Environment:** Do not expose the adapter to water, excessive moisture, or extreme temperatures. Use in a well-ventilated area.
- **Disassembly:** Do not attempt to open or disassemble the adapter. There are no user-serviceable parts inside.
- **Cable Care:** Avoid bending, twisting, or crimping the power cables excessively. Ensure cables are not tripped over.

- **Compatibility:** Use only with compatible devices that require a 12VDC power supply with a matching barrel connector.




Image 2: The adapter features a smart chip for multiple electrical protections, including short-circuit, over-voltage, and over-current protection.

3. Package Contents

Verify that all items are present in the package:

- 1 x Power Adapter Unit
- 2 x Power Cables (AC input cable and DC output cable)

4. Setup Instructions

Follow these steps to set up your onerbl 12V AC/DC Adapter:

1. **Connect AC Input Cable:** Take the AC input cable (the one with the two-prong plug) and connect its C7 connector end firmly into the corresponding port on the power adapter unit.
2. **Plug into Wall Outlet:** Insert the two-prong plug of the AC input cable into a standard wall electrical outlet (AC 100-240V).
3. **Connect to Device:** Take the DC output cable (with the barrel connector) and plug the barrel connector end securely into the power input port of your compatible device (e.g., Gawfolk monitor).
4. **Verify Connection:** Ensure all connections are snug and secure. The adapter is now ready to supply power.



Image 3: The adapter in use, connected to a wall outlet and powering a device on a desk. A blue indicator light is visible on the adapter.

5. Operating Instructions

Once properly connected as described in the Setup section, the onerbl 12V AC/DC Adapter will automatically begin supplying power to your connected device. A blue LED indicator light on the adapter unit will illuminate, signifying that the adapter is receiving power and is operational.
No further user interaction is required for basic operation. To disconnect power, simply unplug the AC input cable from the wall outlet or the DC output cable from your device.

6. Maintenance

To ensure the longevity and optimal performance of your adapter, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the adapter and cables. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures.

- **Cable Integrity:** Regularly inspect the cables for any signs of damage, such as cuts, fraying, or exposed wires. If damage is found, discontinue use and replace the cable.



Image 4: The durable cable design features copper wire and a PVC jacket for enhanced longevity and safety.

7. Troubleshooting

If you encounter issues with your onerbl 12V AC/DC Adapter, refer to the following common problems and solutions:

- **No Power Output:**
  - Ensure the AC input cable is securely plugged into both the adapter and a functional wall outlet.
  - Verify that the wall outlet is supplying power by testing it with another device.
  - Check that the DC output barrel connector is firmly seated in your device's power input port.
- **Adapter Overheating:**
  - Ensure the adapter is placed in a location with adequate ventilation and not covered by objects.
  - Disconnect the adapter from power and allow it to cool down. If overheating persists after reconnecting, discontinue use and contact customer support.
- **Device Not Charging/Powering On:**
  - Confirm that your device is compatible with a 12VDC power supply and the barrel connector type.
  - Check your device's own power indicator or manual for troubleshooting specific to the device.

8. Specifications

Feature	Specification
Input Voltage	AC 100-240V, 50/60Hz

Output Voltage	12 Volts DC
Connector Type	Barrel Connector
Compatible Devices	Gawfolk GF320D, GF320A, GF270C, GF270D, GF270E, GF270F, Dajing ADP-48D12, ADP48D12
Included Components	1 x Power Adapter, 2 x Cables
Manufacturer	Shenzhen Waweis Technology Co., Ltd
Total Cable Length	Approximately 127.8 inches (324.6 cm)



Image 5: Detailed diagram showing the dimensions of the adapter unit and the total cable length, which is approximately 127.8 inches.

9. Warranty and Support

This onerbl 12V AC/DC Adapter is covered by a standard manufacturer's warranty. For specific warranty terms, duration, or to make a warranty claim, please refer to the documentation provided at the time of purchase or contact your retailer. For technical assistance or further inquiries, please reach out to the seller or manufacturer directly.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CTC31XPD

More documents and user manuals: **https://manuals.plus/**