Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl a9d72886-a515-47e3-bad3-fafe56358e4a

onerbl 30V AC/DC Adapter Instruction Manual

Compatible with TAGIC TG-VC02 Vacuum Cleaner

Introduction

This instruction manual provides essential information for the safe and effective use of your onerbl 30V AC/DC Adapter. This adapter is specifically designed to provide power and charge the 25.9V 2200mAh 56.98Wh Li-ion Battery A15-7SF18650NR-22 found in the TAGIC TG-VC02, TGVC02 150W 6 in 1 Lightweight Cordless Stick Vacuum Cleaner. Please read this manual thoroughly before use and retain it for future reference.

Important Safety Information

To ensure safe operation and prevent damage, observe the following precautions:

- **Over Voltage Protection:** The adapter is equipped with circuitry to protect against excessive voltage input.
- **Over Heat Protection:** Internal mechanisms are in place to prevent the adapter from overheating during operation.
- Do not expose the adapter to liquids, moisture, or extreme temperatures.
- Avoid dropping or subjecting the adapter to strong impacts.
- Do not attempt to disassemble, modify, or repair the adapter. Refer all servicing to qualified personnel.
- Ensure the adapter is used with compatible devices only, specifically the TAGIC TG-VC02 vacuum cleaner.
- Unplug the adapter from the power outlet when not in use or during electrical storms.

Product Overview

The onerbl 30V AC/DC Adapter is a high-quality replacement power supply designed for reliable performance. It features a compact design and universal input voltage compatibility.



The onerbl 30V AC/DC Adapter, showing its compact design and integrated cable.

Key Features:

- Input: AC 100-240V 50/60Hz (Worldwide AC Input)
- Output: 30V DC (specific current not provided, but implied by compatibility)
- Built-in Over Voltage Protection
- Built-in Over Heat Protection
- Durable construction with quality components.



Visual representation of the adapter's smart chip technology, highlighting short-circuit, over-voltage, and over-current protection features.




Illustration detailing the quality control aspects and durable design of the adapter, including copper wire and PVC jacket for enhanced durability.

Setup Instructions

Follow these steps to properly set up your onerbl AC/DC Adapter:

1. **Unpack:** Carefully remove the adapter from its packaging. Inspect it for any visible damage.
2. **Prepare Device:** Ensure your TAGIC TG-VC02 vacuum cleaner is powered off before connecting the adapter.
3. **Connect to Device:** Insert the adapter's output plug securely into the charging port of your TAGIC TG-VC02 vacuum cleaner.
4. **Connect to Power Outlet:** Plug the adapter's AC prongs into a standard wall outlet (AC 100-240V, 50/60Hz).
5. **Verify Connection:** Once connected, the vacuum cleaner's charging indicator (if present) should activate, signaling that charging has begun or power is being supplied.



The onerbl AC/DC Adapter connected to a power strip, demonstrating its compact size in a typical usage scenario.

Operating Instructions

Once properly connected, the onerbl 30V AC/DC Adapter will automatically begin supplying power to or charging your TAGIC TG-VC02 vacuum cleaner. No further user interaction is typically required during operation.

- Allow the vacuum cleaner to charge fully for optimal battery life.
- Disconnect the adapter from both the wall outlet and the vacuum cleaner once charging is complete or when the device is not in use for extended periods.

Care and Maintenance

Proper care will extend the life of your adapter:

- **Cleaning:** Use a soft, dry cloth to wipe the adapter. Do not use liquid cleaners or solvents.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and moisture when not in use.

- **Cable Inspection:** Regularly check the power cord and connector for any signs of damage, such as fraying, cuts, or bent pins. If damage is found, discontinue use immediately.
- **Ventilation:** Ensure the adapter has adequate ventilation during use to prevent heat buildup. Do not cover it with cloths or place it in enclosed spaces.

Troubleshooting

If you encounter issues with your adapter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Adapter not supplying power/charging	No power from outlet; loose connection; incompatible device; damaged adapter.	Test outlet with another device; ensure all connections are secure; confirm device compatibility; inspect adapter for damage.
Adapter feels hot during use	Normal operation; poor ventilation; excessive load.	A slight warmth is normal. Ensure adequate ventilation; disconnect if excessively hot and allow to cool. If problem persists, discontinue use.
Device not recognizing adapter	Incorrect adapter; dirty/damaged charging port on device.	Verify adapter specifications match device requirements; inspect device's charging port for debris or damage.

Product Specifications

Detailed technical specifications for the onerbl 30V AC/DC Adapter:




Diagram illustrating the dimensions of the onerbl AC/DC Adapter and its cable length.

Specification	Detail
Brand	onerbl
Model Number	a9d72886-a515-47e3-bad3-fafe56358e4a
Input Voltage	AC 100-240V, 50/60Hz
Output Voltage	30V DC
Compatibility	TAGIC TG-VC02, TGVC02 25.9V 2200mAh 56.98Wh Li-ion Battery A15-7SF18650NR-22 150W 6 in 1 Lightweight Cordless Stick Vacuum Cleaner
Color	Black
Item Weight	6.2 ounces

Specification	Detail
Package Dimensions	4 x 3 x 2.2 inches
Cable Length	76 inches (approximately 6.33 feet)
Plug Format	Type C (US Standard)
Manufacturer	Shenzhen Waweis Technology Co., Ltd

Warranty Information

This product is covered by a standard manufacturer's warranty. For specific details regarding warranty coverage, duration, and claims process, please refer to the documentation provided at the time of purchase or contact your retailer. Keep your proof of purchase for warranty validation.

Customer Support

If you have any questions, require technical assistance, or need to report an issue that cannot be resolved using the troubleshooting guide, please contact onerbl customer support. Please have your product model number (a9d72886-a515-47e3-bad3-fafe56358e4a) and purchase information ready when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CTC3SYHC

More documents and user manuals: **https://manuals.plus/**