onerbl B0CTC3TMTB

onerbl 12V AC/DC Adapter Instruction Manual

Compatible with FANGOR F-BR114 Portable Blu-ray Player

1. Introduction

This instruction manual provides essential information for the safe and effective use of your onerbl 12V AC/DC Adapter. This adapter is designed as a replacement power supply for the FANGOR F-BR114 and FBR114 13.3 Inch Portable Blu-ray Player with a 12" HD Swivel Screen. Please read this manual thoroughly before use and retain it for future reference.

2. Safety Information

To ensure safe operation and prevent damage, please observe the following safety precautions:

- This adapter is for indoor use only. Do not expose it to rain or moisture.
- Keep the adapter away from water, heat sources, and direct sunlight.
- Unplug the adapter from the power outlet when not in use for extended periods.
- Do not attempt to disassemble, modify, or repair the adapter. Refer all servicing to qualified personnel.
- Ensure the adapter is connected to a properly grounded electrical outlet.
- Avoid placing heavy objects on the power cord or adapter.
- The adapter features built-in protections against over voltage, over heat, short-circuit, and over-current to safeguard your devices.



Image: This illustration highlights the adapter's smart chip technology, providing multiple layers of protection including short-circuit, over-voltage, and over-current safeguards for electrical safety.

3. Product Overview

The onerbl 12V AC/DC Adapter is a compact and reliable power solution. It converts standard AC wall power to the DC voltage required by your compatible portable Blu-ray player.



Image: A dual view of the onerbl AC/DC adapter, showing its front with input specifications and its side profile with the two-prong plug.



Image: This graphic illustrates the durable construction of the adapter, featuring quality control aspects and the use of copper wire within a

PVC jacket for enhanced longevity and performance.

4. Setup

Follow these steps to connect your onerbl AC/DC Adapter to your FANGOR F-BR114 Portable Blu-ray Player:

1. **Identify the DC Input Port:** Locate the DC input port on your FANGOR F-BR114 portable Blu-ray player. This is typically labeled "DC IN" or similar.
2. **Connect to Power Outlet:** Plug the AC adapter into a standard wall electrical outlet (AC 100-240V).
3. **Connect to Device:** Insert the DC output plug of the adapter firmly into the DC input port of your FANGOR F-BR114 player.

Once connected, your device should begin to power on or charge its internal battery.



Image: The onerbl AC/DC adapter is shown plugged into a power strip, with its cable extending to connect to a portable electronic device, demonstrating a typical setup.

5. Operating

The onerbl AC/DC Adapter operates automatically once connected. It provides a stable 12V DC power supply to your compatible device. No user intervention is required for its basic operation.

- Ensure the adapter is securely plugged into both the wall outlet and your device.
- The adapter is designed for continuous use, but it is recommended to unplug it when not actively powering or charging a device to conserve energy.

6. Maintenance

Proper care will extend the life of your adapter:

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or aerosols.
- **Storage:** Store the adapter in a cool, dry place when not in use. Avoid wrapping the cable too tightly around the adapter to prevent damage to the cord.
- **Inspection:** Periodically inspect the power cord and adapter for any signs of damage, such as frayed wires or cracked casing. If damage is found, discontinue use immediately.

7. Troubleshooting

If you encounter issues with your adapter, try the following solutions:

- **Device Not Powering On/Charging:**
  - Ensure both ends of the adapter are securely connected to the wall outlet and the device.
  - Test the wall outlet with another device to confirm it is functional.
  - Verify that the FANGOR F-BR114's power button is in the 'ON' position or that the device is not in a sleep mode.
- **Adapter Feels Warm:**
  - It is normal for the adapter to feel slightly warm during operation. If it becomes excessively hot to the touch or emits a burning smell, unplug it immediately and discontinue use.
- **Intermittent Power:**
  - Check for loose connections at both the wall outlet and the device's input port.
  - Ensure the power cord is not bent or damaged.

8. Specifications

Input Voltage	AC 100-240V, 50/60Hz
Output Voltage	DC 12V
Compatible Devices	FANGOR F-BR114, FBR114 Portable Blu-ray Player
Cable Length	76 inches (approximately 6.3 feet)
Dimensions (Adapter Body)	2.6 inches (Length) x 1.6 inches (Width) x 1.2 inches (Height)
Protection Features	Over Voltage Protection, Over Heat Protection, Short-circuit Protection, Over-current Protection
Manufacturer	Shenzhen Waweis Technology Co., Ltd

Brand	onerbl




Image: This image provides key physical dimensions of the onerbl AC/DC adapter, including its length, width, height, and the total cable length of 76 inches.

9. Warranty and Support

For warranty information or technical support, please refer to the documentation provided with your purchase or contact the seller directly. Ensure you have your product model number (B0CTC3TMTB) and purchase details available when seeking support.