onerbl 5V AC/DC Adapter

onerbl 5V AC/DC Adapter User Manual

Compatible with Victrola VSC-550BT and VSS-890BT-LGR Turntable Players

1. Introduction

This manual provides essential instructions for the safe and effective use of your onerbl 5V AC/DC Adapter. This power supply is designed to provide reliable power to compatible electronic devices, including specific Victrola turntable models such as the VSC-550BT and VSS-890BT-LGR. Please read this manual thoroughly before use and retain it for future reference.

2. Important Safety Instructions

- **Read all instructions:** Before using the adapter, read and understand all safety and operating instructions.
- **Power Source:** Only connect the adapter to a power outlet that matches the voltage and frequency specified on the adapter label (AC 100-240V, 50/60Hz).
- **Avoid Moisture:** Do not expose the adapter to rain, moisture, or extreme humidity. Do not use it near water.
- **Ventilation:** Ensure adequate ventilation around the adapter. Do not cover it or place it in an enclosed space that could restrict airflow.
- **Cable Protection:** Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the adapter.
- **Disconnecting:** Always grasp the plug, not the cord, when disconnecting the adapter from the power outlet.
- **Damage:** Do not operate the adapter if it has been damaged in any way. If the cord or plug is damaged, or if the adapter has been dropped or exposed to water, discontinue use immediately and contact support.
- **Cleaning:** Unplug the adapter from the wall outlet before cleaning. Use a dry cloth for cleaning.
- **Children:** Keep the adapter out of reach of children.

3. Setup Instructions

Follow these steps to correctly set up your onerbl 5V AC/DC Adapter:

1. **Verify Compatibility:** Ensure your device requires a 5V DC input and that the adapter's connector plug is compatible with your device's power input port. This adapter is specifically designed for devices like the Victrola VSC-550BT and VSS-890BT-LGR turntable players.

2. **Connect to Device:** Insert the DC output plug of the onerbl adapter firmly into the power input port of your electronic device.
3. **Connect to Power Outlet:** Plug the AC input prongs of the adapter into a standard wall power outlet (AC 100-240V, 50/60Hz).
4. **Power On Device:** Once connected, you can power on your device as usual. The adapter will automatically provide the necessary power.



Image: The onerbl 5V AC/DC adapter connected to a power strip, ready for use with a device.

4. Operating the Adapter

The onerbl 5V AC/DC Adapter operates automatically once connected. It is designed for continuous use within its specified voltage and current limits.

- **Automatic Operation:** The adapter automatically converts the AC input voltage (100-240V) to the required 5V DC output for your device.
- **Protection Features:** The adapter incorporates multiple safety features to protect both the adapter and your connected device:



Image: Diagram showing the adapter's built-in short-circuit, over-voltage, and over-current protection.

- **Over Voltage Protection:** Prevents damage from excessive voltage.
- **Over Heat Protection:** Shuts down if internal temperatures become too high.
- **Short Circuit Protection:** Safeguards against electrical shorts.

5. Care and Maintenance

Proper care ensures the longevity and safe operation of your adapter:

- **Cleaning:** Disconnect the adapter from the power outlet and your device before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or aerosols.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Cable Inspection:** Regularly inspect the power cord and connector for any signs of damage, such as fraying, cuts, or bent pins. If damage is observed, discontinue use and replace the adapter.
- **Avoid Stress:** Do not bend the cable sharply or place heavy objects on it.




Image: Illustration of the adapter's durable design, featuring copper wire and a PVC jacket for enhanced longevity.

6. Troubleshooting

If you encounter issues with your adapter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device not receiving power.	• Adapter not fully plugged into outlet. • Adapter not fully connected to device. • Power outlet is not functional. • Adapter or cable is damaged. • Device is incompatible or faulty.	• Ensure adapter is securely plugged into a live wall outlet. • Verify the DC plug is fully inserted into the device's power port. • Test the outlet with another device. • Inspect the adapter and cable for visible damage. If damaged, replace. • Confirm device requires 5V DC input. Test device with another compatible power source if available.
Adapter feels excessively hot.	• Poor ventilation. • Overload (device drawing too much power). • Internal fault.	• Ensure adapter is in an open area with good airflow. • Verify your device's power requirements do not exceed the adapter's output capacity (1A). • Disconnect immediately and replace if overheating persists.

If these solutions do not resolve the issue, please contact customer support.

7. Specifications



Image: Front and side view of the onerbl 5V AC/DC adapter.

Model	5V AC/DC Adapter
Input Voltage	AC 100-240V, 50/60Hz
Output Voltage	DC 5V
Output Current	1A (Maximum)
Cable Length	76 inches (approx. 1.93 meters)
Dimensions (Adapter Body)	Approx. 2.6 x 1.6 x 1.2 inches (6.6 x 4.1 x 3.0 cm)
Protection Features	Over Voltage Protection, Over Heat Protection, Short Circuit Protection
Manufacturer	Shenzhen Waweis Technology Co., Ltd

Compatible Devices	Victrola VSC-550BT, VSS-890BT-LGR, and other 5V DC compatible devices.




Image: Detailed dimensions of the onerbl 5V AC/DC adapter and its 76-inch cable length.



Image: Illustration of the wide range of applications for this type of 5V AC/DC adapter, including various electronic devices.

8. Warranty Information

This product is covered by a standard manufacturer's warranty against defects in materials and workmanship. The specific duration and terms of the warranty may vary. Please refer to your purchase documentation or contact the seller for detailed warranty information.

9. Customer Support

If you have any questions, require technical assistance, or need to report an issue with your onerbl 5V AC/DC Adapter, please contact the seller or manufacturer directly through the platform where the product was purchased. Provide your product model number and purchase date for faster service.

© 2024 onerbl. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question