Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl PAC-A-01060, PAC-A-01208

onerbl 12V AC/DC Adapter Instruction Manual

For Arcade1Up PAC-A-01060, PAC-A-01208, and compatible models

1. Introduction

This instruction manual provides essential information for the safe and effective use of your onerbl 12V AC/DC Adapter. This adapter is designed to provide reliable power to compatible devices, including Arcade1Up PAC-A-01060 and PAC-A-01208 models. Please read this manual thoroughly before use and retain it for future reference.

2. Product Overview and Features

The onerbl 12V AC/DC Adapter is a high-quality replacement power supply designed for durability and performance. It features a robust design with multiple safety protections to ensure stable power delivery.

Key Features:

- **Input:** AC 100-240V 50/60Hz (Worldwide AC Input)
- **Output:** 12V DC (specific amperage not provided, refer to product label)
- **Safety Protections:** Over Voltage Protection, Over Heat Protection, Short-Circuit Protection, Over-Current Protection
- **Durable Construction:** Features copper wire and a PVC jacket for enhanced longevity.
- **Extended Cord Design:** Provides flexibility in placement with a total cable length of approximately 127.8 inches (3.25 meters).




Figure 2.1: Dimensions of the onerbl 12V AC/DC Adapter. The adapter measures 4.2 inches in length. The DC output cable is 44.3 inches long, and the AC input cable is 79.3 inches long, for a total cable length of 127.8 inches.



Figure 2.2: The adapter incorporates a smart chip for multiple electrical protections, including short-circuit, over-voltage, and over-current safeguards.



Figure 2.3: The cable features a durable design with a PVC jacket protecting copper wires, ensuring quality and longevity.

3. Specifications

Specification	Detail
Brand	onerbl
Input Voltage	AC 100-240V, 50/60Hz
Output Voltage	12V DC
Compatible Devices	Arcade1Up PAC-A-01060, PAC-A-01208, Bandai Namco Rister, and other 12V devices
Manufacturer	Shenzhen Waweis Technology Co., Ltd

4. Setup Instructions

Follow these steps to properly set up your onerbl 12V AC/DC Adapter:

1. **Verify Compatibility:** Ensure your device requires a 12V DC power input and that the adapter's connector type matches your device's power port. This adapter is specifically designed for Arcade1Up PAC-A-01060 and PAC-A-01208 models.
2. **Connect to Device:** Insert the DC output connector of the adapter firmly into the power input port of your Arcade1Up game machine or other compatible device.
3. **Connect to Power Outlet:** Plug the AC input cable (the two-prong plug) into a standard AC 100-240V wall outlet.

4. **Power On:** Once connected, your device should receive power. If your device has a power switch, turn it on.



Figure 4.1: The adapter connected to a wall outlet and a device, ready for operation.

5. Operating Instructions

The onerbl 12V AC/DC Adapter operates automatically once connected. No user intervention is required for its basic function.

- Ensure the adapter is placed in a well-ventilated area to prevent overheating.
- Avoid covering the adapter during operation.
- If your device is not powering on, check all connections and ensure the wall outlet is functional.

6. Maintenance

Proper maintenance ensures the longevity and safe operation of your adapter.

- **Cleaning:** Disconnect the adapter from the power outlet and your device before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and moisture. Avoid tightly coiling the cables to prevent damage.
- **Inspection:** Periodically inspect the adapter and cables for any signs of damage, such as cuts, frayed wires, or bent pins. If damage is found, discontinue use immediately.

7. Troubleshooting

If you encounter issues with your onerbl 12V AC/DC Adapter, refer to the following common problems and solutions:

- **Device Not Powering On:**
  - Ensure both the AC plug and DC connector are fully inserted.
  - Test the wall outlet with another device to confirm it is supplying power.
  - Verify that your device's power switch is in the 'ON' position.
  - Confirm that your device requires 12V DC input and that the adapter's output matches.
- **Adapter Feels Warm:**
  - It is normal for the adapter to feel slightly warm during operation.
  - If it feels excessively hot, disconnect it immediately. Ensure it is in a well-ventilated area and not covered.
- **Intermittent Power:**
  - Check for loose connections at both the wall outlet and the device.
  - Inspect the cables for any visible damage.

If problems persist after following these steps, please contact customer support.

8. Warranty and Support

Your onerbl 12V AC/DC Adapter comes with a standard warranty covering manufacturing defects. For specific warranty terms and duration, please refer to the product packaging or your purchase documentation.
For technical support, troubleshooting assistance, or warranty claims, please contact the seller or manufacturer directly. Contact information can typically be found on the product packaging or the retailer's website where the product was purchased.

© 2024 onerbl. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CTC5H4F7

More documents and user manuals: **https://manuals.plus/**