

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Panasonic](#) /

› [Panasonic Swipe Right Travel Shaver for Men, Portable Electric Razor with USB-C Charging, 3-Blade Cutting System and Beard Sensor Technology, Wet/Dry Use - ES-CM3A-K Black](#)

Panasonic ES-CM3A-K

Panasonic ES-CM3A Travel Shaver User Manual

Model: ES-CM3A-K

PRODUCT OVERVIEW

The Panasonic ES-CM3A Travel Shaver is a compact, portable electric razor designed for convenient grooming on the go. It features a 3-blade cutting system, beard sensor technology, and USB-C charging for versatile use.



Figure 1: Front view of the Panasonic ES-CM3A Travel Shaver with the protective cap removed, showing the foil head.

SETUP

1. Unboxing and Initial Inspection

Carefully remove all components from the packaging. Verify that all items listed in the package contents are present and undamaged. The package typically includes the shaver unit, a protective cap, a USB-C charging cable, a cleaning brush, and lubricating oil.



Figure 2: The Panasonic ES-CM3A shaver, USB-C cable, and cleaning accessories laid out, demonstrating its compact size for travel.

2. Initial Charging

Before first use, fully charge the shaver. Connect the supplied USB-C cable to the charging port located at the bottom of the shaver. Plug the other end into a compatible USB power source (e.g., computer, wall adapter). The charging indicator lights will illuminate during charging and turn off or change color when fully charged. A full charge provides approximately 60 minutes of operation.



Figure 3: The shaver connected to a USB-C cable for charging, highlighting its universal charging capability.

OPERATING INSTRUCTIONS

1. Turning On/Off

To activate the shaver, slide the protective cap to the right. This action automatically turns the shaver on. To turn it off, slide the cap back to the left until it clicks into place, covering the foil head.

2. Shaving Techniques (Wet/Dry Use)

The ES-CM3A can be used for both wet and dry shaving. For dry shaving, ensure your skin is clean and dry. For wet shaving, apply shaving gel or foam to your face or body. Hold the shaver at a right angle to your skin and move it gently against the direction of hair growth. The smart beard sensor technology will automatically adjust motor power based on hair thickness for optimal performance.



HIGH-QUALITY STAINLESS STEEL BLADES

Built with hypoallergenic blades and precision foils, to deliver a smooth, irritation-free shave—every time.

Figure 4: A man using the shaver on his face, illustrating the ergonomic design and control during shaving.

MAINTENANCE

1. Cleaning the Shaver

The shaver is IPX7 waterproof, allowing for easy cleaning under running water. After each use, remove the outer foil frame by pressing the release buttons on the sides. Rinse the foil frame and the inner blades thoroughly under cool tap water. Shake off excess water and allow components to air dry completely before reassembling or storing.



LONG BATTERY LIFE

60-min charge lasts a vacation; 5-min quick charge gives 1 full shave when you're in a rush

Figure 5: The shaver being cleaned under running water, showcasing its waterproof design for easy maintenance.

2. Lubrication

For optimal performance and longevity, apply a drop of the provided lubricating oil to the outer foil and inner blades periodically (e.g., once a week or after several uses). Turn the shaver on for a few seconds to distribute the oil evenly.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is depleted.	Charge the shaver fully using the USB-C cable.
Poor shaving performance.	Blades or foil are dull/damaged, or shaver is clogged with hair.	Clean the shaver thoroughly. If performance does not improve, consider replacing the outer foil and inner blades.

Problem	Possible Cause	Solution
Shaver stops during use.	Battery is low.	Recharge the shaver.

SPECIFICATIONS

- **Model:** ES-CM3A-K
- **Cutting System:** 3-Blade
- **Charging:** USB-C
- **Battery Life:** Approximately 60 minutes (fully charged)
- **Waterproof:** IPX7 (fully washable)
- **Special Features:** Beard Sensor Technology, Wet/Dry Use, Portable Design
- **Dimensions:** 6.5 x 4.69 x 2.28 inches
- **Weight:** 9.38 ounces

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official Panasonic website or contact their customer service directly. Keep your purchase receipt as proof of purchase for warranty claims.

Important Safety Information: Except when charging, always unplug this appliance from the electrical outlet immediately after using. Unplug this appliance before cleaning.