

Manuals.plus /

› Panasonic /

› Panasonic ES-RM3B-K Electric Wet Dry Shaver Instruction Manual

Panasonic ES-RM3B-K

Panasonic ES-RM3B-K Electric Wet Dry Shaver Instruction Manual

Model: ES-RM3B-K

IMPORTANT SAFETY INSTRUCTIONS

To ensure safe operation and prevent injury or damage, please read all instructions carefully before using this appliance.

- **Power Source:** Except when charging, always unplug this appliance from the electrical outlet immediately after using. Unplug this appliance before cleaning.
- **Water Exposure:** This shaver is designed for wet and dry use. However, do not immerse the charging adapter in water.
- **Children:** Keep the appliance out of reach of children. Close supervision is necessary when this appliance is used by, on, or near children or individuals with certain disabilities.
- **Damage:** Do not operate the appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped or damaged.
- **Maintenance:** Do not attempt to repair the appliance yourself. Refer to the 'Maintenance' section for cleaning and care.

PRODUCT OVERVIEW

The Panasonic ES-RM3B-K Electric Wet Dry Shaver is engineered for a close and comfortable shave. It features a 3-blade cutting system with hypoallergenic stainless steel blades and foils, designed to follow facial contours and minimize irritation. The shaver is powered by a high-speed motor for efficient hair removal and offers convenient USB-C charging.



Main view of the Panasonic ES-RM3B-K Electric Wet Dry Shaver.

Key Features:

- **3-Blade Cutting System:** Hypoallergenic stainless steel blades and foils for a close shave.
- **High-Power Motor:** Approximately 8,000 RPM for consistent performance.
- **Wet/Dry Operation:** Suitable for use with or without shaving gel/cream, in or out of the shower.
- **Ergonomic Design:** Slim and lightweight for comfortable handling.
- **USB-C Charging:** Convenient and fast charging.



Close-up view of the shaver's 3-blade cutting system.

The shaver's floating head design adapts to facial contours, ensuring efficient contact with the skin for a smooth result.

SETUP

Charging the Shaver:

1. Ensure the shaver is turned off.
2. Connect the provided USB-C charging cable to the shaver's charging port.
3. Plug the other end of the USB-C cable into a compatible USB power source (e.g., wall adapter, computer USB port).
4. The charging indicator light will illuminate to show that the shaver is charging.
5. A full charge takes approximately 1 hour and provides up to 50 minutes of shaving time.
6. Unplug the shaver once fully charged.



The shaver's USB-C charging port for convenient power-ups.

OPERATING INSTRUCTIONS

General Shaving Tips:

- For best results, shave before washing your face.
- Hold the shaver at a right angle (90 degrees) to your skin.
- Stretch your skin taut with your free hand to make the hairs stand upright.
- Move the shaver slowly over your face against the direction of hair growth.
- Apply gentle pressure; excessive pressure can cause irritation.

Wet Shaving:

The ES-RM3B-K is waterproof (IPX7 rated) and can be used for wet shaving. Apply shaving gel or foam to your face before shaving for a smoother experience and reduced friction.



The shaver's showerproof design allows for convenient wet shaving.

Shaving Demonstration Video:

Your browser does not support the video tag.

This video provides a demonstration of the Panasonic ES-RM3B shaver in use, offering insights into its performance and shaving technique.

MAINTENANCE

Cleaning the Shaver:

Regular cleaning ensures optimal performance and hygiene.

1. Turn off the shaver and unplug it from any power source.
2. Remove the outer foil frame.
3. Rinse the outer foil frame and the inner blades under cool running water until all hair clippings are removed.
4. Shake off excess water and allow the parts to air dry completely before reassembling.
5. Do not use harsh detergents or abrasive cleaners.



The shaver can be easily rinsed under running water for cleaning.

Blade and Foil Replacement:

For continued optimal shaving performance, it is recommended to replace the outer foil and inner blades periodically. The lifespan of the blades can vary depending on usage, but typically ranges from 12 to 24 months. Refer to Panasonic's official website or authorized retailers for replacement parts.

TROUBLESHOOTING

If you encounter issues with your Panasonic ES-RM3B-K shaver, please refer to the following common solutions:

- **Shaver does not turn on:** Ensure the shaver is fully charged. Check the USB-C cable and power source for proper connection. The travel lock feature might be activated; press and hold the power button for a few seconds to deactivate it.
- **Poor shaving performance:** The blades and foils may be dull. Consider replacing them if they have been in use for an extended period. Ensure the shaver head is clean and free of hair clippings. Apply gentle pressure and shave against the grain.
- **Skin irritation:** Ensure your skin is clean before shaving. Use a wet shave with gel or foam to reduce friction. Avoid applying excessive pressure. Allow your skin to adapt to the new shaver over a few weeks.
- **Charging issues:** Verify that the USB-C cable is securely connected to both the shaver and the power source. Try a different USB-C cable or power adapter.

If the problem persists after attempting these solutions, please contact Panasonic customer support for further assistance.

SPECIFICATIONS

Feature	Detail
Model Number	ES-RM3B-K
Brand	Panasonic
Number of Blades	3
Head Type	Foil
Blade Material	Stainless Steel
Power Source	Battery Powered
Battery Type	1 Lithium Ion battery (included)
Charging Time	1 hour for full charge
Battery Average Life	50 minutes
Waterproof Rating	IPX7 (Washable, Waterproof)
Item Weight	0.3 Kilograms (10.41 ounces)
Dimensions	8.19 x 4.92 x 2.28 inches (Package)
Included Components	Charger

WARRANTY AND SUPPORT

This Panasonic product is covered by a manufacturer's warranty. For specific warranty details, including coverage period and terms, please refer to the warranty card included with your product or visit the official Panasonic website.

For technical support, replacement parts, or any inquiries regarding your ES-RM3B-K shaver, please contact Panasonic customer service. Contact information can typically be found on the product packaging or the official Panasonic support website.

Online Resources:

- Visit the Panasonic Store on Amazon for additional products and information.