

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Samsung](#) /

› [Samsung Galaxy A15 5G SM-A156M/DS User Manual](#)

## Samsung SM-A156M/DS

# Samsung Galaxy A15 5G SM-A156M/DS User Manual

Model: SM-A156M/DS

## INTRODUCTION

---

Welcome to the user manual for your new Samsung Galaxy A15 5G smartphone. This guide provides essential information to help you get started, operate, and maintain your device effectively. The Samsung Galaxy A15 5G features a vibrant 6.5-inch Super AMOLED display, a versatile triple camera system, and a long-lasting 5000mAh battery, designed to enhance your mobile experience.



Figure 1: Front view of the Samsung Galaxy A15 5G.

## 1. SETUP

### 1.1 Unboxing and Initial Inspection

Upon opening the package, ensure all components are present. The box typically contains the Samsung Galaxy A15 5G smartphone and an adapter. Inspect the device for any physical damage before proceeding.

### 1.2 SIM Card and MicroSD Card Installation

The Samsung Galaxy A15 5G supports Dual-SIM functionality and a MicroSD card for expandable storage up to 1TB.

1. Locate the SIM tray on the side of your device.
2. Insert the SIM ejection tool into the small hole on the tray to open it.
3. Place your Nano-SIM card(s) and/or MicroSD card into the tray with the gold contacts facing down. Ensure they are correctly seated.
4. Gently push the tray back into the slot until it clicks into place.



Figure 2: Back view of the Samsung Galaxy A15 5G, showing camera and SIM tray location (conceptual).

### 1.3 Initial Power On and Setup

1. Press and hold the Power/Side key until the Samsung logo appears.
2. Follow the on-screen prompts to select your language, connect to a Wi-Fi network, and set up your Google

account.

3. Configure security features such as the side fingerprint sensor, PIN, pattern, or password.

## 1.4 Charging the Battery

Before first use, it is recommended to fully charge the device. The Galaxy A15 5G is equipped with a 5000mAh (typical) battery and supports Super Fast Charging.

- Connect the adapter to a power outlet.
- Connect the USB cable (not always included, but implied by "Adapter" in box) to the adapter and to the USB-C port on your phone.
- The charging indicator will appear on the screen.

# Stay in the zone with a 2-day battery

More time to get productive with a 5,000mAh (typical) battery that lasts for 2 days and recharges rapidly with Super Fast Charging.



Figure 3: The Samsung Galaxy A15 5G features a 5000mAh battery for extended use.

## 2. OPERATING YOUR DEVICE

### 2.1 Display and Navigation

The Galaxy A15 5G features a 6.5-inch Super AMOLED display with a 1080 x 2340 resolution and a 90Hz refresh

rate for smooth visuals. Navigate the interface using touch gestures: tap, swipe, pinch-to-zoom.

## 2.2 Camera Features

Capture moments with the versatile camera system:

- **Main Camera:** 50MP (OIS) for high-resolution photos.
- **Ultra Wide Camera:** 5MP for expansive landscapes.
- **Macro Camera:** 2MP for detailed close-up shots.
- **Front Camera:** 13MP for clear selfies.



Figure 4: Multi-camera system of the Samsung Galaxy A15 5G.

## 2.3 Performance and Storage

The device is powered by an octa-core Mediatek Helio G99 processor with 6GB RAM, ensuring smooth performance for daily tasks. It comes with 128GB of internal storage, expandable via MicroSD card.

## 2.4 Security Features

Unlock your phone securely using the side-mounted fingerprint sensor. Additional security options include PIN,

pattern, and password.

## 2.5 Connectivity

The Galaxy A15 5G supports various connectivity options:

- **Cellular:** 5G network compatibility (GSM Unlocked).
- **Wireless:** Wi-Fi for internet access.
- **Bluetooth:** For connecting to wireless accessories.
- **GPS:** For location services and navigation.

## 2.6 Audio

The device includes a 3.5 mm audio jack for wired headphones, in addition to Bluetooth audio capabilities.

# 3. MAINTENANCE

---

## 3.1 Battery Care

To maximize battery life:

- Avoid extreme temperatures.
- Use only Samsung-approved chargers and cables.
- Do not let the battery drain completely regularly.
- Enable power-saving modes when necessary.

## 3.2 Software Updates

Regularly check for and install software updates to ensure optimal performance, security, and access to new features. Updates are typically found in **Settings > Software update**.

## 3.3 Cleaning Your Device

Use a soft, lint-free cloth to clean the screen and body of your phone. Avoid harsh chemicals or abrasive materials.

# 4. TROUBLESHOOTING

---

## 4.1 Common Issues and Solutions

- **Device not powering on:** Ensure the battery is charged. Press and hold the Power/Side key for at least 10 seconds to force a restart.
- **Apps freezing or crashing:** Close the app and reopen it. If the issue persists, clear the app's cache (Settings > Apps > [App Name] > Storage > Clear cache).
- **Connectivity problems (Wi-Fi/Bluetooth/Cellular):** Toggle the respective connection off and on. Restart your device. For cellular issues, check SIM card installation.
- **Slow performance:** Close unnecessary background apps. Clear cache and temporary files. Consider a factory reset if performance issues persist after other troubleshooting steps.

## 4.2 Factory Reset

A factory reset will erase all data from your device and restore it to its original factory settings. Back up all important data before proceeding.

1. Go to **Settings > General management > Reset > Factory data reset**

2. Review the information and tap **Reset**.
3. Enter your screen lock information if prompted, then tap **Delete all**.

## 5. SPECIFICATIONS

Feature	Specification
Model Name	Samsung Galaxy A15 5G
Model Number	SM-A156M/DSN
Display	6.5-inch Super AMOLED, 1080 x 2340 pixels, 90Hz Refresh Rate
Processor	Mediatek Helio G99 Octa-core
RAM	6 GB
Internal Storage	128 GB
Expandable Storage	MicroSD, up to 1TB
Main Camera	50MP (OIS)
Ultra Wide Camera	5MP
Macro Camera	2MP
Front Camera	13MP
Battery Capacity	5000 mAh (non-removable)
Operating System	Android
Dimensions	6.30 x 3.02 x 0.33 inches (160.1 x 76.8 x 8.4 mm)
Weight	7.05 oz (200 g)
Audio Jack	3.5 mm

## 6. WARRANTY AND SUPPORT

For warranty information, please refer to the warranty card included with your product or visit the official Samsung website. For technical support, software updates, or service inquiries, please contact Samsung customer service or visit an authorized service center. You can find contact details and support resources on the official Samsung support website.

**Online Resources:** [Samsung Support Website](#)

© 2026 Samsung. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.