



Manuals.plus /

- › Fjords /
- › Fjords Axel Power Recliner Chair User Manual

Fjords Axel 848116PB

Fjords Axel Power Recliner Chair User Manual

Model: Axel 848116PB

1. INTRODUCTION

Thank you for choosing the Fjords Axel Power Recliner Chair. This manual provides essential information for the safe and efficient use, maintenance, and care of your new recliner. The Axel chair is designed for comfort and support, featuring a dual motorized recline system, independent footrest and back position control, a swivel base, and an adjustable headrest.

Please read this manual thoroughly before using the chair and retain it for future reference.



Image 1.1: The Fjords Axel Power Recliner Chair in a living room environment.

2. SETUP

The Fjords Axel Power Recliner Chair is delivered fully assembled and requires no additional setup. Follow these steps for initial placement:

1. **Unpacking:** Carefully remove all packaging materials from the chair. Ensure no components are left inside the packaging.
2. **Placement:** Position the chair in your desired location. Ensure there is adequate space around the chair for full recline functionality and swivel. Avoid placing the chair in direct sunlight or near heat sources to prevent material damage.
3. **Power Connection:** Locate the power cord and plug it into a standard electrical outlet. Ensure the cord is not pinched or obstructed.

Important: Do not exceed the maximum weight recommendation of 250 pounds for this chair.

3. OPERATING INSTRUCTIONS

The Axel Power Recliner features a dual motor system for independent control of the backrest and footrest, along with a swivel base and adjustable headrest.

3.1. Recline and Footrest Operation

The chair is equipped with easy-to-use buttons located on the side of the chair for controlling the recline and footrest.



Image 3.1: Control buttons for recline and footrest.

- **Footrest Extension:** Press the designated button to extend the footrest. Continue holding to adjust to your desired position.
- **Backrest Recline:** Press the designated button to recline the backrest. Continue holding to adjust to your desired angle.
- **Retracting:** Use the corresponding buttons to retract the footrest and return the backrest to the upright position.



Image 3.2: The chair in a reclined position with the footrest extended.

3.2. Headrest Adjustment

The Axel chair features a moveable head pillow for added comfort and a manual release adjustable headrest angle. Adjust the headrest manually to your preferred position by gently pushing or pulling it.

3.3. Swivel Function

The chair base allows for smooth 360-degree swivel motion. Simply rotate the chair to face your desired direction.

4. MAINTENANCE

Proper care and maintenance will extend the life and appearance of your Fjords Axel Power Recliner Chair.

4.1. Leather Care

The chair is upholstered in Soft Line Leather. To maintain its quality:

- **Regular Cleaning:** Dust the leather regularly with a soft, dry cloth.
- **Spills:** Immediately blot any spills with a clean, absorbent cloth. Do not rub. For stubborn stains, use a mild leather cleaner specifically designed for aniline or semi-aniline leather, following the product instructions. Test on an inconspicuous area first.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or household detergents, as these can damage the leather finish.
- **Conditioning:** Periodically apply a leather conditioner to keep the leather supple and prevent drying and cracking.
- **Sunlight/Heat:** Keep the chair away from direct sunlight and heat sources to prevent fading and drying of the leather.

4.2. General Care

- **Moving the Chair:** When moving the chair, lift it rather than dragging it to prevent damage to the base or floor.
- **Electrical Components:** Ensure the power cord is not damaged. If any electrical issues arise, disconnect the power immediately and contact customer support.

5. TROUBLESHOOTING

If you encounter any issues with your Fjords Axel Power Recliner Chair, please refer to the following common troubleshooting steps:

- **Chair Not Reclining/Footrest Not Extending:**
 - Check if the power cord is securely plugged into both the chair and the wall outlet.
 - Ensure the wall outlet is functional by testing it with another appliance.
 - Verify that no objects are obstructing the reclining mechanism or footrest.
- **Unusual Noises During Operation:**
 - Inspect the area around the motor and moving parts for any foreign objects.
 - Ensure all visible connections are secure.
- **Headrest Not Adjusting:**
 - The headrest is manually adjustable. Ensure you are applying gentle, firm pressure to move it.

If these steps do not resolve the issue, please contact Fjords customer support for further assistance.

6. SPECIFICATIONS

Detailed specifications for the Fjords Axel Power Recliner Chair (Large Size):



Image 6.1: Dimensions of the Fjords Axel Power Recliner Chair.

Feature	Detail
Model Name	Axel
Model Number	848116PB
Product Dimensions (D x W x H)	37" x 32.5" x 42"
Item Weight	100 Pounds
Maximum Weight Recommendation	250 Pounds
Upholstery Material	Soft Line Leather (Shadow Grey)
Fill Material	Foam
Frame Material	Metal
Assembly Required	No (Pre-assembled)
Features	Dual Motor Recline, Independent Footrest/Back Control, Swivel Base, Moveable Head Pillow, Adjustable Headrest Angle

Image 6.2: Detailed measurements for Fjords Axel Recliner Chair (Medium and Large).

Image 6.3: Fjords Soft Line Leather information and color options.

7. WARRANTY INFORMATION

The Fjords Axel Power Recliner Chair is backed by a manufacturer's warranty:

- **Frames:** 10-year limited warranty.
- **Molded Foam, Wood Components, Gas Cylinders, and Cables:** 5-year limited warranty.
- **Reclining Mechanisms and Power Components:** 3-year limited warranty.
- **Leather or Fabric Covers:** 2-year limited warranty.

Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects under normal use. It does not cover damage resulting from misuse, accidents, or unauthorized modifications.

8. CUSTOMER SUPPORT

For further assistance, warranty claims, or inquiries not covered in this manual, please contact Fjords customer support or your authorized retailer.

Fjords Official Website: Visit the Fjords Store on Amazon

When contacting support, please have your model number (Axel 848116PB) and proof of purchase readily available.

