Fjords 848116PB

Fjords Axel Power Recliner Chair User Manual

Model: 848116PB

1. Introduction

This manual provides essential instructions for the safe and efficient use of your Fjords Axel Power Recliner Chair. Please read this manual thoroughly before assembly and operation, and retain it for future reference. The Fjords Axel is designed for comfort, featuring a dual motor system for independent control of the backrest and footrest, a swivel base, and an adjustable headrest.

2. Safety Information

- Ensure all power connections are secure and the power cord is not pinched or damaged.
- Keep hands, feet, and pets clear of all moving parts during operation to prevent injury.
- Do not allow children to play on or operate the recliner unsupervised.
- Unplug the chair from the power outlet before cleaning, moving, or performing any maintenance.
- Do not sit on the footrest when it is extended.
- Avoid placing heavy objects on the chair's moving parts.

3. Package Contents

Verify that all components are present before beginning assembly:

- Fjords Axel Recliner Seat
- Fjords Axel Recliner Backrest
- Swivel Base

- Power Adapter and Cord
- User Manual (this document)

4. Setup and Assembly

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a soft, clean surface to prevent damage.
2. **Attach Swivel Base:** Securely attach the swivel base to the bottom of the recliner seat according to the markings. Ensure all fasteners are tightened.
3. **Install Backrest:** Slide the backrest onto the metal posts located on the rear of the seat frame. Push down firmly until it locks into place. You should hear a click.
4. **Connect Power:** Locate the power cable extending from the chair. Connect it to the provided power adapter, then plug the adapter into a standard electrical outlet.
5. **Initial Test:** Once assembled and powered, test the recline functions using the control panel to ensure proper operation.



Image 1: Fjords Axel Power Recliner Chair with indicated dimensions (37"D x 32.5"W x 42"H).

5. Operating Instructions

The Fjords Axel Power Recliner features a dual motor system for independent control of the backrest and footrest, along with an adjustable headrest and swivel function.

5.1. Power Recline Function

The control panel is located on the side of the chair. It features large, easy-to-use buttons for adjusting your seating position.



Image 2: Close-up view of the control panel with buttons for recline and footrest adjustment.

- **Footrest Control:** Use the designated button to extend or retract the footrest. Press and hold to achieve your desired position.
- **Backrest Control:** Use the separate button to recline or bring the backrest upright. Press and hold to adjust the angle.
- **Simultaneous Adjustment:** The dual motor system allows you to adjust the footrest and backrest independently or simultaneously to find your optimal comfort.

5.2. Adjustable Headrest

The chair features a moveable head pillow and a manual release adjustable headrest angle. Adjust the headrest by hand to support your head and neck comfortably in any reclined position.

5.3. Swivel Function

The chair is equipped with a swivel base, allowing you to rotate the chair 360 degrees for convenience and flexibility.



Image 3: The Fjords Axel Power Recliner Chair in its upright position, showcasing its design and swivel base.

6. Maintenance

6.1. Leather Care (Soft Line Ice Leather)

Your Fjords Axel recliner is upholstered in Soft Line Ice leather. To maintain its appearance and longevity:

- **Regular Cleaning:** Dust the leather regularly with a soft, dry cloth. For light spills, wipe immediately with a clean, damp cloth and dry thoroughly.
- **Avoid Harsh Cleaners:** Do not use abrasive cleaners, solvents, or household detergents, as these can damage the leather finish. Use only specialized leather cleaning products if necessary, following the product instructions.
- **Protect from Sunlight:** Avoid prolonged exposure to direct sunlight or heat sources, which can cause the leather to fade or dry out.
- **Conditioning:** Periodically apply a leather conditioner suitable for aniline or semi-aniline leather to keep it

supple and prevent cracking.



Image 4: A close-up of the Soft Line Ice leather swatch (SL-244), illustrating the texture and color.

6.2. General Maintenance

- **Mechanism:** The power recline mechanism is designed for maintenance-free operation. Do not attempt to lubricate or disassemble it.
- **Power Cord:** Regularly inspect the power cord for any signs of damage. If damaged, discontinue use and contact customer support.
- **Moving:** When moving the chair, lift it rather than dragging it to prevent damage to the base and flooring.

7. Troubleshooting

If you encounter issues with your Fjords Axel Power Recliner, refer to the following common solutions:

- **Chair Not Reclining:**
  - Ensure the power cord is securely plugged into both the chair and a working electrical outlet.
  - Check if the outlet is functional by plugging in another appliance.
  - Verify that all internal connections between the backrest and seat are firm.
- **Unusual Noises During Operation:**
  - Ensure no objects are obstructing the moving parts of the mechanism.
  - If noises persist, discontinue use and contact customer support.
- **Headrest Not Adjusting:**
  - The headrest is manually adjustable. Ensure the manual release mechanism is not jammed.

For issues not resolved by these steps, please contact Fjords customer support.

8. Specifications

Feature	Detail
Brand	Fjords
Model Name	Axel
Model Number	848116PB
Size	Large
Upholstery	Soft Line Leather - Ice (SL-244)

Feature	Detail
Product Dimensions (D x W x H)	37" x 32.5" x 42"
Item Weight	100 pounds
Special Features	Dual Motorized Recline, Swivel Base, Adjustable Headrest, Ergonomic Design
UPC	786721526387

9. Warranty Information

The Fjords Axel Power Recliner Chair is backed by a**Fjords 10-Year limited manufacturer warranty**. This warranty typically covers the structural frame and reclining mechanism against manufacturing defects under normal use. It does not usually cover normal wear and tear, misuse, or damage to upholstery (leather) unless it is a manufacturing defect upon receipt.
Please retain your proof of purchase for warranty claims. For specific details regarding coverage and to initiate a warranty claim, refer to the official Fjords warranty documentation or contact Fjords customer support.

10. Support and Contact

For further assistance, technical support, or warranty inquiries, please contact Fjords customer service. You can typically find contact information on the Fjords official website or through your retailer.
Online Resources: Visit the Fjords Store on Amazon for additional product information and support.