

[Manuals.plus](#) /

> [SONGMICS](#) /

> SONGMICS Laundry Sorter Instruction Manual

SONGMICS URLS102B01

SONGMICS Laundry Sorter Instruction Manual

Model: URLS102B01 (135 L)

Brand: SONGMICS

INTRODUCTION

The SONGMICS Laundry Sorter is designed to streamline your laundry routine by providing an efficient and organized way to collect, sort, and transport clothes. This rolling laundry basket features three removable bags, making laundry day more manageable. Its robust construction ensures durability and long-lasting performance in various home environments, including laundry rooms, bedrooms, and bathrooms.



Image: The SONGMICS Laundry Sorter, a three-bag unit designed for efficient laundry organization.

KEY FEATURES

- **Large Capacity:** This laundry sorter offers a total capacity of 35.7 gallons (135 L), providing ample space to collect and organize a significant amount of laundry, preventing clutter.
- **3-Section Sorting:** Equipped with three separate washing bags, the sorter allows for easy pre-sorting of laundry by color or type, significantly reducing sorting time on laundry day.
- **Easy Mobility:** Featuring rails that double as handles and four smooth-rolling casters, the laundry cart can be effortlessly moved between rooms. Two of the casters are lockable, ensuring stability when the sorter is in place.
- **Portable, Water-Resistant Bags:** The three individual laundry bags are removable and feature metal handles, allowing for convenient transport to the washing machine. The bags are PVC-coated, making them water-resistant and easy to clean.
- **Sturdy and Durable Construction:** Crafted from robust 600D Oxford fabric and reinforced with 0.9-inch diameter steel tubes, the laundry cart boasts a stable and durable structure capable of supporting up to 66 lb (30 kg) in total.
- **Simple Assembly:** Designed for straightforward setup, the sorter comes with a well-designed structure and

clear, easy-to-read instructions, enabling quick assembly.

Spacious 35.7 Gal. (135 L) Volume with 3 Separate Bags

- Holds tons of clothes, perfect for family use
- Make it easy to sort your laundry by color or type

35.7 Gal.
(135 L)



Image: Visual representation of the sorter's capacity, highlighting the 35.7-gallon total volume and individual bag capacities.

Easy to Carry & Move

Removable bags for portability,
casters and handles for easy movement



4 Swivel Casters,
2 with Brakes




Image: Demonstrates the removable bags and the lockable swivel casters for easy movement and stability.

Sturdy and Durable

Robust steel frame and thick bags provide a max. load of 66 lb (30 kg)



Sturdy Steel Tubes



Water-Resistant Oxford Fabric



Image: Details of the robust steel tube frame and the water-resistant properties of the Oxford fabric bags.

ASSEMBLY INSTRUCTIONS

Package Contents

- 1 x 3-Bag Laundry Sorter Frame
- 3 x Removable Laundry Bags
- 1 x Accessory Kit (including necessary screws and connectors)
- 1 x Instruction Manual

Required Tools

No additional tools are typically required for assembly, as an accessory kit with all necessary components is included.

Step-by-Step Assembly

1. Unpack all components and verify against the package contents list.
2. Follow the detailed diagrams and instructions provided in the included instruction manual to assemble the steel frame. Ensure all connections are secure.
3. Attach the four casters to the base of the frame. Ensure the two lockable casters are positioned as indicated in the manual for optimal stability.
4. Hang the three removable laundry bags onto the designated hooks on the top bar of the frame.
5. Confirm the sorter is stable and all parts are correctly installed before use.

Note: Some users have reported minor difficulties with part labeling or alignment during assembly. Refer closely to the provided manual and ensure all parts are correctly oriented before tightening screws. If a part appears to be missing a hole, double-check the orientation or contact customer support.

OPERATING INSTRUCTIONS

Sorting Laundry

Utilize the three distinct bags to pre-sort your laundry. Common sorting methods include:

- Lights, Darks, and Delicates
- Towels, Linens, and Clothing
- By family member

Moving the Sorter

To move the laundry sorter, unlock the two lockable casters by flipping their levers. Use the integrated rails as handles to push or pull the cart to your desired location. Once positioned, engage the caster locks to secure the sorter in place.

Removing and Re-attaching Bags

Each laundry bag is designed for easy removal. Simply lift the bag by its metal handles from the hooks on the frame. This allows you to transport individual loads of laundry directly to your washing machine without moving the entire sorter.



Images: Demonstrating the ease of removing and carrying the individual laundry bags.

To re-attach, align the metal handles with the hooks on the frame and lower the bag into position.

MAINTENANCE

Cleaning the Bags

The PVC-coated 600D Oxford fabric bags are water-resistant and designed for easy cleaning. For general cleaning, wipe the interior and exterior surfaces with a damp cloth and mild detergent. Allow to air dry completely before re-attaching to the frame.



Image: Illustrates the water-resistant nature of the bag material.

Frame Care

Wipe the steel frame with a dry or slightly damp cloth to remove dust and dirt. Avoid using abrasive cleaners or harsh chemicals that could damage the finish. Regularly check all screws and connections to ensure they remain tight and secure.

TROUBLESHOOTING

- **Difficulty with Assembly:** If you encounter issues during assembly, such as misaligned holes or unclear instructions, refer to the detailed manual. Ensure all parts are oriented correctly before attempting to force connections. If problems persist, contact SONGMICS customer support for assistance.
- **Bags Tearing/Wear:** While the bags are made from durable Oxford fabric, excessive overloading or sharp objects placed inside can cause wear or tearing over time. Avoid exceeding the recommended weight capacity (66 lb total). If a bag is damaged, replacement bags may be available through SONGMICS customer service.
- **Casters Not Rolling Smoothly:** Check for any lint, hair, or debris caught in the caster wheels. Clean the wheels regularly. Ensure the lock mechanisms are fully disengaged when attempting to roll the sorter.

SPECIFICATIONS

Attribute	Detail
Product Dimensions	31.5"L x 15.16"W x 31.89"H
Brand	SONGMICS
Color	Ink Black

Material	Powder Coated Steel Tube, 600D Polyester Fiber Bag, Nylon Caster
Style	Modern
Special Feature	Portable, Handle
Shape	Rectangular
Included Components	3-Bag Laundry Sorter, Accessory Kit, Instructions
Size	135 L
Number of Pieces	3
Number of Compartments	3
Mounting Type	Floor Mount
Item Weight	7.92 pounds (3.6 Kilograms)
Capacity	35.7 Gallons
Recommended Uses For Product	Laundry collection, sorting, transport
Room Type	Laundry Room, Bathroom, Bedroom
Manufacturer	SONGMICS
UPC	194343074252
ASIN	B0CTF57JY3
Date First Available	June 1, 2024

WARRANTY AND SUPPORT

For warranty information, product support, or to inquire about replacement parts, please contact SONGMICS customer service directly. Refer to the contact information provided on the product packaging or the official SONGMICS website.

SAFETY INFORMATION

- Do not exceed the maximum weight capacity of 66 lb (30 kg).
- Keep small children and pets away from the sorter during assembly to prevent access to small parts.
- Ensure casters are locked when the sorter is stationary to prevent accidental movement.
- Avoid placing sharp or pointed objects in the bags that could puncture the fabric.
- Use the product on a flat, stable surface.

