

MITER CASE M4

MITER Case for Muse HiFi M4 - User Manual

Model: M4 Case (Black)

1. INTRODUCTION

This manual provides instructions for the proper use and care of your MITER Artificial PU Leather Case, designed specifically for the Muse HiFi M4 portable audio player. The case is crafted from high-quality artificial PU leather and suede, offering protection against shocks, fingerprints, and scratches while maintaining full access to the device's functions.

Please read this manual thoroughly to ensure optimal protection and longevity for your Muse HiFi M4 player.

2. SETUP AND INSTALLATION

Follow these steps to correctly install your Muse HiFi M4 player into the MITER case:

1. Ensure your Muse HiFi M4 player is clean and free of dust or debris before insertion.
2. Gently slide the Muse HiFi M4 player into the case, starting from the top or bottom opening, depending on the case design.
3. Carefully push the player until it is fully seated within the case. Ensure that all edges of the player are covered by the case material.
4. Verify that all ports (headphone jacks, charging port) and buttons (power, volume, playback controls) are correctly aligned with the case's cutouts and remain fully accessible and functional.



Figure 1: Front view of the Muse HiFi M4 player securely installed in the black MITER case, displaying the device's internal components.



Figure 2: Various angles of the MITER case demonstrating precise cutouts for all ports and controls of the Muse HiFi M4 player.

3. OPERATING THE DEVICE WITH THE CASE

The MITER case is designed to provide protection without hindering the functionality of your Muse HiFi M4 player. Once installed, you will have full access to:

- **Buttons:** Power, volume, and playback control buttons are accessible through the case's precise cutouts.
- **Ports:** Headphone jacks and the charging/data port are fully exposed for easy connection.
- **Screen:** The front opening ensures the screen is visible and usable.

The case adds a layer of protection against accidental drops and daily wear, helping to preserve the aesthetic and functional integrity of your device.

4. CARE AND MAINTENANCE

To ensure the longevity and appearance of your MITER Artificial PU Leather Case, please follow these care instructions:

- **Cleaning:** Wipe the case gently with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or solvents, as these can damage the PU leather material.
- **Stains:** For minor stains, use a small amount of mild soap diluted in water on a soft cloth. Gently rub the stained area and then wipe clean with a separate damp cloth. Allow to air dry completely.
- **Storage:** When not in use, store the case in a cool, dry place away from direct sunlight and extreme temperatures to prevent material degradation.
- **Avoid Sharp Objects:** Keep the case away from sharp objects to prevent scratches or punctures to the PU leather.




Figure 3: Rear view of the MITER case, highlighting the textured artificial PU leather and the embossed brand logo.

5. TROUBLESHOOTING

This section addresses minor issues you might encounter with your case.

- **Case feels too tight or loose:** The MITER case is precision-engineered for the Muse HiFi M4. Ensure the player is inserted correctly and fully seated. If the fit is still unsatisfactory, double-check that you have the correct model case for your device.
- **Buttons are difficult to press:** Verify that the player is properly aligned within the case and that the case's button cutouts are not obstructed. Slight adjustments to the player's position within the case may resolve this.
- **Discoloration or wear:** Over time, all materials may show signs of wear. Follow the care instructions in Section 4 to minimize this. Significant discoloration or damage may indicate exposure to harsh conditions or chemicals.

6. SPECIFICATIONS

Product Name	MITER Case for Muse HiFi M4
Model Number	M4
Compatibility	Muse HiFi M4 Portable Audio Player
Material	Italy made Artificial PU Leather, Suede
Color	Black
Item Weight	2.47 ounces (approximately 70 grams)
Package Dimensions	5.51 x 4.33 x 1.57 inches (14 x 11 x 4 cm)
Origin	Made in South Korea



Figure 4: The MITER case is available in multiple colors, including Black (left) and Red (right).

7. WARRANTY AND SUPPORT

For any questions regarding your MITER Case for Muse HiFi M4, or if you encounter any issues not covered in this manual, please contact the manufacturer or your point of purchase for assistance. Specific warranty details may vary by region and retailer.

Please retain your proof of purchase for any warranty claims.

