



[Manuals.plus](#) /

> [Yardenaler](#) /

> Yardenaler 10x12 FT Wooden Pergola Instruction Manual

Yardenaler 10x12 FT Wooden Pergola

Yardenaler 10x12 FT Wooden Pergola Instruction Manual

Model: 10x12 FT Wooden Pergola

Brand: Yardenaler

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Yardenaler 10x12 FT Wooden Pergola. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

SAFETY INFORMATION

Always follow the assembly instructions carefully.

Use the included stakes and consider using expansion screws (not included) for added stability.

Ensure the surface where the pergola is mounted is flat and stable.

Do not exceed the weight limit of the pergola.

Keep children and pets away from the assembly area during installation.

Always use appropriate safety gear when handling heavy objects and tools.

SETUP AND ASSEMBLY

The Yardenaler 10x12 FT Wooden Pergola requires assembly. It is recommended that at least two adults participate in the assembly process.

Before You Begin

- Unpack all components and verify against the parts list (refer to your packaging for the complete list).
- Ensure you have all necessary tools, including a drill, measuring tape, and safety equipment.
- Choose a flat, stable location for installation.

Assembly Steps

1. Assemble the main posts and beams according to the diagrams provided in your product packaging.

2. Attach the roof slats, ensuring they are evenly spaced.
3. Secure the pergola to the ground using the included stakes. For enhanced stability, especially on wood decks or concrete, consider using expansion screws (not included) to anchor the posts.



Assembled Yardenaler 10x12 FT Wooden Pergola in a backyard setting.

STAKES INCLUDED FOR INSTALLING THE POSTS ON DIRT GROUND

NOT Recommend Stone or Any Type of Paver as They Can Lift



Detailed dimensions of the Yardenaler 10x12 FT Wooden Pergola, including post size and overall footprint.

SOLID CEDAR WOOD

WITH WEATHER-RESISTANT STAIN



100% Sturdy Natural Wood Construction
Extra Water-Based Stain is Highly Recommended for Better Protection



Illustration of stakes included for securing the pergola posts on dirt ground, with notes on applicability for cement and wood decks.

USAGE GUIDELINES

Your Yardenaler Wooden Pergola is designed to provide an outdoor living space for relaxation and entertainment.

- The flat roof design allows for ample sunlight. For additional shade or rain protection, an extra cover can be added to the top (not included).
- Light-weighted hangings and decorations can be suspended from the open slatted roof trellis.
- This pergola is suitable for various outdoor activities, including hosting parties, barbecues, or simply enjoying your garden.

QUALITY

**SOLID WOOD CONSTRUCTION
STANDS UP TO 4 SEASONS**

WITHSTANDS UP TO 80 MPH



Close-up view of the slatted roof trellis of the Yardenaler Wooden Pergola, highlighting its design for light-weighted decorations.




Yardenaler Wooden Pergola providing a shaded area for outdoor furniture and activities.

MAINTENANCE

To ensure the longevity and appearance of your Yardenaler Wooden Pergola, regular maintenance is recommended.

- The cedar wood is treated with a weather-resistant stain. For better protection and to maintain its appearance, it is highly recommended to apply an extra water-based stain periodically.
- Inspect all connections and fasteners regularly to ensure they remain tight. Tighten any loose bolts or screws.
- Clean the wood surfaces with a mild soap and water solution as needed. Avoid harsh chemicals that may damage the wood or stain.
- During extreme weather conditions (e.g., heavy snow, strong winds), inspect the pergola for any signs of stress or damage.



UNPARALLELED SLATTED ROOF TRELLIS

WOODEN PERGOLA TOP

Multi-level and Functional Addition to Your Outdoor Life
Open for Light-Weighted Hanging, Decorations or Extra Shading Cover

Image emphasizing the solid cedar wood construction with weather-resistant stain, recommending additional water-based stain for protection.



Visual representation of the pergola's durability against various weather conditions, including snow and sun.

TROUBLESHOOTING

Instability Issues

- **Problem:** Pergola feels wobbly or unstable.
- **Solution:** Ensure all bolts and screws are securely tightened. Verify that the posts are properly anchored to the ground using the provided stakes. For additional stability, especially on non-dirt surfaces, consider using expansion screws (not included) to anchor the posts.

Wood Discoloration or Wear

- **Problem:** Wood appears faded or shows signs of weathering.
- **Solution:** Apply an additional coat of water-based stain to protect the cedar wood from environmental elements and restore its appearance. Regular staining helps prevent rot and wear.

SPECIFICATIONS

Feature	Detail
Brand	Yardenaler
Model	10x12 FT Wooden Pergola
Material	Cedar Wood
Product Dimensions (L x W x H)	144.1"L x 120.1"W x 92.15"H
Interior Dimensions (L x W x H)	109.9"L x 89.8"W x 85.83"H
Post Size	5.5" x 5.5"

Item Weight	273 Pounds
Water Resistance Level	Water Resistant
UV Light Protection	Yes
Assembly Required	Yes

WARRANTY INFORMATION

Please refer to the product packaging or the manufacturer's official website for specific warranty details. Keep your proof of purchase for any warranty claims.

CUSTOMER SUPPORT

For assistance with assembly, missing parts, or any other inquiries, please contact Yardenaler customer service. Contact information can typically be found on the product packaging or the brand's official website.