

[Manuals.plus](#) /

› [Rolipo](#) /

› Rolipo Travel Steam Iron and Garment Steamer, Model SL-007 Instruction Manual

Rolipo SL-007

Rolipo Travel Steam Iron and Garment Steamer

Model: SL-007

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using this appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always unplug the appliance from the electrical outlet when filling with water, emptying, or when not in use.
- Do not operate the steamer with a damaged cord or plug, or if the appliance has been dropped or damaged.
- To avoid the risk of electric shock, do not immerse the steamer in water or other liquids.
- Keep the steamer and its cord out of reach of children.
- Use the appliance only for its intended purpose as described in this manual.
- The steam is hot. Always direct the steam away from yourself and others. Do not touch the hot soleplate.
- Never steam clothes while wearing them.
- Use distilled or demineralized water to prevent mineral buildup and extend the life of the appliance.

2. PRODUCT OVERVIEW

The Rolipo SL-007 is a compact and portable steam iron and garment steamer designed for efficient wrinkle removal at home or while traveling.



Image: The Rolipo SL-007 Travel Steam Iron and Garment Steamer, showcasing its compact design.

PERFEKTER REISEBEGLEITER



Image: The compact steamer being packed into a travel bag, highlighting its portability.

Components:

- **Water Tank:** Transparent, detachable tank for easy filling and monitoring water level.
- **Steam Nozzle/Soleplate:** Emits steam and can be used for light pressing.
- **Handle:** Ergonomically designed for comfortable grip.
- **Power Button/Steam Trigger:** Activates heating and steam release.
- **Power Cord:** Connects to an electrical outlet.

3. SETUP

1. **Unpack:** Carefully remove the steamer from its packaging and check for any damage. Retain packaging for future storage or transport.
2. **Fill Water Tank:**
 - Ensure the steamer is unplugged.
 - Detach the transparent water tank by gently sliding it out.
 - Open the water tank cap and fill with distilled or demineralized water up to the MAX line. Do not overfill.
 - Close the cap securely and reattach the water tank to the steamer until it clicks into place.

SICHTBARER WASSERTANK

Das ist sehr einfach zu installieren und zu demonstrieren. Kein Wasseraustritt.

Überprüfen Sie den Wasserstand deutlich und füllen Sie die richtige Wassermenge in den Wassertank für kontinuierliches Dämpfen.



Image: The transparent water tank, showing the water level and ease of installation.

3. **Power Connection:** Plug the power cord into a standard 230V electrical outlet.

4. OPERATING INSTRUCTIONS

The Rolipo SL-007 is designed for quick and effective wrinkle removal. It can be used both vertically and horizontally.

1. **Preheating:** Once plugged in, the steamer will begin to heat up. The indicator light will show when it's ready for use (typically within 20-30 seconds).
2. **Steaming Garments:**
 - Hang the garment on a hanger or lay it flat on a clean, heat-resistant surface.
 - Hold the steamer upright (for vertical steaming) or flat (for horizontal steaming) and press the steam trigger.
 - Move the steam nozzle slowly over the fabric, allowing the steam to penetrate and relax the fibers. For stubborn wrinkles, you may gently press the soleplate against the fabric.
 - For best results, pull the fabric taut with your free hand while steaming.

IN JEDEM WINKEL DÄMPFEN

Flachbügeln und Handbügeln werden empfohlen, vertikal oder horizontal.



Image: Demonstrates both vertical steaming of a shirt on a hanger and horizontal steaming on a flat surface.



Image: Illustrates the strong steam penetration on multiple garments hanging on a rack.

- 3. **Fabric Compatibility:** The steamer is safe for use on most fabrics, including delicate materials like silk, wool, cotton, linen, polyester, and nylon. Always test on an inconspicuous area first.
- 4. **Finishing:** Once steaming is complete, release the steam trigger and unplug the appliance. Allow garments to cool and dry before wearing or storing.

5. MAINTENANCE AND CLEANING

Regular maintenance ensures optimal performance and extends the life of your steamer.

1. **After Each Use:**

- Unplug the steamer and allow it to cool completely.
- Remove the water tank and empty any remaining water.
- Wipe the exterior of the steamer with a soft, damp cloth.

2. **Descaling (Monthly or as needed):**

- If you notice reduced steam output or mineral residue, descaling may be necessary.
- Mix a solution of 50% white vinegar and 50% water.
- Fill the water tank with this solution and run the steamer until the tank is empty.
- Repeat with clean, distilled water to rinse out any vinegar residue.
- **Caution:** Do not use harsh chemicals or abrasive cleaners.

- 3. **Storage:** Store the steamer in a cool, dry place, away from direct sunlight and moisture. Ensure the water tank is empty before storage.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No steam or low steam output.	Water tank empty. Steamer not heated sufficiently. Mineral buildup (scale).	Refill water tank. Allow more time for preheating. Perform descaling procedure (Section 5).
Water leaking from nozzle.	Water tank not properly seated. Overfilled water tank. Steamer not fully heated.	Ensure water tank is securely attached. Do not fill past the MAX line. Wait for the indicator light to show it's ready.
Steamer not turning on.	Not plugged in. Power outlet issue.	Check power cord connection. Test with another outlet.

If the problem persists after trying these solutions, please contact customer support.

7. SPECIFICATIONS

- **Model:** SL-007
- **Brand:** Rolipo
- **Power:** 1800 Watts
- **Voltage:** 230 Volts
- **Color:** Black
- **GTIN/UPC:** 666186537589
- **Weight:** Approximately 0.85 kg (as per product description)

8. WARRANTY AND SUPPORT

Rolipo products are manufactured to high-quality standards. For warranty information or technical support, please refer to the warranty card included with your purchase or contact your retailer. Keep your proof of purchase for any warranty claims.

© 2026 Rolipo. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question