

Boat Airdopes Hype

Boat Airdopes Hype User Manual

Model: Airdopes Hype

INTRODUCTION

Welcome to the user manual for your new Boat Airdopes Hype wireless earbuds. These earbuds are designed to provide a superior audio experience with advanced features and comfortable wear. This manual will guide you through the setup, operation, maintenance, and troubleshooting of your device, ensuring you get the most out of your Airdopes Hype.

PRODUCT OVERVIEW

The Boat Airdopes Hype are sleek, in-ear wireless earbuds that come with a compact charging case. They are engineered for immersive sound and extended listening sessions, making them ideal for daily use, calls, and music.



Figure 1: Boat Airdopes Hype Earbuds and Charging Case. The image displays the black earbuds nestled within their open charging case, highlighting their compact and ergonomic design.

Your browser does not support the video tag.

Video 1: Official Product Overview for Boat Airdopes Hype Wireless Earbuds. This video provides a visual introduction to the earbuds, showcasing their design and key functionalities.

KEY FEATURES

- **Immersive Audio:** Equipped with 13mm drivers for rich, clear sound and a frequency response range of 20Hz-20Khz.

13mm Drivers boAt Signature Sound



Figure 2: 13mm Drivers for Signature Sound. This image highlights the audio quality delivered by the earbuds' 13mm drivers.

- **Clear Communication:** Features Dual Mics with ENx™ Technology for enhanced call clarity.

Dual Mics ENx™ Technology



Figure 3: Dual Mics with ENx™ Technology. Demonstrates the earbud's microphone capability for clear voice transmission.

- **Low Latency Gaming:** BEAST™ Mode provides ultra-low 50ms latency for a seamless gaming experience.

BEAST™ Mode

50ms Low Latency



Figure 4: BEAST™ Mode for Low Latency. Illustrates the earbuds' low-latency feature, beneficial for gaming.

- **Extended Playtime:** Enjoy up to 100 hours of total playback with the charging case. Fast charging provides 120 minutes of playtime from just 10 minutes of charge.

Upto 100 Hours Playback

10 MINS
ASAP™ CHARGE
=
120 MINS
PLAYTIME



Figure 5: Extended Playback and Fast Charging. Highlights the impressive battery life and quick charging capabilities.

- **Seamless Connectivity:** Bluetooth v5.3 with IWP™ Technology for instant pairing and stable connection within a 10-meter operating range.
- **Durable Design:** IPX5 sweat and splash resistance, making them suitable for workouts and outdoor activities.
- **Convenient Charging:** USB Type-C interface for modern and efficient charging.
- **Intuitive Controls:** Touch control functionality for easy management of music and calls.
- **Portable:** Pocketable design for easy carrying.



Figure 6: Connectivity, Durability, and Design Features. This composite image showcases the Bluetooth connectivity, IPX5 rating, Type-C charging, and portable design of the earbuds.

WHAT'S IN THE BOX

- 1 UNIT boAt Airdopes Hype
- 1 Unit USB Type-C Charging Cable
- 1 UNIT Manual (this document)
- 1 UNIT Catalogue
- 1 UNIT Warranty Card

SETUP

1. Initial Charging

Before first use, fully charge your Boat Airdopes Hype. Place both earbuds into the charging case and connect the USB Type-C cable to the charging port on the case and a power source. The indicator lights on the case will show the charging

status. A full charge typically takes about 1 hour for the case and earbuds.

2. Pairing with Your Device

1. Ensure both earbuds are charged and inside the charging case.
2. Open the lid of the charging case. The earbuds will automatically enter pairing mode (indicated by flashing lights on the earbuds).
3. On your mobile device (cellphone), go to *Bluetooth settings*.
4. Search for available devices and select "Boat Airdopes Hype" from the list.
5. Once connected, you will hear a confirmation tone, and the earbud lights will stop flashing.

Note: The earbuds feature IWP™ (Insta Wake N' Pair) Technology, allowing them to connect instantly to your last paired device as soon as you open the case lid.

OPERATING INSTRUCTIONS

The Boat Airdopes Hype features intuitive touch controls on each earbud for easy management of your audio and calls.

Touch Controls

Function	Action
Play/Pause Music	Single tap on either earbud
Next Track	Double tap on the right earbud
Previous Track	Double tap on the left earbud
Answer/End Call	Single tap on either earbud
Reject Call	Long press (2 seconds) on either earbud
Activate Voice Assistant (Google Assistant)	Triple tap on either earbud
Toggle BEAST™ Mode (Low Latency)	Long press (3 seconds) on the right earbud

Power On/Off

- **Power On:** Open the charging case lid, or long press the touch area on both earbuds for 3 seconds if they are outside the case and off.
- **Power Off:** Place the earbuds back into the charging case and close the lid. Alternatively, long press the touch area on both earbuds for 5 seconds.

MAINTENANCE

Proper care will extend the lifespan of your Boat Airdopes Hype earbuds.

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials. Gently clean the charging contacts on both the earbuds and the case to ensure proper charging.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage. Store in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To preserve battery life, avoid fully discharging the earbuds and case frequently. Charge them regularly, even if not in constant use.
- **Water Resistance:** The earbuds are IPX5 sweat and splash resistant. This means they can withstand light rain and

sweat, but they are *not* waterproof. Do not submerge them in water or expose them to heavy rain or strong water jets. Dry them thoroughly before placing them back in the charging case.

TROUBLESHOOTING

If you encounter any issues with your Boat Airdopes Hype, try the following solutions:

- **Earbuds Not Pairing/Connecting:**
 - Ensure both earbuds are charged.
 - Turn off Bluetooth on your device, then turn it back on.
 - Forget "Boat Airdopes Hype" from your device's Bluetooth list and try pairing again.
 - Place both earbuds back into the charging case, close the lid for 5 seconds, then open it again to re-initiate pairing mode.
- **Only One Earbud Working:**
 - Ensure both earbuds are charged.
 - Place both earbuds back into the charging case, close the lid, and then open it again. This often re-syncs them.
 - Perform a factory reset (refer to the specific reset procedure in the full manual if available, or try long-pressing both earbuds while in the case for 10 seconds).
- **Earbuds Not Charging:**
 - Check the USB Type-C cable and power adapter. Try a different cable or adapter.
 - Ensure the charging contacts on the earbuds and inside the case are clean and free of debris.
 - Make sure the earbuds are correctly seated in the charging case.
- **Low Volume/Poor Sound Quality:**
 - Adjust the volume on both your device and the earbuds.
 - Ensure the earbuds are clean and free from earwax buildup.
 - Check if the earbuds are properly seated in your ears for an optimal seal.

TECHNICAL SPECIFICATIONS

Feature	Detail
Model Name	Airdopes Hype
Driver Size	13 mm
Playtime	Up to 100 Hours (Total)
Charging Interface	USB Type-C
Frequency Response	20Hz-20Khz
Operating Range	10 meters
Bluetooth Version	5.3
Compatible Devices	Cellphones
Material	Plastic

Feature	Detail
Dimensions (Product)	4.45 x 2.87 x 1.34 inches
Color	Opal Black
Water Resistance	IPX5 (Sweat & Splash Resistant)
Control Type	Touch Control
Form Factor	In Ear

WARRANTY AND SUPPORT

Your Boat Airdopes Hype comes with a Warranty Card included in the box. Please refer to this card for detailed information regarding warranty terms and conditions.

For further assistance, product registration, or to access the latest support resources, please visit the official Boat website or the product detail page on Amazon.com.

Manufacturer: Imagine Marketing Limited

Documents - Boat – Airdopes Hype




[\[pdf\]](#) User Manual

User Manual Croma Get ready to immerse yourself in musical bliss with your very own pair of boAt Airdopes Hype Please consider this manual as guiding map Buy TWS Earbuds Environmental Noise Cancellation IPX5 Water Resistant ASAP Charge Pearl White Online 274318 media croma image upload v1689070678 Assets Entertainment Wireless |||

...

lang: **score:28** filesize: 80.38 K page_count: 1 document date: 2023-06-21



[\[pdf\]](#) Test Report

Test Report Sysvedh338070000663f46dfca07d imagine boat s3 amazonaws vendor qc reports |||

Test Report TICKET REFERENCE : 45754813 TEST DATE : 11-05-2024 15:52:22
PRODUCT DESCRIPTION : Boat **Airdopes Hype** Pearl White NATURE OF
PROBLEM CUSTOMER VOICE : Charging Issue TEST DETAILS PV INSPECTION
STATUS : PV Claim Rejected REMARKS : Damaged Product-Ear Piece Damaged
IMAGES Page 1 of ...

lang: **score:24** filesize: 277.35 K page_count: 1 document date: 2024-05-11



[boAt Airdopes Hype: User Manual & Specifications for Premium Wireless Earbuds](#)

Comprehensive user manual for boAt Airdopes Hype wireless earbuds. Learn about package contents, power on/off, connection, basic functions, voice assistant, ENx™ Tech, factory reset, specifications, and warnings. Features Bluetooth 5.3 and IPX5 water resistance.

lang: **score:23** filesize: 258.69 K page_count: 1 document date: 2023-07-05