KENSID KS42SH-5014BK

KENSID 52-Inch Low Profile Ceiling Fan Instruction Manual

Model: KS42SH-5014BK

1. Safety Information

Read all instructions carefully before beginning installation. If you are unfamiliar with electrical wiring, consult a qualified electrician. Ensure power is disconnected at the circuit breaker before installation or maintenance. This product is intended for indoor use only. Do not use with a dimmer switch unless specified for ceiling fans. Keep children away from the fan during operation.

- Always turn off power at the main circuit breaker before installation or maintenance.
- Ensure all electrical connections comply with local codes and ordinances.
- Mount the fan to a ceiling joist or a fan-rated outlet box capable of supporting the fan's weight.
- Do not bend blade holders during installation or cleaning.
- Keep a minimum clearance of 7 feet from the floor to the fan blades.

2. Package Contents

Verify all components are present before beginning assembly. If any parts are missing or damaged, contact customer service.



Image: All components of the KENSID 52-inch ceiling fan laid out for inspection, including motor housing, blades, remote control, and mounting hardware.

- Motor Housing Assembly
- Fan Blades (5)
- Blade Brackets (5)
- Light Kit with Dimmable LED
- Remote Control and Receiver
- Mounting Bracket
- Hardware Pack (screws, wire nuts, etc.)
- Instruction Manual

3. Product Features

The KENSID 52-inch ceiling fan offers a blend of modern design and functionality for optimal comfort and lighting.

- **52-Inch Blade Span:** Ideal for medium to large rooms.
- **Low Profile Recessed Mount:** Suitable for rooms with lower ceilings.
- **Dimmable LED Light:** Integrated 22W LED light with adjustable color temperature (3000K Warm, 4500K Natural, 6000K Cold White) and 10%-100% brightness control.
- **6 Adjustable Speeds:** Customize airflow for various activities, from sleeping to fitness.
- **Reversible DC Motor:** Allows for seasonal use (forward for cooling, reverse for circulating warm air).
- **Customizable Remote Control:** Full control over fan speed, light settings, timer, and forward/reverse function. Includes memory function for fan and light states.
- **Ultra-Quiet Operation:** Designed for minimal noise, ensuring a peaceful environment.



Image: The integrated LED light offers three color temperatures and dimmable brightness from 10% to 100%.



Image: The fan features 6 adjustable speeds, suitable for various room activities and comfort levels.



Image: The fan is designed for ultra-quiet operation, providing a comfortable and peaceful environment.

4. Installation Guide

Follow these steps for safe and proper installation of your KENSID ceiling fan. It is recommended to have two people for installation.

4.1 Unboxing and Component Identification

Carefully open the packaging and lay out all components on a clean, soft surface to prevent scratches. Refer to the package contents list to ensure all parts are present.

Your browser does not support the video tag.

Video: This video demonstrates the unboxing and assembly process of the KENSID ceiling fan, including attaching the blades and light kit.

4.2 Motor Assembly

1. Remove the screws from the motor housing.

2. Carefully insert the remote control receiver into the motor housing. Connect the wires from the motor to the receiver as indicated by the color coding (e.g., yellow to yellow, white to white, red to red, black to black).
3. Secure the receiver inside the housing and reattach the cover.

4.3 Blade Attachment

1. Attach each blade bracket to a fan blade using the provided screws. Ensure the "This Side Up" marking on the bracket faces upwards.
2. Secure the assembled blade and bracket to the motor housing. Repeat for all five blades.



Image: Close-up of the fan's components, highlighting the blade attachment points and the LED light kit.

4.4 Light Kit Installation

1. Connect the LED light module wires to the corresponding wires from the motor assembly.
2. Carefully align the light module with the motor housing and secure it with the provided screws.
3. Attach the light cover by twisting it into place or securing it with screws, depending on the design.

4.5 Ceiling Mounting and Wiring

1. Ensure the ceiling mounting bracket is securely attached to a ceiling joist or a fan-rated outlet box.
2. Hang the fan assembly onto the mounting bracket.
3. Connect the household electrical wires to the fan's wiring using wire nuts. Typically, black to black (live), white to white (neutral), and green/bare copper to green/bare copper (ground).
4. Tuck all wires neatly into the outlet box and secure the canopy to the mounting bracket.

5. Operating Instructions

Your KENSID ceiling fan is operated via the included remote control. Install 2 AAA batteries (not included) into the remote control.



Image: The remote control provides comprehensive control over fan and light functions.

5.1 Remote Control Functions

- **Fan ON/OFF:** Press the fan icon button to turn the fan on or off.
- **Fan Speed (1-6):** Use buttons 1 through 6 to select desired fan speed. 1 is the lowest, 6 is the highest.
- **Light ON/OFF:** Press the light bulb icon button to turn the light on or off.
- **Increase/Decrease Brightness:** Use the "+" and "-" buttons to adjust light brightness (10%-100%).
- **Color Temperature Adjustment:** Press the button with the sun icon to cycle through Warm Light (3000K), Natural Light (4500K), and Cold White Light (6000K).
- **Timer Setting:** Press 1H, 4H, or 8H to set the fan to turn off automatically after 1, 4, or 8 hours.
- **Forwards/Reverse:** Press the button with two arrows to change the direction of blade rotation for seasonal use.
- **Enable/Disable Beep Sound:** Press the speaker icon button to toggle the remote's beep sound.
- **Memory Function:** Long press the fan icon to enable/disable fan state memory. Long press the light icon to enable/disable light state memory.

---

6. Maintenance

Regular maintenance ensures optimal performance and extends the life of your ceiling fan.

- **Cleaning:** Use a soft, damp cloth to clean the fan blades and motor housing. Do not use abrasive cleaners or solvents.
- **Blade Balance:** If the fan wobbles, check that all blade screws are tight. You may need to use a balancing kit (not included) to correct severe wobbling.
- **Light Kit:** The integrated LED light is designed for long life and typically does not require replacement. If it malfunctions, contact customer support.
- **Annual Check:** Periodically check all connections and mounting hardware for tightness.

---

7. Troubleshooting

If you experience issues with your KENSID ceiling fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; loose wire connections; remote control battery low.	Check circuit breaker. Ensure all wire connections are secure. Replace remote control batteries.
Fan wobbles	Loose blade screws; unbalanced blades; loose mounting bracket.	Tighten all blade screws. Use a balancing kit. Ensure mounting bracket is securely fastened.
Light does not work	Loose wire connection to light kit; faulty LED module.	Check light kit wiring connections. Contact customer support if LED module is faulty.
Remote control not working	Low batteries; remote not paired with receiver.	Replace batteries. Refer to remote pairing instructions in the full manual (if applicable, or assume it's pre-paired).

---

8. Specifications

Key technical specifications for the KENSID 52-inch ceiling fan.



Product Name	52-inch Ceiling Fan	**Material**	Splint+Metall
Rated Voltage	110V-265V	**F/R**	Foward/Reverse
Motor Power	32W	**Speeds**	1-6 Wind Speeds
Control Method	Remote Control	**Overall Height**	250mm
Lamp Configuration	22W LED	**Fan Blade**	5 Splint Fan Blades

Image: Detailed dimensions and technical specifications of the KENSID 52-inch ceiling fan.

Feature	Detail
Product Name	52-inch Ceiling Fan
Model Number	KS42SH-5014BK
Material	Splint + Metall
Rated Voltage	110V-265V
Motor Power	32W
Control Method	Remote Control

Feature	Detail
Lamp Configuration	22W LED
F/R (Forward/Reverse)	Supported
Speeds	1-6 Wind Speeds
Overall Height	250mm (9.8 inches)
Fan Blade	5 Splint Fan Blades (Reversible: Deep Walnut / Light Walnut)

9. Warranty and Support

For warranty information, technical support, or to order replacement parts, please contact KENSID customer service. Keep your purchase receipt as proof of purchase.
Contact Information: Refer to the product packaging or the seller's website for the most current contact details.

© 2024 KENSID. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question