

PowerLocus B0CTGHQP95

PowerLocus Bluetooth Headphones for Kids User Manual

Model: B0CTGHQP95

Brand: PowerLocus

1. INTRODUCTION

This manual provides comprehensive instructions for the safe and effective use of your PowerLocus Bluetooth Headphones for Kids, Model B0CTGHQP95. Please read this manual thoroughly before using the product and retain it for future reference. This product is designed to provide a safe and enjoyable audio experience for children with features like volume limitation and versatile connectivity options.

2. PACKAGE CONTENTS

Carefully unpack the box and ensure all items listed below are present and in good condition. If any items are missing or damaged, please contact PowerLocus customer support.

- PowerLocus Bluetooth Headphones
- Protective Carrying Case
- Micro USB Charging Cable
- 3.5mm Audio Cable
- User Manual (this document)
- Warranty Card



Image: Contents of the PowerLocus Bluetooth Headphones package, including the headphones, protective case, charging cable, audio cable, and documentation.

3. PRODUCT OVERVIEW

3.1 Headphone Features

- **Bluetooth 5.0 Connectivity:** Provides a stable wireless connection up to 39 feet (12 meters).
- **85dB Volume Limit:** Ensures safe listening levels to protect children's hearing.
- **Built-in Microphone:** For clear communication during calls or online learning.
- **Multiple Playback Modes:** Supports wireless (Bluetooth), wired (3.5mm AUX), and Micro SD card playback.
- **LED Light Feature:** Integrated LED lights on the earcups can be activated or deactivated.
- **Foldable and Extendable Design:** For easy storage and adjustable fit.
- **Comfortable Design:** Features super soft protein foam leatherette earmuffs and a padded headband for extended wear.
- **Long Battery Life:** Up to 10 hours of continuous playback on a single charge.



Image: Detailed view of the headphones showing features like super soft memory foam earmuffs, a soft headband filled with memory foam, and adjustable sizing.

3.2 Headphone Controls and Ports

Familiarize yourself with the location and function of the buttons and ports on your headphones:

Component	Function
Power Switch	Turns the headphones on or off.
Volume Up / Next Track Button	Short press to increase volume; long press to skip to the next track.
Volume Down / Previous Track Button	Short press to decrease volume; long press to go to the previous track.
Play/Pause / Call Answer Button	Press to play or pause audio; press to answer or end a phone call.
LED Indicator Light	Indicates power status, pairing mode, and charging status.
Microphone	For voice input during calls or recordings.
Micro USB Charging Port	Connect the Micro USB cable for charging the headphones.
3.5mm Audio Input (AUX)	Connect the 3.5mm audio cable for wired listening.
Micro SD Card Slot	Insert a Micro SD card for direct audio playback.

4. SETUP

4.1 Charging the Headphones

1. Locate the Micro USB charging port on the headphones.
2. Connect the smaller end of the Micro USB charging cable to the headphone's charging port.
3. Connect the larger end of the USB charging cable to a USB power source (e.g., computer USB port, USB wall adapter).
4. The LED indicator light will illuminate during charging. It will change color or turn off once charging is complete.
5. A full charge provides over 10 hours of playback time.

4.2 Bluetooth Pairing

1. Ensure the headphones are fully charged.
 2. Turn on the headphones by sliding the Power Switch. The LED indicator will flash, indicating pairing mode.
 3. On your device (smartphone, tablet, laptop), navigate to the Bluetooth settings.
 4. Enable Bluetooth and search for available devices.
 5. Select "PowerLocus Kids" (or similar name) from the list of found devices.
 6. Once connected, the LED indicator will stop flashing or change to a solid color, indicating a successful pairing.
 7. The headphones will automatically attempt to reconnect to the last paired device when powered on.
-

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- To power on: Slide the Power Switch to the "ON" position.
- To power off: Slide the Power Switch to the "OFF" position.

5.2 Bluetooth Mode

- **Play/Pause:** Press the Play/Pause button.
- **Volume Control:** Short press the Volume Up (+) or Volume Down (-) buttons.
- **Next/Previous Track:** Long press the Volume Up (+) button for the next track; long press the Volume Down (-) button for the previous track.
- **Answering/Ending Calls:** Press the Play/Pause button to answer an incoming call or end an ongoing call.

5.3 Wired Mode (AUX)

- Connect one end of the 3.5mm audio cable to the AUX input port on the headphones.
- Connect the other end of the 3.5mm audio cable to the audio output jack of your device.
- In wired mode, the headphone's battery is not used, and controls on the headphones may be limited (volume and track control will typically be managed by the connected device).

5.4 Micro SD Card Playback

- Insert a Micro SD card (with supported audio files) into the Micro SD card slot on the headphones.
- The headphones will automatically switch to Micro SD card playback mode.

- Use the Play/Pause, Volume Up/Down, and Next/Previous Track buttons to control playback.

5.5 LED Light Activation



Image: PowerLocus headphones with the LED lights illuminated on the earcups, indicating the LED light feature is active.

- The LED lights on the earcups can be turned on or off. Refer to the specific button on your headphones (often a dedicated button or a long press combination on one of the existing buttons) to toggle this feature.

6. MAINTENANCE

6.1 Cleaning

- Wipe the headphones with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Avoid getting moisture into any openings.

6.2 Storage

- When not in use, store the headphones in the provided protective carrying case to prevent damage.

- Store in a cool, dry place away from extreme temperatures and direct sunlight.



Image: The foldable PowerLocus headphones neatly stored inside a backpack, demonstrating their portability.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Headphones do not power on.	Low battery.	Charge the headphones fully using the provided USB cable.
Cannot pair with a Bluetooth device.	Bluetooth is off on the device; headphones not in pairing mode; device too far.	Ensure Bluetooth is enabled on your device. Make sure headphones are in pairing mode (LED flashing). Bring headphones closer to the device (within 39ft). Try restarting both devices.
No sound in Bluetooth mode.	Volume too low; headphones not connected; incorrect audio output selected on device.	Increase volume on both headphones and connected device. Verify headphones are successfully paired. Check device's audio output settings.
No sound in wired (AUX) mode.	3.5mm cable not fully inserted; cable is faulty; device volume too low.	Ensure the 3.5mm cable is securely plugged into both the headphones and the audio source. Try a different 3.5mm cable if available. Increase volume on the audio source.
Microphone not working.	Microphone muted on device; headphones not selected as input device.	Check microphone settings on your connected device. Ensure the headphones are selected as the input device.

8. SPECIFICATIONS

Feature	Detail
Brand	PowerLocus
Model	B0CTGHQP95
Connectivity Technology	Wireless (Bluetooth), Wired (3.5mm AUX)
Wireless Communication	Bluetooth 5.0
Bluetooth Range	Up to 39 feet (12 meters)
Form Factor	Over Ear
Ear Placement	Over Ear
Volume Limit	85dB
Battery Life	Over 10 hours (wireless mode)
Material	Faux Leather (earmuffs)
Special Feature	Lightweight, Foldable, LED Lights, Built-in Mic, Micro SD Card Slot





9. WARRANTY AND CUSTOMER SUPPORT









PowerLocus provides a **24-month warranty** for these Bluetooth headphones, covering manufacturing defects and workmanship. This warranty ensures your product is free from defects under normal use during the warranty period.

For any questions, technical assistance, or warranty claims, please contact our dedicated customer support team. We offer **24/7 customer support** to assist you.

Please refer to the warranty card included in your package for detailed terms and conditions, or visit the official PowerLocus website for contact information.

Related Documents - B0CTGHQP95

<div> USER MANUAL PowerLocus P2 Kids Princess <small>For Warranty or Problems with the product, please contact us!</small> Email Support: info@powerlocus.com </div>	<p>PowerLocus P2 Kids Princess User Manual</p> <p>Comprehensive user manual for the PowerLocus P2 Kids Princess wireless headphones, covering setup, operation, features, and safety guidelines.</p>
<div> USER MANUAL PowerLocus P2 <small>For Warranty or Problems with the product, please contact us!</small> Email Support: info@powerlocus.com </div>	<p>PowerLocus P2 User Manual: Features, Operation, and Safety</p> <p>Comprehensive user manual for the PowerLocus P2 headphones, detailing product features, pairing instructions, audio modes, charging, and safety guidelines. Includes technical specifications and compliance information.</p>

<div data-bbox="188 114 240 179"></div> <div data-bbox="159 203 271 246"><p>P1 Kids User Manual • Uživatelský manuál • Utworzył manuál • Benutzerhandbuch</p></div>	<p>PowerLocus P1 Kids Wireless Headphones User Manual</p> <p>Comprehensive user manual for the PowerLocus P1 Kids wireless headphones, covering setup, features, troubleshooting, and safety information.</p>
<div data-bbox="197 427 231 468"></div> <div data-bbox="162 481 264 582"></div> <div data-bbox="159 591 271 633"><p>P2 Kids User Manual • Uživatelský manuál • Utworzył manuál • Benutzerhandbuch</p></div>	<p>PowerLocus P2 Kids Wireless Headphones User Manual</p> <p>Comprehensive user manual for the PowerLocus P2 Kids wireless headphones, covering product description, specifications, pairing, MP3/FM functions, call handling, charging, wired mode, safety instructions, and warranty conditions.</p>
<div data-bbox="188 1001 240 1030"></div> <div data-bbox="165 1043 261 1057"><p>USER MANUAL</p></div> <div data-bbox="165 1097 261 1128"><p>PowerLocus P2 Kids</p></div> <div data-bbox="156 1151 271 1167"><p>For Warranty or Problems with the product, please contact us!</p></div> <div data-bbox="165 1178 261 1200"><p>Email Support: info@powerlocus.com</p></div> <div data-bbox="197 1214 231 1254"></div> <div data-bbox="127 1245 185 1261"><p>PowerLocus® All Rights Reserved www.powerlocus.com</p></div>	<p>PowerLocus P2 Kids User Manual</p> <p>User manual for the PowerLocus P2 Kids wireless headphones, detailing features, setup, specifications, and safety guidelines.</p>
<div data-bbox="188 1337 240 1366"></div> <div data-bbox="165 1366 261 1379"><p>USER MANUAL</p></div> <div data-bbox="181 1386 245 1415"><p>PowerLocus P3</p></div> <div data-bbox="165 1417 261 1523"></div> <div data-bbox="165 1525 261 1545"><p>Email Support: info@powerlocus.com</p></div> <div data-bbox="197 1550 231 1590"></div> <div data-bbox="197 1583 231 1597"><p>PowerLocus</p></div>	<p>PowerLocus P3 Wireless Headphones User Manual</p> <p>This user manual provides comprehensive instructions for the PowerLocus P3 wireless headphones, covering setup, operation, features, and troubleshooting. Learn how to pair, charge, and use your P3 headphones effectively.</p>