

## TAB R3

# TAB Carpet Cleaner Machine R3 - Instruction Manual

Model: R3 | Brand: TAB

## PRODUCT OVERVIEW

The TAB R3 Carpet Cleaner Machine is a powerful and portable upholstery spot cleaner designed for deep stain removal. Featuring 18KPa suction power and a self-cleaning hose tool, it is ideal for cleaning carpets, upholstery, car seats, and more. Its dual large tanks separate clean and dirty water, ensuring efficient and hygienic cleaning.

## SETUP AND ASSEMBLY

Before first use, ensure all components are present and undamaged. The machine is designed for easy assembly and storage.

### Components Overview

- Main Unit with Dual Tanks (Clean Water Tank: 54 oz, Dirty Water Tank: 42.2 oz)
- Flexible Hose (5.9 FT)
- Power Cord (16.4 FT)
- Handle with Spray Trigger
- Replaceable Brushes: Multi-function standard brush, Wide brush, T-shape brush, Self-cleaning brush

### Initial Setup

1. **Attach Hose:** Connect the flexible hose to the main unit. Ensure it clicks securely into place.
2. **Select Brush:** Choose the appropriate brush for your cleaning task. Attach it to the handle until it snaps into position.
3. **Fill Clean Water Tank:** Remove the clean water tank (labeled "Clean Water Tank") from the main unit. Open the cap and fill with clean water. You may add suitable cleaning solutions for stubborn stains. Close the cap securely and place the tank back into the unit.
4. **Position Dirty Water Tank:** Ensure the dirty water tank (labeled "Dirty Water Tank") is correctly seated in its compartment.
5. **Plug In:** Plug the power cord into a 120V electrical outlet. The main power switch is located on the back of the unit.



Figure 1: Main unit with tanks and hose attached.

# 18Kpa Super Strong Suction Power

Prepare to Be Amazed: Deep Cleaning Tough Spots in Minutes!



Figure 2: Demonstrating 18KPa Super Strong Suction Power.



# Multifunctional Replaceable Brushes




Figure 3: Various brush attachments for different surfaces like sofa, carpet, car seat, and gaps.

## OPERATING INSTRUCTIONS

The TAB R3 is designed for efficient and chemical-free cleaning. Follow these steps for optimal performance.

1. **Power On:** Press the power button on the control panel. The machine will start.
2. **Select Power Mode:** Use the "Power" button to switch between "Standard" and "Turbo" suction modes. Turbo mode provides stronger suction for tougher stains.
3. **Select Water Temperature:** Use the "Temp" button to choose between "Warm" or "Hot" water. The machine will heat the water to the selected temperature. Hot water is recommended for deep cleaning and stubborn stains.
4. **Clean Surface:** Hold the handle with the attached brush firmly. Press the trigger on the handle to spray water onto the surface. Move the brush slowly over the stained area, allowing the suction to lift the dirty water. Repeat as necessary until the stain is removed.
5. **Avoid Over-Wetting:** Do not over-wet the surface. The powerful suction helps to dry the area quickly.



# Don't Worry About Pet Mess



Figure 4: Cleaning pet messes with the TAB R3.

Your browser does not support the video tag.

Video 1: Official product demonstration of the 18KPA Carpet Cleaner Machine in action.

## MAINTENANCE AND CLEANING

Regular maintenance ensures the longevity and optimal performance of your TAB R3 machine.

1. **Empty Dirty Water Tank:** After each use, remove the dirty water tank. Open the lid and empty the contents into a drain. Rinse the tank thoroughly with clean water.
2. **Clean Brushes:** Detach the used brush from the handle. The brush heads can be disassembled for easier cleaning. Rinse them under running water to remove any debris or residue.
3. **Self-Cleaning Hose Tool:** Attach the self-cleaning brush to the handle. Place the self-cleaning brush into the designated slot on the main unit (usually near the dirty water tank). Turn on the machine and press the spray trigger to flush clean water through the hose, cleaning it internally. This prevents clogs and odors.
4. **Store Properly:** Once all components are clean and dry, wrap the flexible hose around the base of the unit. Secure the power cord using the integrated cord management system. Store the machine in a cool, dry place.

# Removable Large Water Tank

Less Refills, More Cleaning!



Figure 5: Removable 54oz clean water tank and 42oz dirty water tank.



# Self-Cleaning Hose Tool



Figure 6: Using the self-cleaning hose tool for internal hose maintenance.

Your browser does not support the video tag.

Video 2: Official product demonstration of the self-cleaning hose feature.

## TROUBLESHOOTING

If you encounter issues with your TAB R3, try these common troubleshooting steps:

- **No Suction:**

- Check if the dirty water tank is full. Empty and rinse if necessary.
- Ensure the hose and brush attachments are securely connected.
- Verify that the main unit is properly plugged in and the power switch on the back is ON.

- **No Water Spraying:**

- Check if the clean water tank is empty. Refill if necessary.
- Ensure the clean water tank is correctly seated in the unit.

- Verify that the spray trigger on the handle is being pressed.

- **Machine Not Turning On:**

- Check if the power cord is securely plugged into a working outlet.
- Ensure the main power switch on the back of the unit is in the "ON" position.

- **Hose Damage:**

- The detachable hose design allows for easy replacement if damaged. Contact customer support for a replacement.

## SPECIFICATIONS


Brand	TAB
Model Name	R3
Rated Voltage	120 V
Suction Power	18KPa (Turbo Mode)
Clean Water Tank Capacity	54 oz (1600 ml)
Dirty Water Tank Capacity	42.2 oz (1250 ml)
Power Cord Length	16.4 FT (5 m)
Hose Length	5.9 FT (1.8 m)
Item Weight	10.19 pounds
Low Noise Operation	≤80dB

## WARRANTY AND SUPPORT






For any product inquiries, troubleshooting assistance, or warranty claims, please visit the official TAB Store on Amazon or contact customer support.

- **Official TAB Store:** [Visit the TAB Store](#)
- **Protection Plans:** Extended protection plans are available for purchase.
  - 2-Year Protection Plan
  - 3-Year Protection Plan
  - Complete Protect (monthly subscription)

## Related Documents - R3

	<a href="#">TAB R6 Carpet Cleaner Machine User Manual</a> User manual for the TAB R6 Carpet Cleaner Machine, providing comprehensive instructions for safe operation, maintenance, and troubleshooting.
---	--



	<p><a href="#">TAB R6 Carpet Cleaner Machine User Manual</a></p> <p>Comprehensive user manual for the TAB R6 Carpet Cleaner Machine, covering safety instructions, product introduction, preparation, operating instructions, maintenance, and troubleshooting.</p>
	<p><a href="#">TAB T6-Pro Smart Cordless Wet Dry Vacuum Cleaner and Mop User Manual</a></p> <p>Comprehensive user manual for the TAB T6-Pro Smart Cordless Wet Dry Vacuum Cleaner and Mop, covering safety instructions, assembly, operation, maintenance, and troubleshooting.</p>
	<p><a href="#">EG200/EG300 Series Product Information and Refurbished Item Guide</a></p> <p>Information regarding EG200 and EG300 series products, including notes on accessories, model variations, and guidelines for refurbished units. This document serves as an instruction or support guide.</p>
	<p><a href="#">TAB EG200/EG300 Series Product Information and Notes</a></p> <p>Overview of TAB EG200, EG300 series products, including models EG201, EG351, and EG351A. This document provides general information and important notes regarding accessories, illustrative images, and the handling of refurbished units.</p>
	<p><a href="#">TAB e.module L5.1 Lithium-ion Energy Storage System Operation Manual</a></p> <p>This manual provides comprehensive instructions for the installation, operation, and safety precautions for the TAB e.module L5.1 Lithium-ion Energy Storage System. Learn about its features, specifications, front panel controls, and proper handling procedures.</p>