

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [vidaXL](#) /

› [vidaXL Shoe Cabinet Sonoma Oak 80x21x87.5 cm - Instruction Manual](#)

vidaXL 839919

vidaXL Shoe Cabinet Sonoma Oak 80x21x87.5 cm - Instruction Manual

INTRODUCTION

This instruction manual provides detailed guidance for the assembly, operation, and maintenance of your vidaXL Shoe Cabinet, model 839919. Designed for efficient shoe storage in compact spaces, this cabinet features a durable engineered wood construction with a Sonoma Oak finish. Please read all instructions carefully before beginning assembly or use.

Key Features:

- **Durable Material:** Constructed from high-quality engineered wood with a smooth, strong, stable, and moisture-resistant surface.
- **Ample Storage:** Features two flip-drawers designed to keep your shoes organized and easily accessible.
- **Sturdy Top Surface:** The robust top is suitable for displaying decorative items, photo frames, or small potted plants.
- **Space-Saving Design:** Its slim profile is ideal for small areas such as entryways and hallways.

SAFETY INFORMATION

Warning: To prevent tipping, this product **must** be securely attached to the wall using the included wall attachment device. Failure to do so can result in serious injury.

Always ensure all screws and fasteners are tightened properly. Do not overload the cabinet beyond its maximum weight capacity of 40 kg.

SETUP AND ASSEMBLY

Assembly is required for this shoe cabinet. Please follow the steps below. It is recommended to have two people for assembly to ensure stability and ease of construction.

1. **Unpack Components:** Carefully unpack all parts and hardware from the packaging. Verify that all components listed in the parts list are present and undamaged.
2. **Identify Parts:** Familiarize yourself with each panel and piece of hardware. Refer to the included diagram for identification.

3. **Assemble Frame:** Begin by assembling the main frame of the cabinet according to the provided diagrams. Ensure all connections are secure.
4. **Install Flip-Drawers:** Attach the mechanisms and panels for the two flip-drawers. Test their movement to ensure smooth operation.
5. **Attach Back Panel:** Secure the back panel to the cabinet frame.
6. **Wall Attachment:** Using the provided hardware, securely attach the shoe cabinet to a sturdy wall. This step is crucial for safety and stability.



Image: Diagram showing the dimensions of the vidaXL Shoe Cabinet: 80 cm width, 21 cm depth, 87.5 cm height.



Image: vidaXL Shoe Cabinet with both flip-down drawers closed, showcasing its compact design.

OPERATING INSTRUCTIONS

Using your vidaXL Shoe Cabinet is straightforward:

- **Opening Drawers:** Gently pull the top edge of a drawer outwards. The drawer will pivot downwards, revealing the shoe compartments.
- **Storing Shoes:** Place your shoes into the designated compartments within the flip-drawer. The design accommodates various shoe sizes, but avoid forcing oversized items.
- **Closing Drawers:** Push the drawer upwards until it clicks securely into its closed position. Ensure it is fully closed to maintain the cabinet's neat appearance and protect your shoes.



Image: vidaXL Shoe Cabinet with two flip-down drawers open, showing shoes stored inside.



Image: Close-up view of the interior mechanism of a flip-down shoe drawer.

MAINTENANCE

Proper care will extend the life and appearance of your shoe cabinet:

- **Cleaning:** Wipe the surfaces with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the engineered wood finish.
- **Dusting:** Regularly dust the cabinet with a dry, soft cloth to prevent buildup.
- **Spills:** Immediately wipe up any spills to prevent moisture absorption and staining.
- **Inspection:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.

TROUBLESHOOTING

If you encounter any issues with your shoe cabinet, refer to the following common solutions:

- **Cabinet feels wobbly:** Ensure the cabinet is properly attached to the wall using the anti-tipping device. Check that all assembly screws are tightened.
- **Drawers do not open/close smoothly:** Verify that no shoes or objects are obstructing the drawer mechanism. Check that the drawer slides are correctly installed and free of debris.
- **Scratches or minor damage:** For minor scratches, a furniture repair pen or wax stick matching the Sonoma Oak finish can be used.

If problems persist, please contact customer support.

SPECIFICATIONS

Brand	vidaXL
Model Number	839919
Color	Sonoma Oak
Material	Engineered Wood
Product Dimensions (W x D x H)	80 x 21 x 87.5 cm (31.5" x 8.3" x 34.4")
Item Weight	21.74 kg
Maximum Load Capacity	40 kg
Number of Drawers	2
Assembly Required	Yes
Mounting Type	Freestanding (with wall attachment recommended)
Country of Origin	China

WARRANTY AND SUPPORT

For warranty information, please refer to the terms and conditions provided at the time of purchase or contact your retailer. If you require technical assistance, have questions about assembly, or need replacement parts, please contact vidaXL customer support through their official website or the retailer where the product was purchased.