

ESR 6B014

ESR Rebound Magnetic Keyboard Case 360 User Manual

Model: 6B014

1. INTRODUCTION

The ESR Rebound Magnetic Keyboard Case 360 is designed to enhance your iPad experience by providing a versatile keyboard and protective case. It features a detachable back case, a multifunctional trackpad, and multiple viewing angles to support various tasks from typing to browsing.

2. COMPATIBILITY

This keyboard case is specifically designed for the following iPad models:

- iPad Air 13" (M3 2025)
- iPad Air 13" (M2 2024)

To verify your iPad model number, check the back of your device. Compatible model numbers include A3268, A3269, A3271 for iPad Air 13" (M3 2025) and A2898, A2899, A2900 for iPad Air 13" (M2 2024).

Only for iPad Air 13" (M3) 2025 /Air 13" (M2) 2024



iPad Air 13" (M3) 2025/Air 13" (M2) 2024



iPad Air 11" (M2) 2024

Please Double Check

Verify your model number before ordering



Models

iPad Air 13" (M3) 2025:
A3268, A3269, A3271

iPad Air 13" (M2) 2024:
A2898, A2899, A2900

Image: Compatibility chart and how to check your iPad model number.

3. WHAT'S IN THE BOX

Your ESR Rebound Magnetic Keyboard Case 360 package includes:

- ESR Rebound Magnetic Keyboard Case 360
- USB Cable (for charging the keyboard)

4. SETUP

4.1 Attaching Your iPad

The case features a detachable back cover that magnetically attaches to your iPad. Simply align your iPad with the magnetic back cover until it snaps into place. The back cover can be used independently for protection even when the keyboard is not attached.

Versatile Detachable Back Case

Stay protected with or without the keyboard



Magnetically compatible
with original iPad



Image: Detachable back case and magnetic compatibility.

4.2 Bluetooth Pairing

1. Ensure your keyboard is charged.
2. Turn on the keyboard using the power switch.
3. On your iPad, go to **Settings > Bluetooth**.
4. Turn on Bluetooth.
5. The keyboard will appear as "ESR Keyboard" under "Other Devices". Tap on it to connect.
6. Confirm the pairing request on your iPad.

4.3 Charging the Keyboard

Connect the provided USB cable to the charging port on the keyboard and to a compatible USB power adapter. The keyboard uses a USB-C port for charging. A full charge provides extended battery life, with up to 1 year of standby time or 3 months of day use (2 hours a day with backlit keys off).

Do More, Charge Less

Standby 1 year

Day use¹ 3 months

Night use² 1 weeks

¹2 hours a day with backlit keys off ²2 hours a day with backlit keys on

Image: Battery life and charging information.

5. OPERATING INSTRUCTIONS

5.1 Adjusting Viewing Angles

The magnetic stand allows for quick and easy adjustment of viewing angles, providing optimal comfort for various activities such as typing, viewing, and browsing. Simply open the case to set the perfect angle.

Powerful Versatility

Typing

Viewing

Browsing

Image: Powerful versatility in typing, viewing, and browsing modes.

Quick-Set Magnetic Stand

Get the perfect angle just by opening the case




Image: Quick-set magnetic stand for optimal viewing angles.

5.2 Using the Trackpad

The multifunctional trackpad supports various gestures for smooth and accurate control of your iPad. These include clicking, scrolling, zooming, and navigating to the home screen.

Multifunctional Trackpad



Smooth and Accurate Typing




Image: Multifunctional trackpad with gesture support.

5.3 Keyboard Backlight

The keyboard features backlit keys. To adjust the backlight brightness or change colors, use the dedicated function keys on the keyboard. Refer to the keyboard layout for specific key functions.

5.4 Apple Pencil Storage

The case includes a secure magnetic clasp designed to hold and protect your Apple Pencil, ensuring it stays in place

when not in use.

Protect Your Pencil

Secure magnetic clasp



Image: Secure magnetic clasp for Apple Pencil protection.

6. MAINTENANCE

To ensure the longevity of your ESR Rebound Magnetic Keyboard Case 360, follow these maintenance guidelines:

- **Cleaning:** Use a soft, damp cloth to wipe down the exterior of the case and keyboard. Avoid harsh chemicals or

abrasive materials.

- **Storage:** When not in use, keep the case closed to protect the screen and keyboard. Store in a cool, dry place away from direct sunlight.
- **Handling:** Avoid dropping the case or exposing it to extreme temperatures or liquids.

7. TROUBLESHOOTING

7.1 Bluetooth Connectivity Issues

If your keyboard is not connecting to your iPad:

- Ensure the keyboard is turned on and fully charged.
- Make sure Bluetooth is enabled on your iPad (Settings > Bluetooth).
- Forget the device on your iPad (if previously paired) and attempt to pair again.
- Restart both your iPad and the keyboard.
- Ensure the keyboard is within the effective Bluetooth range (typically 10 meters or 33 feet).

7.2 Trackpad Not Responding

If the trackpad is unresponsive or clicks are not registering:

- Ensure the keyboard is properly connected via Bluetooth.
- Check iPad settings for trackpad sensitivity (Settings > Accessibility > Touch > AssistiveTouch > Tracking Sensitivity).
- Clean the trackpad surface to remove any debris or smudges.
- Restart the keyboard and iPad.

7.3 Keyboard Not Charging

If the keyboard is not charging:

- Verify that the USB cable is securely connected to both the keyboard and the power source.
- Try a different USB-C cable and/or power adapter.
- Ensure the power source is functional.

8. SPECIFICATIONS

Model Name	6B014
Brand	ESR
Color	White
Material	Polyurethane (PU), Aluminum, Thermoplastic Polyurethane (TPU), Polycarbonate
Number of Keys	78
Keyboard Layout	QWERTY
Power Source	Rechargeable battery
Item Weight	3.17 pounds
Package Dimensions	12.52 x 9.61 x 1.14 inches

Date First Available	January 29, 2024
----------------------	------------------

9. WARRANTY AND SUPPORT

For warranty information and customer support, please visit the official ESR website or contact their customer service directly. You can also visit the [ESR Store on Amazon](#) for more product details and assistance.

© 2024 ESR. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question