

BILLCONCH S320

BILLCONCH Smart Biometric Gun Safe S320 Instruction Manual

Model: S320
Brand: BILLCONCH

1. INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your BILLCONCH Smart Biometric Gun Safe S320. This smart safe offers multiple quick-access methods including fingerprint, PIN, app, and key, ensuring secure storage for your pistols and other valuables. It features a robust alloy steel construction, an intuitive LCD display with voice guidance, and a flexible interior design.



Image: The BILLCONCH Smart Biometric Gun Safe S320, showcasing its digital keypad, fingerprint scanner, and a smartphone displaying the companion app interface.

2. WHAT'S IN THE BOX

Verify that all components are present before proceeding with setup:

- BILLCONCH Smart Biometric Gun Safe S320
- Emergency Keys (2)
- AA Batteries (4)

- USB-C Charging Cable (for keypad emergency power)
- Mounting Hardware (bolts for concrete/wall mounting)
- Mounting Template
- Instruction Manual
- Detachable Pistol Brackets (6)
- Removable Shelf

Your browser does not support the video tag.

Video: A seller-provided overview of the items included in the BILLCONCH Smart Gun Safe package, demonstrating the unboxing process and highlighting key components.

Your browser does not support the video tag.

Video: A seller-provided full unboxing of the BILLCONCH Smart Safe, detailing each item and its initial presentation within the packaging.

3. SETUP

3.1 Battery Installation

The safe requires four AA batteries for operation. These are included in the package.

1. Locate the battery compartment on the inside of the safe door.
2. Remove the battery compartment cover.
3. Insert four AA batteries, ensuring correct polarity (+/-).
4. Replace the battery compartment cover.



Image: A visual representation of the USB emergency power supply port on the keypad and the internal battery compartment requiring four AA batteries.

3.2 Mounting the Safe

For enhanced security, the safe can be mounted to a wall or floor using the provided hardware and template.

1. Choose a suitable location for mounting.
2. Use the provided mounting template to mark the drill points on the desired surface.
3. Drill pilot holes according to the template.
4. Align the safe's mounting holes with the drilled holes.
5. Secure the safe using the provided bolts.

Fingerprint Unlock

High-resolution fingerprint scanning and self-learning technology unlock a pistol safe with one hand in 1s.



Image: The BILLCONCH Smart Gun Safe S320 with its dimensions labeled, alongside a mounting template to assist with secure installation.

4. OPERATION

4.1 Fingerprint Unlock

The biometric fingerprint scanner allows for quick and secure access.

1. Place a registered finger on the fingerprint sensor.
2. The safe will unlock in approximately 1 second upon successful recognition.



Image: A hand demonstrating the fingerprint unlock feature on the BILLCONCH Smart Gun Safe, with a glowing blue light indicating active scanning.

4.2 Keypad Unlock

Use a programmed PIN code for access.


1. Enter your 6-digit PIN code using the numeric keypad.
2. Press the 'Enter' key (usually indicated by an arrow or checkmark).
3. The safe will unlock.



Convenient APP Control



Easily manage fingerprints and view unlock history anytime.



Note: Privacy is protected since it's connected via Bluetooth

Image: A hand entering a code on the numeric keypad of the BILLCONCH Smart Gun Safe, illustrating the keypad unlock method.

4.3 Key Unlock

In case of battery depletion or electronic malfunction, use the emergency key.

1. Locate the hidden keyhole cover on the keypad panel.
2. Gently remove or slide the cover to expose the keyhole.
3. Insert the emergency key and turn to unlock the safe.



Image: A hand inserting an emergency key into the hidden keyhole of the BILLCONCH Smart Gun Safe's keypad, providing mechanical access.

4.4 App Unlock

The companion app allows for remote management and unlocking via Bluetooth.

1. Download the official BILLCONCH app from your smartphone's app store.
2. Follow the in-app instructions to pair your safe via Bluetooth.
3. Use the app interface to unlock the safe, manage fingerprints, and view unlock history.

BILLCONCH Multifunctional Smart Gun Safe

Keep Your Home Safe: Protect Kids from Guns



Image: Multiple smartphone screens displaying the BILLCONCH app interface, showing options for device management, fingerprint management, and unlock history.

Your browser does not support the video tag.

Video: A seller-provided review demonstrating the various unlock methods of the BILLCONCH Smart Gun Safe, including app functionality, fingerprint scanning, and keypad entry.

5. FEATURES

5.1 Automatic Locking Feature

The safe is designed to automatically lock when the door is closed, provided a valid password or fingerprint has been used. This eliminates the need for manual locking mechanisms.

Keypad Unlock

Numeric keys 0-9 diversify passwords and enhance security. It also opens smoothly with a number PIN with 6 digits.



Image: A comparison illustrating the automatic locking feature of the BILLCONCH-S320 safe versus other brands that require manual knob rotation.

5.2 Smart LCD Display and Voice Guide

The integrated LCD screen provides a smart user interface, displaying information such as date, time, and battery level. Voice guidance assists users through setup and operation, which can be switched to silent mode if preferred.

Two Spare Key

Ensures Access Despite Battery Drain Or Electronic Failure.



Image: The BILLCONCH Smart Gun Safe's LCD display showing menu options for fingerprint management, password management, and system settings, indicating intuitive operation.

5.3 Detachable Pistol Brackets and Removable Shelf

The safe includes six detachable pistol brackets for organized handgun storage. A removable shelf allows for flexible interior configuration, accommodating various items such as documents, cash, or other valuables.

Wait A Moment After Closing The Door For It To Lock Automatically



BILLCONCH-320

Opening:
Enter password, pull door open.

Closing:
Push door to lock automatically.



OTHER BRANDS

Opening:
Enter password, rotate knob, pull door open.

Closing:
Push door, rotate knob to lock.

Image: The interior of the BILLCONCH Smart Gun Safe showing detachable pistol brackets in both folded and unfolded positions, demonstrating flexible storage options.

Detachable Pistol Bracket

The gun safe features 6 removable pistol brackets for secure handgun storage. When not in use, it can be unscrewed to optimize space for other items.




Image: The interior of the BILLCONCH Smart Gun Safe displayed with and without its removable shelf, highlighting customizable storage space.

5.4 Silent Mode and LED Light

The safe offers a silent mode for discreet operation. A built-in automatic LED light illuminates the interior upon opening, ensuring visibility in low-light conditions.



Image: The BILLCONCH Smart Gun Safe highlighting its Silent Mode and LED Light features, with icons representing each function.

6. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your safe.

- **Cleaning:** Wipe the exterior and interior surfaces with a soft, dry cloth. Avoid abrasive cleaners or solvents.
- **Battery Replacement:** Replace all four AA batteries when the low battery indicator appears on the LCD screen.
- **Emergency Power:** If batteries die, use the provided USB-C cable to connect to an external power source for temporary access. This port is for emergency power only and does not charge the internal batteries.

7. TROUBLESHOOTING

If you encounter issues with your safe, refer to the following common solutions:

- **Safe Not Opening:** Ensure batteries are not depleted. Try using the emergency key or the USB emergency power supply. Verify correct PIN entry or proper fingerprint placement.
- **Fingerprint Not Recognized:** Ensure your finger is clean and dry. Try re-registering your fingerprint in the settings menu.
- **Keypad Unresponsive:** Check battery level. If using emergency USB power, ensure a stable connection.
- **App Connectivity Issues:** Ensure Bluetooth is enabled on your smartphone and the safe. Try restarting the app or re-pairing the device.

8. SPECIFICATIONS

Feature	Specification
Brand	BILLCONCH

Model Number	S320
Product Dimensions	11.81"D x 12.99"W x 10.24"H
Item Weight	19.91 pounds
Internal Volume	0.9 cubic feet
Lock Type	Biometric, Keypad, Key, App
Material	Alloy Steel
Color	Black
Special Features	Anti-Theft, Biometric Fingerprint, LCD Display, Voice Guide, Foldable Gun Racks, Automatic Locking, Silent Mode, LED Light
Mounting Type	Wall Mount
Batteries Required	Yes (4x AA Alkaline)
Water Resistance Level	Not Water Resistant
UPC	738629377912

9. WARRANTY AND SUPPORT

BILLCONCH is committed to providing reliable products and excellent customer service. Your safe comes with a comprehensive warranty and dedicated support.

- **Response Time:** Customer inquiries are typically responded to within 8 hours.
- **Money-Back & Replacement:** Enjoy a 30-day money-back guarantee and replacement policy.
- **Warranty Service:** A 365-day warranty is provided for your product.
- **After-Sales Service:** Lifelong after-sales service is available for all customers.



8 hours

Respond quickly within 8 hours



30 Days

30 days money-back & Replacement



365 Days

Warranty Service



L ifelong

After-sales service for everyone

Image: Icons representing BILLCONCH's customer support commitments: 8-hour response, 30-day money-back/replacement, 365-day warranty, and lifelong after-sales service.