



Manuals.plus /

- › **vidaXL** /
- › vidaXL Recliner Chair with Raise Aid (Model 3204824) Instruction Manual

**vidaXL 3204824**

# vidaXL Recliner Chair with Raise Aid (Model 3204824) Instruction Manual

Light Grey Fabric

## 1. INTRODUCTION

---

This manual provides essential instructions for the safe assembly, operation, and maintenance of your vidaXL Recliner Chair with Raise Aid. Please read this manual thoroughly before use and retain it for future reference.



Image 1: The vidaXL Recliner Chair with Raise Aid in a home environment.

## 2. SAFETY INFORMATION

To ensure safe operation and prevent injury or damage, please observe the following safety guidelines:

- **Maximum Load Capacity:** Do not exceed the maximum load capacity of **110 kg**.
- **Power Supply:** Ensure the power adapter for the lift function is connected to a suitable electrical outlet (Input: DC 24V, 1.5A; Output Voltage: 100-240V~, 50-60Hz).
- **Children and Pets:** Keep children and pets away from the chair's moving parts during operation.
- **Clearance:** Ensure adequate clearance around the chair when reclining or using the lift function to avoid obstruction or damage.
- **Stable Surface:** Place the chair on a flat, stable surface.
- **Unplug When Not in Use:** Unplug the chair from the power outlet when not in use or before cleaning/maintenance.
- **Professional Repair:** Do not attempt to repair the electrical components yourself. Contact qualified personnel for service.

### 3. PACKAGE CONTENTS

---

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, contact vidaXL customer support.

- Recliner Chair Base
- Backrest Section
- Armrests (2)
- Power Adapter and Cable
- Assembly Hardware (screws, bolts, etc.)
- Instruction Manual (this document)

### 4. SETUP AND ASSEMBLY INSTRUCTIONS

---

Assembly is required. It is recommended to have two people for assembly. Follow these steps carefully:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a soft, clean surface to prevent scratches.
2. **Attach Backrest:** Slide the backrest section onto the metal brackets located on the chair base until it clicks securely into place. Ensure it is firmly seated.
3. **Connect Armrests:** Attach the armrests to the sides of the chair base using the provided hardware. Tighten all screws firmly, but do not overtighten.
4. **Connect Power:** Locate the power cable from the chair and connect it to the power adapter. Plug the adapter into a standard electrical outlet.
5. **Test Functions:** Before regular use, test both the electric lift and manual recline functions to ensure proper operation.



Image 2: Fully assembled vidaXL Recliner Chair.

## 5. OPERATING INSTRUCTIONS

---

### 5.1 Electric Lift Function

The electric lift function assists users in standing up from the chair. This function is controlled by an electric motor.

- To activate the lift, press and hold the appropriate button on the control panel (usually located on the side of the chair).
- The chair will gently tilt forward and lift, helping you to a standing position.
- Release the button once you have reached the desired height or are fully standing.

- To lower the chair, press and hold the opposite button.




Image 3: Illustration of the electric lift control and chair's lifting motion.

## 5.2 Manual Recline Function

The chair features a manual recline mechanism, allowing you to adjust the backrest and footrest for comfort.

- Locate the handle on the right side of the chair.
- Pull the handle to release the footrest and recline the backrest.
- Lean back to achieve your desired recline angle, up to a maximum inclination of 135 degrees.
- To return to the upright position, push the backrest forward while simultaneously pushing the handle back into its original position. The footrest will retract.



Image 4: Illustration of the manual recline handle and various recline positions.

## 6. MAINTENANCE

---

Regular maintenance will prolong the life and appearance of your recliner chair.

- **Cleaning Fabric:** For general cleaning, use a soft, damp cloth. For spills, blot immediately with a clean, dry cloth. Avoid harsh chemicals or abrasive cleaners.
- **Dusting:** Regularly dust the chair with a soft brush or vacuum cleaner with an upholstery attachment.
- **Moving Parts:** Periodically check all bolts and screws to ensure they are tight. Do not lubricate moving parts unless specifically instructed by the manufacturer.

- **Power Cord:** Inspect the power cord and adapter for any signs of damage. If damaged, discontinue use and contact customer support.

## 7. TROUBLESHOOTING

If you encounter issues with your recliner chair, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Electric lift not working.	Power cord unplugged, outlet not working, damaged power adapter.	Check power connections. Test outlet with another device. Inspect power cord/adapter for damage.
Manual recline mechanism stuck.	Obstruction, mechanism needs adjustment.	Ensure no objects are blocking the mechanism. Check if the handle is fully engaged.
Chair feels unstable.	Loose assembly hardware, uneven floor.	Tighten all assembly screws. Move chair to a level surface.

If the problem persists after attempting these solutions, please contact vidaXL customer support.

## 8. SPECIFICATIONS

Feature	Detail
<b>Brand</b>	vidaXL
<b>Model Number</b>	3204824
<b>Color</b>	Light Grey
<b>Material</b>	Fabric (100% polyester), metal, plywood
<b>Filling Material</b>	Foam, PP fiber
<b>Dimensions (Upright)</b>	75 x 99 x 99 cm (W x D x H)
<b>Dimensions (Reclined)</b>	75 x 145 x 81 cm (W x D x H)
<b>Seat Width</b>	50 cm
<b>Seat Depth</b>	57 cm
<b>Seat Height from Ground</b>	42-44 cm
<b>Armrest Height from Ground</b>	58 cm
<b>Electric Lift Input</b>	DC 24V, 1.5A
<b>Electric Lift Output Voltage</b>	100-240V~, 50-60Hz
<b>Maximum Load Capacity</b>	110 kg
<b>Item Weight</b>	26.85 Kilograms
<b>Assembly Required</b>	Yes



Image 5: Technical drawing with detailed dimensions of the recliner chair.

## 9. WARRANTY AND SUPPORT

---

For warranty information, technical support, or to report missing/damaged parts, please contact vidaXL customer service. Refer to your purchase documentation for specific warranty terms and contact details. You can often find support information on the official vidaXL website or through your retailer.