

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [VOLISUN](#) /

› [VOLISUN Low Profile Ceiling Fan with Light and Remote - Model 8289-BK Instruction Manual](#)

VOLISUN 8289-BK

VOLISUN Low Profile Ceiling Fan with Light and Remote - Model 8289-BK

Instruction Manual

INTRODUCTION

Thank you for choosing the VOLISUN Low Profile Ceiling Fan with Light. This manual provides essential information for the safe and efficient installation, operation, and maintenance of your new ceiling fan. Please read these instructions thoroughly before installation and keep them for future reference.

IMPORTANT SAFETY INFORMATION

WARNING: To reduce the risk of fire, electric shock, or personal injury, always turn off power at the main circuit breaker or fuse box before beginning installation. Ensure all wiring is in accordance with national and local electrical codes. If you are unsure about wiring, consult a qualified electrician.

- Read all instructions carefully before installing the fan.
- Ensure the installation site can support the fan's weight.
- Do not bend fan blades when installing or cleaning.
- Keep a safe distance from rotating fan blades.
- Use only replacement parts specified by the manufacturer.

PACKAGE CONTENTS

Verify that all components are present and undamaged before proceeding with installation.

- Ceiling Fan with Integrated LED Light
- Remote Control

- Mounting Bracket
- Installation Hardware (screws, wire nuts, hook)
- User Manual



Image: Overview of the VOLISUN Low Profile Ceiling Fan components, including the main fan body, remote control, and installation hardware.

SETUP AND INSTALLATION

The VOLISUN Low Profile Ceiling Fan is designed for easy installation, with most components pre-assembled. Follow these steps carefully:

1. Prepare for Installation

- Turn off power at the circuit breaker.
- Ensure the existing electrical box is suitable for ceiling fan support.

2. Install Mounting Bracket

Secure the mounting bracket to the ceiling electrical box using the provided screws. Ensure it is firmly attached.

Your browser does not support the video tag.

Video: This video demonstrates the installation of the mounting bracket to the ceiling. It shows how to secure the bracket and prepare the wiring for the fan.

3. Wiring Connections

Connect the ceiling wiring to the fan's wiring. Match colors (e.g., black to black, white to white, green/bare copper to ground). Use the provided wire nuts to secure connections. Utilize the included S-hook to temporarily hang the fan body while making electrical connections, reducing strain during wiring.

CUSTOMIZABLE LIGHT

Meet all your lighting needs



Warm Light
3000K

Natural Light
4500K

Cold Light
6500K

Stepless Adjustable



Stepless Dimmable



🔧 216LM

🔧 4320LM

Image: Close-up view of the wiring connections, showing how to connect the fan's wires to the household electrical wires using wire nuts.

4. Attach Fan Body to Bracket

Carefully lift the fan body and align it with the mounting bracket. Twist or slide the fan body into place until it locks securely. Tighten any remaining screws to firmly attach the fan to the ceiling.

Your browser does not support the video tag.

Video: This video provides a detailed guide on how to install the ceiling fan light, including connecting wires and securing the fan body.

OPERATING INSTRUCTIONS

Your VOLISUN ceiling fan can be operated via the included remote control, a wall switch, or a smartphone application.

Remote Control Functions

The remote control allows for comprehensive management of your fan and light settings:

- **Power On/Off:** Turn the fan and light on or off.
- **Fan Speed:** Select from 6 different wind speeds.
- **Light Brightness:** Adjust light intensity (216LM to 4320LM).
- **Color Temperature:** Change light color from warm (3000K) to natural (4500K) to cool (6500K).
- **Fan Direction:** Reverse fan direction for summer (downward airflow) or winter (upward airflow).
- **Timer:** Set a 1-hour or 2-hour timer for automatic shutdown.
- **Memory Function:** The fan remembers your last light and fan settings when turned off and on via remote or wall switch.

APP Control

Need to pair by yourself,
please refer to the video for specific instructions.



Image: The remote control for the VOLISUN ceiling fan, highlighting buttons for fan speed, light control, and timer settings.

App Control

For enhanced control, download the VOLISUN smart home application. The app provides all remote control functionalities and may offer additional features. Refer to the app's instructions for pairing and usage.

Your browser does not support the video tag.

Video: This video demonstrates how to pair the ceiling fan light with the mobile application for smart control.

Your browser does not support the video tag.

Video: This video highlights the flexible memory function of the fan, controllable by wall switch, remote, or app.

MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** Use a soft, damp cloth to clean the fan. Do not use abrasive cleaners or solvents.
- **Blade Care:** The fan features clear ABS blades. Wipe them gently to remove dust.
- **Light Source:** The LED light source is integrated and non-removable. Do not attempt to replace individual LEDs.
- **Tighten Screws:** Periodically check and tighten all screws on the fan body and mounting bracket to ensure secure operation.

TROUBLESHOOTING

If you experience any issues with your fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not start	No power, loose wiring, remote battery dead.	Check circuit breaker. Ensure all wire connections are secure. Replace remote batteries.
Light does not turn on/flickers	Loose wiring, remote battery dead, light setting issue.	Check wiring. Replace remote batteries. Cycle through light color temperatures/brightness settings.
Remote not working	Dead batteries, not paired correctly.	Replace remote batteries. Refer to pairing instructions in the full manual.
Excessive noise	Loose screws, fan not mounted securely.	Tighten all screws on the mounting bracket and fan body.

If problems persist, please contact VOLISUN support.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	VOLISUN
Model Name	Ceiling Fan with Light
Model Number	8289-BK
Size	19.7 INCH (19.7"L x 19.7"W x 5.3"H)
Color	Black
Material	Acrylic, Acrylonitrile Butadiene Styrene, Aluminum
Light Source Type	LED
Brightness	4320 Lumens
Color Temperature	3000K-6500K (Dimmable)
Fan Speeds	6
Control Method	App, Remote, Wall Switch
Power Source	Corded Electric
Voltage	110 Volts

Feature	Detail
Item Weight	7.6 Pounds
Room Type Recommendation	Bedroom, Dining Room, Home Office, Kids Room, Living Room

WARRANTY AND SUPPORT

VOLISUN proudly stands behind its products. This ceiling fan comes with **afull 3-year service warranty** covering any defects or malfunctions. If you have any questions or require assistance, please do not hesitate to contact our VOLISUN support team.

For support, please visit the [VOLISUN Store on Amazon](#) or refer to the contact information provided in your package.