

[Manuals.plus](#) /

> [BvenuBigLite](#) /

> BvenuBigLite 52 Inch 3 Blade Outdoor Ceiling Fan with Light Instruction Manual

BvenuBigLite WS-FPZ180-18C-BK-AP

BvenuBigLite 52 Inch 3 Blade Outdoor Ceiling Fan with Light

Model: WS-FPZ180-18C-BK-AP

INTRODUCTION

This manual provides detailed instructions for the safe installation, operation, and maintenance of your BvenuBigLite 52 Inch 3 Blade Outdoor Ceiling Fan with Light. Please read this manual thoroughly before installation and retain it for future reference. Proper installation and use are essential for optimal performance and safety.

SAFETY INFORMATION

- Always turn off power at the circuit breaker before beginning installation or performing any maintenance.
- All wiring must be in accordance with national and local electrical codes. If you are unfamiliar with wiring, consult a qualified electrician.
- Ensure the installation location can support the weight of the fan (approximately 15 kg / 33 lbs).
- Do not connect the fan to a dimmer switch or variable speed controller other than the provided remote control.
- Maintain a minimum clearance of 7 feet (2.1 meters) from the floor to the bottom edge of the fan blades.
- Ensure all connections are tight and secure to prevent the fan from falling or causing electrical hazards.
- This fan is suitable for damp locations, such as covered patios, but not for direct exposure to water.

PACKAGE CONTENTS

Verify that all components are present before beginning installation. If any parts are missing or damaged, contact customer support.

- Fan Motor Assembly
- Fan Blades (3)
- Downrods (3.9" and 7.9")
- Canopy and Mounting Bracket
- LED Light Kit
- Remote Control with Wall Mount
- Hardware Pack (screws, wire nuts, etc.)

SPECIFICATIONS

Brand	BvenuBigLite
Model Number	WS-FPZ180-18C-BK-AP
Colour	White and Gold
Fan Design	3 Blade Ceiling Fan
Power Source	DC
Product Dimensions (D x W x H)	132.1D x 132.1W x 35.6H Centimetres (52 Inch Diameter)
Air Flow Capacity	6800 Cubic Feet Per Minute
Voltage	110 Volts
Number of Speed Settings	5
Light Kit	Dimmable LED, 3-Color Temperature (3000K, 4500K, 6000K)
Control Type	Remote Control
Mounting Type	Downrod Mount
Special Features	Reversible DC Motor, Timer Function (1/2/4/8H)

Ceiling Fan with Remote



Figure 1: Ceiling Fan Specifications and Features Overview. This image illustrates the fan's dimensions, including blade length (51.9 inches), downrod options (3.9 inches and 7.9 inches), and motor housing height (11.42 inches). It also highlights key features with icons: DC Motor, Energy Saving, Remote Control, 1/2/4/8H Timer, 5 Speed Settings, Reversible function, Natural Wind mode, and Lower Noise operation.

SETUP AND INSTALLATION

Before You Begin: Ensure power is disconnected at the circuit breaker. Read all instructions carefully. It is recommended to have two people for installation.

- 1. Mounting Bracket Installation:** Secure the mounting bracket to the ceiling junction box. Ensure the junction box is rated for fan support. Use hardware suitable for your ceiling type.
- 2. Downrod Assembly:** Choose the desired downrod (3.9" or 7.9"). Feed the motor wires through the downrod. Insert the downrod into the motor housing and secure with the provided pin and screw.
- 3. Hanging the Fan:** Carefully lift the fan assembly and hang it on the mounting bracket hook. This allows for hands-free wiring.
- 4. Wiring Connections:** Connect the fan's electrical wires to the household supply wires according to local codes. Typically, this involves connecting live, neutral, and ground wires. Ensure the remote receiver is properly wired between the fan and the power supply.
- 5. Canopy Installation:** Slide the canopy up to the ceiling and secure it to the mounting bracket with screws, ensuring all wires are tucked neatly inside.

6. **Blade Attachment:** Attach the three fan blades to the motor housing using the provided screws. Ensure they are securely fastened.
7. **Light Kit Installation:** Connect the light kit wires to the fan motor assembly wires. Secure the LED light kit to the bottom of the fan motor housing.

For visual guidance, refer to the video guides available from the manufacturer (if applicable) or consult a qualified electrician.

OPERATING INSTRUCTIONS

Your BvenuBigLite ceiling fan is controlled by the included remote control. Ensure the remote has batteries installed.




Figure 2: Remote Control Functions. This image displays the remote control and highlights its various buttons: Light On/Off, Fan Off, 5 Speed Settings, Timer (1H, 2H, 4H, 8H), and Reversible Motor Button (F/R).

- **Power On/Off:** Press the "FAN OFF" button to turn the fan off. Press any speed button (1-5) to turn the fan on. Press the "LIGHT ON/OFF" button to control the light.
- **Fan Speed:** Use buttons "1" through "5" to select the desired fan speed. "1" is the lowest speed, and "5" is the highest.
- **Light Color Temperature:** With the light on, repeatedly press the "LIGHT ON/OFF" button to cycle through the three color temperatures: Warm Light (3000K), Natural Light (4500K), and White Light (6000K). The fan

will beep to confirm the change.

Ceiling Fan with LED Light



Figure 3: Adjustable Light Color Temperatures. This image demonstrates the three available light color temperatures: Warm Light (3000K), Natural Light (4500K), and White Light (6000K), illustrating how the ambiance changes with each setting.

- **Reversible Motor (Summer/Winter Mode):** Press the "F/R" (Forward/Reverse) button to change the direction of the fan blades.
 - **Summer Mode (Downward Airflow):** Blades rotate counter-clockwise to create a cooling breeze.
 - **Winter Mode (Upward Airflow):** Blades rotate clockwise to circulate warm air trapped near the ceiling.

Ceiling Fan with Led Light

3-color change



Warm Light
3000K

Natural Light
4500K

White Light
6000K

Color of light can be changed by remote control (with beep)

Figure 4: Reversible Motor Function. This image visually explains the reversible motor feature, showing blue arrows for downward airflow (Summer mode, sending breeze and keeping cool) and orange arrows for upward airflow (Winter mode, increasing air circulation for warmth).

- **Timer Function:** Press the "1H", "2H", "4H", or "8H" buttons to set the fan to automatically turn off after the selected duration.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your ceiling fan.

- **Cleaning:** Periodically clean the fan blades and motor housing with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these can damage the finish.
- **Blade Tightness:** Check all blade screws periodically to ensure they are tight. Loose blades can cause wobbling and noise.
- **Light Kit:** The LED light kit is designed for long life. If replacement is ever needed, contact customer support for compatible parts. Do not attempt to replace individual LEDs.
- **Remote Control:** Replace batteries in the remote control when its range decreases or it becomes unresponsive. Use AAA batteries.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Remote control issues.	Check circuit breaker; Ensure all wiring connections are secure; Replace remote batteries or re-pair remote if necessary.
Fan wobbles	Loose blades or mounting hardware; Unbalanced blades.	Tighten all blade screws and mounting bracket screws; Ensure blades are installed correctly; Use a balancing kit (not included) if necessary.
Light does not work	Loose wire connection to light kit; Faulty LED driver.	Check light kit wiring connections; Contact customer support for assistance if LED driver is suspected.
Remote control not working	Dead batteries; Remote not paired with receiver.	Replace batteries; Refer to remote pairing instructions (usually involves pressing a button on the remote within a few seconds of restoring power to the fan).
Fan makes noise	Loose screws; Motor hum; Blades hitting an obstruction.	Check and tighten all screws; Ensure no wires are rubbing against the canopy or motor; Verify blades are not hitting anything.

WARRANTY AND SUPPORT

This BvenuBigLite ceiling fan comes with a **3-year warranty** from the date of purchase, covering defects in materials and workmanship. This warranty does not cover damage caused by improper installation, misuse, abuse, or natural disasters.

For warranty claims, technical support, or replacement parts, please contact BvenuBigLite customer service. Have your model number (WS-FPZ180-18C-BK-AP) and proof of purchase ready.

Contact Information: Please refer to the contact details provided on your purchase receipt or the official BvenuBigLite website.