

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [RECHOO](#) /

› [RECHOO SFL007 LED Tactical Flashlight User Manual](#)

RECHOO SFL007

RECHOO SFL007 LED Tactical Flashlight User Manual

Model: SFL007

1. INTRODUCTION

Thank you for choosing the RECHOO SFL007 LED Tactical Flashlight. This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your new flashlight. Please read this manual thoroughly before use and retain it for future reference.



Image 1.1: The RECHOO SFL007 LED Tactical Flashlight, shown as a 2-pack with its retail packaging and included AAA batteries.

2. SAFETY INSTRUCTIONS

- Do not shine the flashlight directly into eyes, as the high lumen output can cause temporary vision impairment.
- Keep out of reach of children.
- Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the flashlight will not be used for an extended period to prevent leakage.
- Dispose of used batteries responsibly according to local regulations.
- Avoid disassembling the flashlight, as this may void the warranty and cause damage.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- RECHOO SFL007 LED Tactical Flashlight (x2)
- AAA Batteries (x6)
- Battery Holders (x2)
- User Manual (this document)

4. PRODUCT OVERVIEW

Familiarize yourself with the components of your RECHOO SFL007 flashlight.

Structure Analysis



Image 4.1: Detailed breakdown of the RECHOO SFL007 flashlight's structural components and features, including the LED bulb, zoom function, anti-slip design, and battery compartment. It also indicates that rechargeable batteries are not supported.

- **LED Bulb:** High-efficiency light source.
- **Zoomable Design:** Adjustable head for focus control.
- **Anti-slip Grip:** Textured surface for secure handling.
- **Single Button:** Controls power and lighting modes.
- **Battery Compartment:** Holds 3x AAA batteries. *Note: Rechargeable batteries are not supported.*

5. SETUP: BATTERY INSTALLATION

Your RECHOO SFL007 flashlight requires 3 AAA batteries. Batteries are included in the package.

1. Unscrew the tail cap of the flashlight by turning it counter-clockwise.
2. Insert the three AAA batteries into the provided battery holder, ensuring correct polarity (+/-) as indicated on the holder.
3. Place the battery holder with batteries into the flashlight body, with the positive (+) end facing towards the head of the flashlight.
4. Screw the tail cap back on clockwise until securely tightened.

6. OPERATING INSTRUCTIONS

6.1 Power On/Off and Mode Selection

The RECHOO SFL007 features a single tactical switch for all operations.



Image 6.1: A user's hand demonstrating the operation of the tactical switch on the RECHOO SFL007 flashlight, highlighting the three available lighting modes: High, Low, and Strobe.

- **To Turn On/Off:** Fully click the tail cap switch once to turn the flashlight ON. Fully click it again to turn it OFF.
- **To Change Modes:** With the flashlight ON, lightly press (half-click) the tail cap switch to cycle through the three lighting modes: **High** → **Low** → **Strobe**.

6.2 Zoom Function (Adjustable Focus)

The flashlight features an adjustable head to change the beam focus from a wide floodlight to a narrow spotlight.



Image 6.2: The flashlight beam adjusted to a narrow, focused spotlight for distant observation (Zoom In).

Weather Resistant

Perfect for outdoor use no matter rain or snow



Image 6.3: The flashlight beam adjusted to a wide floodlight for broad area illumination (Zoom Out).

- **To Zoom In (Spotlight):** Gently pull the head of the flashlight away from the body. This will narrow the beam for a more focused, long-distance light.
- **To Zoom Out (Floodlight):** Gently push the head of the flashlight towards the body. This will widen the beam for broader area illumination.

7. MAINTENANCE

7.1 Cleaning

- Wipe the flashlight body with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Clean the lens gently with a lens cleaning cloth to maintain optimal light output.

7.2 Storage

- Store the flashlight in a cool, dry place when not in use.
- Remove batteries if storing for more than a month to prevent corrosion.

7.3 Weather Resistance

TACTICAL SWITCH

Lightly click it to cycle through 3 modes.
Click it once to turn it ON/OFF.

3

Lighting Modes



High Mode



Low Mode



Strobe Mode



Image 7.1: The RECHOO SFL007 flashlight operating in rainy conditions, highlighting its IPX4 waterproof rating and robust, impact-resistant construction suitable for outdoor use.

The RECHOO SFL007 is designed with IPX4 water resistance, making it suitable for use in various weather conditions like rain or snow. It is also shockproof and impact-resistant due to its military-grade aluminum alloy construction. However, it is not designed for submersion in water.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Flashlight does not turn on.	Dead or incorrectly inserted batteries.	Check battery polarity. Replace with fresh AAA batteries. Ensure tail cap is fully tightened.
Light is dim or flickers.	Low battery power. Loose connections.	Replace batteries. Ensure battery holder and tail cap are securely fastened.
Cannot change lighting modes.	Switch not fully engaged or faulty.	Ensure you are performing a "half-click" for mode changes. If issue persists, contact customer support.
Zoom function is stiff.	Dirt or debris in the mechanism.	Gently clean the exterior of the zoom mechanism. Do not force movement.

9. SPECIFICATIONS

Feature	Detail
Model	SFL007
Light Source	LED
Power Source	3 x AAA Batteries (non-rechargeable)
Material	Military-grade Aluminum Alloy
Lighting Modes	High, Low, Strobe
Special Features	Adjustable Focus (Zoomable), Durable, Portable, Weatherproof (IPX4)
Dimensions	Approximately 4.52 x 1.25 inches
Weight	Approximately 0.17 lb (without batteries)

10. WARRANTY AND CUSTOMER SUPPORT

RECHOO products are manufactured to high-quality standards. For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official RECHOO website. If you encounter any issues not covered in the troubleshooting section, please do not hesitate to contact our customer support team for assistance.

11. INTENDED USE AND PORTABILITY

The RECHOO SFL007 flashlight is designed for a variety of applications due to its compact size and robust features.



Image 11.1: A visual representation of the RECHOO SFL007 flashlight's versatility and compact design, illustrating its use in various scenarios such as reading, camping, and hiking, and its small size compared to a smartphone.

- **Compact and Portable:** Measuring approximately 4.52 x 1.25 inches and weighing 0.17 lb, it fits easily into pockets, bags, or vehicle compartments.
- **Versatile Applications:** Ideal for home emergencies, camping, hiking, dog walking, cycling, power outages, and general outdoor activities.