Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bajaj PX25 Torque

Bajaj PX25 Torque Air Cooler User Manual

Model: PX25 Torque (24L)

1. Product Overview

The Bajaj PX25 Torque Air Cooler is a personal air cooler designed for efficient cooling in small to medium-sized rooms. It features a 24-liter water tank, anti-bacterial honeycomb cooling pads, and a high-speed fan for a powerful air throw.



Image: Bajaj PX25 Torque Air Cooler highlighting key features like inverter compatibility, 4-way swing, 4-way mobility, and 3-speed control.

- **DuraMarine Pump:** Equipped with a DuraMarine Pump for higher insulation, protecting the pump from moisture and extending its lifespan.
- **Anti-bacterial Hexacool Technology:** Ensures cleaner and fresher air by preventing bacterial growth on cooling pads.
- **Turbo Fan Technology:** Provides strong airflow for effective cooling.
- **Air Throw:** Delivers a powerful air throw of up to 5 meters (16 feet).
- **Capacity:** 24-liter water tank for extended cooling.
- **Inverter Compatible:** Designed to work with home inverters, ensuring continuous cooling during power outages.

2. What's in the Box

Upon unpacking, please ensure all the following components are present:

- Bajaj PX25 Torque Air Cooler Unit

- Set of Wheels
- User Manual (this document)
- Warranty Card

Your browser does not support the video tag.

Video: Unboxing the Bajaj PX25 Torque Air Cooler, showing the cooler, wheels, instruction manual, and warranty card inside the packaging.

3. Setup and Installation

1. **Unpacking:** Carefully remove the air cooler from its packaging. Retain the packaging for future transport or storage.
2. **Wheel Installation:** Attach the provided wheels to the base of the cooler. Ensure they are securely fastened for easy mobility.
3. **Placement:** Position the air cooler on a flat, stable surface. For optimal cooling, place it near an open window or door to allow fresh air intake.
4. **Water Filling:** Open the water inlet cap and fill the tank with clean water. Do not exceed the maximum fill line indicated on the cooler. The cooler has a 24-liter capacity.
5. **Power Connection:** Plug the power cord into a suitable 230V AC power outlet.



Image: Diagram showing the dimensions of the Bajaj PX25 Torque Air Cooler and its 24-liter water tank capacity.

4. Operating Instructions

The Bajaj PX25 Torque Air Cooler operates manually using control knobs located on the top panel.

1. **Power On/Off:** Turn the 'Fan' knob to the 'ON' position to start the cooler. Turn it to 'OFF' to switch it off.
2. **Fan Speed Control:** The 'Fan' knob allows you to select from 3 fan speeds (Low, Medium, High) to adjust the airflow intensity.
3. **Pump/Cooling Function:** Turn the 'Swing/Pump' knob to activate the water pump, which circulates water over the cooling pads for evaporative cooling.
4. **Swing Function:** The 'Swing/Pump' knob also controls the 4-way swing deflection, distributing cool air across a wider area.



Image: Close-up view of the control knobs on the Bajaj PX25 Torque Air Cooler for fan speed and swing/pump functions.

5. Maintenance

Regular maintenance ensures optimal performance and longevity of your air cooler.

- **Water Tank Cleaning:** Drain and clean the water tank regularly (at least once a week) to prevent algae growth and maintain hygiene. Use a soft cloth and mild detergent.
- **Cooling Pad Cleaning:** Periodically inspect and clean the honeycomb cooling pads. If heavily soiled, they can be gently rinsed with water. Ensure they are dry before re-installing.
- **Exterior Cleaning:** Wipe the exterior of the cooler with a damp cloth. Do not use abrasive cleaners or solvents.
- **Pump Maintenance:** The DuraMarine Pump is designed for durability, but ensure the water level is always above the minimum mark to prevent dry running.



Image: Bajaj PX25 Torque Air Cooler with an illustration of the DuraMarine Pump, emphasizing its role in longevity and consistent cooling.

6. Troubleshooting

Problem	Possible Cause	Solution
Cooler not turning on	No power supply; Power cord not plugged in; Fuse blown.	Check power outlet; Ensure cord is securely plugged in; Check household fuse/breaker.
No cooling effect	Water tank empty; Pump not working; Cooling pads are dry or clogged.	Fill water tank; Check pump operation; Clean or replace cooling pads.
Reduced airflow	Fan speed set too low; Air filter/pads clogged; Obstruction in air outlet.	Increase fan speed; Clean air filter/pads; Remove any obstructions.
Unpleasant odor	Stagnant water in tank; Dirty cooling pads.	Drain and clean water tank thoroughly; Clean cooling pads.

7. Specifications

Feature	Specification
Brand	Bajaj
Model Name	PX25 Torque
Model Number	480144
Material	Polypropylene (PP)

Feature	Specification
Mounting Type	Freestanding
Color	White
Air Flow Capacity	16 Cubic Feet Per Minute
Controls Type	Knob
Reservoir Capacity	24 Liters
Floor Area Coverage	650 Square Feet
Item Weight	6300 Grams
Wattage	100 Watts
Number Of Speeds	3
Voltage	230 Volts
Operation Mode	Manual
Item Dimensions (D x W x H)	36.5D x 33W x 70.5H Centimeters

8. Warranty and Support

The Bajaj PX25 Torque Air Cooler comes with a comprehensive warranty to ensure peace of mind.

- **Product Warranty:** 3 Years Warranty (1 Year Standard + 2 Years Extended Warranty).
- To avail the 3-year comprehensive warranty, consumers need to register on the official Bajaj Electricals portal.

For any service-related queries or support, please contact Bajaj customer care:

Customer Care Number: 022 - 4128 0000

WhatsApp Number: +91 70399 20000

Email: consumercare@bajajelectricals.com



Image: Bajaj customer care contact details including phone numbers and email address.

© 2024 Bajaj. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CTHC6CXG

More documents and user manuals: **https://manuals.plus/**