

[Manuals.plus](#) /

> [Beleamar](#) /

> Beleamar Manual Launcher & Catching Game Set User Manual

Beleamar 207Y-1+3

Beleamar Manual Launcher & Catching Game Set Instruction Manual

Model: 207Y-1+3 | Brand: Beleamar

INTRODUCTION

Welcome to the world of active outdoor fun with your new Beleamar Manual Launcher & Catching Game Set! This 18-piece set, featuring two frog launchers and sixteen flying discs, is designed to provide dynamic entertainment for kids aged 3 and up. It's perfect for developing motor skills, hand-eye coordination, and encouraging social teamwork in various outdoor settings like backyards, beaches, or parks. Get ready for thrilling competitions and engaging family games!



The Beleamar Manual Launcher & Catching Game Set is 100% kid-powered, promoting active play and family fun.

WHAT'S IN THE BOX

Your Belemar Manual Launcher & Catching Game Set includes the following components:

- 2 x Disc Launchers (Frog Design)
- 16 x Flying Discs (Assorted Colors)



The complete set includes two launchers and sixteen discs for immediate play.

SETUP


The Belemar Manual Launcher & Catching Game Set requires minimal setup, allowing for quick assembly and play.

1. **Unpack Components:** Carefully remove all items from the packaging.
2. **Inspect Launchers:** Ensure the pull-string mechanism on each frog launcher is intact and moves freely.
3. **Prepare Discs:** The flying discs are ready for use directly out of the box.

For a visual guide on unboxing and initial setup, please watch the video below:

Your browser does not support the video tag.

This video demonstrates the unboxing and initial setup of the game set, showing how to prepare the launchers and discs for play.



The launchers and discs are designed for easy handling and durability.

OPERATING INSTRUCTIONS

Operating the Belemar Manual Launcher & Catching Game Set is simple and intuitive, designed for all ages to enjoy.

1. **Load Discs:** Place one or more flying discs into the launcher's opening. The launcher can hold up to four discs at once.
2. **Prepare to Launch:** Hold the launcher firmly with one hand. With the other hand, grasp the pull-ring attached to the string at the bottom of the launcher.
3. **Launch Discs:** Aim the launcher in the desired direction and pull the string sharply and quickly. The discs will launch into the air, reaching heights of 9.8 to 23 feet depending on the number of discs launched.
4. **Catch Discs:** Use the second launcher as a catching net to retrieve the launched discs.

Experiment with launching different quantities of discs to adjust the difficulty and flight patterns. The discs are water-resistant, allowing for play in various outdoor conditions.



Enjoy dynamic play with family and friends, launching and catching discs.



Discs can be launched up to 40 feet, offering exciting long-distance play.

See the launchers in action and learn more about different play styles:

Your browser does not support the video tag.

This video provides a close-up demonstration of how to load and launch the discs, highlighting the ease of use.

Your browser does not support the video tag.

Watch this video to see various outdoor game scenarios and how the launchers can be used for different activities.

MAINTENANCE

To ensure the longevity and optimal performance of your Belemar Manual Launcher & Catching Game Set, follow these simple maintenance guidelines:

- **Cleaning:** The water-resistant discs and launchers can be wiped clean with a damp cloth after use. For tougher dirt, a mild soap solution can be used, followed by rinsing and air drying.
- **Storage:** Store the discs and launchers in a cool, dry place away from direct sunlight when not in use. The discs can be conveniently stored on the launcher's handle for easy organization.
- **Inspection:** Periodically check the pull-string mechanism for any signs of wear or damage. While designed for

durability (tested over 3000 times), regular inspection helps prevent issues.



The product is made from child-friendly, soft, and durable PP material.

TROUBLESHOOTING

If you encounter any issues with your Belemar Manual Launcher & Catching Game Set, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Discs do not launch or launch weakly.	Discs not properly seated; string not pulled sharply enough; string damage.	Ensure discs are placed correctly in the launcher. Pull the string with a quick, firm motion. Inspect the string for fraying or detachment.
String detaches from the launcher.	Excessive force during launch; manufacturing defect.	Attempt to reattach the string if possible. If not, contact customer support for assistance. Avoid pulling the string with extreme force.
Younger children struggle to launch discs.	Requires specific coordination.	Guide the child's hand to demonstrate the correct pulling motion. Start with fewer discs (1-2) for easier launching. Practice makes perfect!

SPECIFICATIONS

- **Product Dimensions:** 5.71 x 5.51 x 5.11 inches
- **Item Weight:** 10.8 ounces
- **Country of Origin:** China
- **Material:** CPSIA/ASTM/EN71 certified PP material
- **Recommended Age:** 3 years and up

- **Model Number:** 207Y-1+3

SAFETY INFORMATION

Please observe the following safety precautions to ensure a safe play experience:

- **Avoid Launch Towards Eyes:** Never aim or launch discs directly at people's faces or eyes.
- **Supervision:** Adult supervision is recommended, especially for younger children, to ensure proper use and safety.
- **Choking Hazard:** Keep small parts away from children under 3 years old.
- **Clear Play Area:** Ensure the play area is clear of obstacles, pets, or other individuals to prevent accidental injury or damage.

WARRANTY & SUPPORT

While specific warranty details are not provided in this manual, Belemar is committed to customer satisfaction. If you have any questions, concerns, or require assistance with your product, please contact Belemar customer support through the retailer's platform or the official Belemar store. We are dedicated to ensuring you and your family enjoy our products to the fullest.

For further assistance, visit the [Belemar Store on Amazon](#).