

Jojoka AC8K003

Jojoka Portable Air Conditioner AC8K003 User Manual

Model: AC8K003

1. INTRODUCTION AND OVERVIEW

Thank you for choosing the Jojoka Portable Air Conditioner, Model AC8K003. This unit is designed to provide efficient cooling, dehumidification, and air circulation for rooms up to 350 sq. ft. It features an 8000 BTU cooling capacity, multiple operating modes, and convenient controls for a comfortable indoor environment.

This manual provides important information regarding the installation, operation, maintenance, and troubleshooting of your portable air conditioner. Please read it thoroughly before use and retain it for future reference.

MULTIPLE PURPOSES

Quiet and powerful



Cooling Mode

8000 Btu up to 350 Sq.Ft



Fan mode

300 m³/HOUR



Dehumidifier Mode

With 26L/day dehumidification capacity



Figure 1: Jojoka Portable Air Conditioner highlighting its Cooling, Fan, and Dehumidifier functions.

2. SAFETY INFORMATION

To ensure safe operation and reduce the risk of injury, electrical shock, fire, or damage to property, please observe the following safety precautions:

- Always connect the unit to a properly grounded electrical outlet with the correct voltage (115 Volts AC).
- Do not operate the unit with a damaged power cord or plug. If the cord is damaged, it must be replaced by the manufacturer or a qualified service agent.
- Do not block the air inlets or outlets of the unit. Maintain adequate clearance around the appliance for proper airflow.
- Do not insert fingers or foreign objects into the air vents.
- Ensure the unit is placed on a stable, level surface to prevent tipping and water leakage.
- Do not use the unit near flammable gases or combustible materials.
- Always unplug the unit before cleaning, servicing, or moving it.

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

3. PRODUCT COMPONENTS

The Jojoka Portable Air Conditioner package includes the following items:

- 1 x Portable Air Conditioner Unit
- 1 x Remote Control
- 1 x Window Kit (adjustable for various window types)
- 1 x Exhaust Hose
- 1 x Instruction Manual (this document)




Figure 2: Main components of the Jojoka Portable Air Conditioner.

4. SETUP AND INSTALLATION

Follow these steps to properly set up your portable air conditioner:

4.1 Positioning the Unit

- Place the unit on a flat, stable surface.
- Ensure there is at least 20 cm (8 inches) of space around the unit for proper air circulation.
- The unit is equipped with universal casters and a carrying handle for easy movement.

4.2 Window Kit Installation

The included window kit is suitable for double/single hung windows or sliding sash windows up to 40 inches in length/width.

1. Adjust the window slider kit to fit your window opening.
2. Secure the window kit in place.
3. Attach one end of the exhaust hose to the unit's exhaust port.
4. Attach the other end of the exhaust hose to the window kit adapter.
5. Ensure all connections are secure to prevent air leakage.

4.3 Drainage Setup

The unit features a manual drainage hole. During dehumidification or prolonged cooling, water will accumulate. You will need to manually drain the water when the unit indicates it is full.

EASY TO INSTALL COMPACT AND PORTABLE

Easily move from room to room
with handles & castors



Figure 3: Proper installation of the exhaust hose and window kit.

5. OPERATING INSTRUCTIONS

Your Jojoka Portable Air Conditioner can be operated using the control panel on the unit or the included remote control.

5.1 Control Panel and Remote Control

The control panel features an LED display and touch buttons for various functions. The remote control offers convenient operation from a distance.



Figure 4: Control panel and remote control for the unit.

5.2 Operating Modes

Press the **MODE** button to cycle through the following modes:

- **Cool Mode:** Provides cooling. Adjust temperature between 61°F (16°C) and 89°F (32°C) using the **UP/DOWN** arrows.
- **Dry Mode (Dehumidifier):** Removes moisture from the air. The fan speed is automatically set to low in this mode.
- **Fan Mode:** Circulates air without cooling. Select high or low fan speed using the **SPEED** button.
- **Sleep Mode:** Operates quietly for comfortable sleeping. The fan speed is automatically set to low.

5.3 Fan Speed Adjustment

In Cool and Fan modes, press the **SPEED** button to select between high and low fan speeds.

5.4 Timer Function

Press the **TIMER** button to set the unit to turn on or off automatically after a set period (up to 24 hours). Use the **UP/DOWN** arrows to adjust the time.

5.5 Oscillation

The unit can be manually adjusted by 100° vertically and 60° horizontally to ensure wide-range oscillation and even air distribution.

6. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your air conditioner.

6.1 Cleaning the Air Filter

The unit is equipped with a cleanable and washable high-density filter (Hyperfilter Technology) to eliminate dust and particles.

1. Unplug the air conditioner from the power outlet.
2. Locate and remove the air filter from the back or side of the unit.
3. Clean the filter using a vacuum cleaner to remove loose dust.
4. For a deeper clean, wash the filter with warm, soapy water. Rinse thoroughly and allow it to air dry completely before reinserting.
5. Reinstall the dry filter into the unit.

It is recommended to clean the air filter every two weeks, or more frequently depending on usage and air quality.

MULTI-SITE APPLICATION



Figure 5: Hyperfilter Technology for air purification.

6.2 Draining Accumulated Water

When the internal water tank is full, the unit may stop operating and display an error code. Manually drain the water:

1. Unplug the unit.
2. Place a shallow pan or tray under the drainage hole at the bottom rear of the unit.
3. Remove the drain plug to allow water to flow out.
4. Once all water has drained, replace the drain plug securely.

6.3 Cleaning the Unit Exterior

Wipe the exterior of the unit with a soft, damp cloth. Do not use harsh chemicals, abrasives, or solvents, as these can damage the surface.

7. TROUBLESHOOTING

If you encounter issues with your Jojoka Portable Air Conditioner, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Unit does not turn on	No power; Power cord not plugged in; Circuit breaker tripped; Full water tank.	Check power connection; Reset circuit breaker; Drain water tank.
Unit is not cooling effectively	Air filter clogged; Exhaust hose not properly installed; Room too large; Doors/windows open; Temperature setting too high.	Clean air filter; Ensure exhaust hose is sealed; Close doors/windows; Lower temperature setting.
Water leakage	Drain plug loose or missing; Unit not level; Internal water tank full.	Secure drain plug; Place unit on a level surface; Drain water tank.
Excessive noise	Unit not on a level surface; Obstruction in fan; Loose parts.	Ensure unit is level; Check for obstructions; Contact customer service if noise persists.

If the problem persists after attempting these solutions, please contact Jojoka customer service for assistance.

8. SPECIFICATIONS

Below are the technical specifications for the Jojoka Portable Air Conditioner Model AC8K003:

- **Model Name:** 8000 BTU Portable Air Conditioners
- **Model Number:** AC8K003
- **Cooling Power:** 8000 British Thermal Units (BTU)
- **Coverage Area:** Up to 350 Square Feet
- **Capacity (Dehumidifier):** 45 pints/day
- **Airflow:** 300 m³/h
- **Voltage:** 115 Volts (AC)
- **Wattage:** 725 watts
- **Noise Level:** 52 Decibels
- **Refrigerant:** R-32
- **Filter Type:** Dust Filter (Cleanable & Washable)
- **Product Dimensions (D x W x H):** 27.9D x 30.5W x 68.6H centimetres (11.0D x 12.0W x 27.0H inches)
- **Item Weight:** 42.5 Pounds (19.3 kg)
- **Control Method:** Remote Control, Control Panel
- **Operating Modes:** Cool, Dry, Fan, Sleep
- **Timer:** 24-hour programmable
- **Window Kit Compatibility:** Max 40 Inches (length/width)

9. WARRANTY AND SUPPORT

Jojoka is committed to providing high-quality products and considerate service. Your portable air conditioner comes with the following:

- **2-Year Warranty:** Covers manufacturing defects and malfunctions under normal use.
- **90-Day Free Replacement:** For eligible issues within the first 90 days of purchase.
- **24-Hour Online Professional Customer Service:** Our dedicated team is available to assist you with any questions or concerns.

For warranty claims, technical support, or any inquiries, please contact our customer service team through the contact information provided on our official website or your purchase platform.