

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Adepem](#) /

› [User Manual: Adepem White Porthole Handle 00266751](#)

Adepem 3665392111580

User Manual: White Porthole Handle

Model: 3665392111580

INTRODUCTION

This manual provides essential information for the installation, operation, and maintenance of your new Adepem White Porthole Handle, model 3665392111580. This handle is a replacement part designed for washing machines, specifically compatible with various Bosch and Siemens models.

Please read this manual thoroughly before attempting any installation or maintenance to ensure proper function and safety.



Image: The Adepem White Porthole Handle, a curved white plastic component with metal pins on each end, designed as a replacement part for washing machine doors.

SETUP AND INSTALLATION

This product is a replacement part. Installation typically involves replacing an existing damaged handle. It is recommended that installation be performed by a qualified technician or an individual with experience in appliance repair.

Safety Precautions:

- Always disconnect the washing machine from the power supply before beginning any installation or repair work.
- Wear appropriate personal protective equipment, such as gloves, if necessary.
- Handle tools and components carefully to avoid injury or damage to the appliance.

General Installation Steps (May vary by washing machine model):

1. **Preparation:** Ensure the washing machine is unplugged and the door is open.
2. **Access:** Depending on the washing machine model, you may need to remove the inner panel of the door to

access the handle mechanism. This often involves unscrewing retaining screws around the door's perimeter.

3. **Remove Old Handle:** Carefully detach the broken or old handle. This usually involves releasing clips or unscrewing fasteners that hold it in place. Note the orientation and connection points.
4. **Install New Handle:** Position the new Adepem handle (model 3665392111580) in the correct orientation. Secure it using the original fasteners or clips. Ensure it moves freely and engages the door latch mechanism correctly.
5. **Reassemble:** Reattach any panels or covers that were removed. Tighten all screws securely.
6. **Test:** Plug the washing machine back into the power supply. Test the door handle by opening and closing the door several times to ensure it latches and unlatches smoothly and securely.

OPERATING THE HANDLE

Once installed, the Adepem White Porthole Handle operates as the original handle of your washing machine. To open the washing machine door, gently pull the handle. To close the door, push it firmly until you hear a click, indicating it is securely latched.

Do not force the handle if the door does not open or close easily. Check for obstructions or issues with the door latch mechanism.

MAINTENANCE

The Adepem White Porthole Handle is designed for durability and requires minimal maintenance. To ensure its longevity:

- **Cleaning:** Wipe the handle periodically with a soft, damp cloth to remove dirt and grime. Avoid abrasive cleaners or solvents that could damage the plastic.
- **Inspection:** Periodically inspect the handle for any signs of wear, cracks, or looseness. Address any issues promptly to prevent further damage.
- **Avoid Excessive Force:** Do not apply excessive force when opening or closing the washing machine door, as this can stress the handle and its internal mechanism.

TROUBLESHOOTING

If you encounter issues with your new handle, consider the following:

- **Handle feels loose:** Check if the screws or fasteners holding the handle in place are tight. Re-tighten if necessary.
- **Door does not latch/unlatch:** Ensure the handle is correctly aligned with the door latch mechanism. There might be an issue with the latch itself, not the handle. Consult your washing machine's specific manual for latch troubleshooting.
- **Handle is stiff:** Ensure no foreign objects are obstructing the handle's movement. Avoid lubricating the handle unless specifically recommended by the washing machine manufacturer.

If problems persist, it is advisable to contact a qualified appliance repair technician.

SPECIFICATIONS

Attribute	Detail
Brand	Adepem

Model Number	3665392111580
ASIN	B0CTHT62PY
Product Dimensions	21 x 17 x 14 cm (8.27 x 6.69 x 5.51 inches)
Weight	250 grams (0.55 lbs)
Manufacturer	ADEPEM A VOS MARQUES, PRÊT, REPAREZ !
Compatibility	Compatible with various Bosch and Siemens washing machine models (e.g., B1wtv3005a/01, Wae16021it/09, Wae20160ff/03, etc.)

WARRANTY AND SUPPORT

For information regarding returns and warranty, please refer to the retailer's policy where the product was purchased. On Amazon.it, if you wish to return a product within 30 days of receipt because you changed your mind, please consult their [help page on returns](#). If you received a defective or damaged product, please consult their [help page on damaged items](#). For specific information on purchases made on the Marketplace, please consult their [help page](#).

For technical support or further assistance with the Adepem White Porthole Handle, please contact the manufacturer or your appliance repair specialist.

