



[Manuals.plus](#) /

> [Veise](#) /

> Veise Door Lock with Handle Set Bundle Instruction Manual

Veise KS02A and KS01B

Veise Door Lock with Handle Set Bundle Instruction Manual

Models: KS02A and KS01B

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Veise Door Lock with Handle Set Bundle. This product offers advanced keyless entry features, combining security with convenience for your home or office.



Image: The Veise Door Lock with Handle Set Bundle, showcasing the keypad deadbolt and the accompanying lever handles in satin nickel.

SETUP AND INSTALLATION

The Veise Door Lock is designed for easy installation with minimal tools. Please follow these steps carefully to ensure proper functionality.

1. Door Compatibility and Measurement

Before installation, verify your door's dimensions and compatibility. The lock is compatible with American standard left and right-handed doors, specifically single cylinder types. It is not compatible with mortise or integrated lock systems.

Check for Proper Size



Door Thickness:
1-3/8"-2"
(35mm-50mm)

Hole Diameter:
2-1/8" (54mm)

1" (25mm)

Backset:
2-3/8" or 2-3/4"
(60mm or 70mm)

Minimum Distance:
4" (101.6mm)

Wide:
1" (25mm)

Latch Hole



Chiseled

Door Compatibility



Single Cylinder



Mortise/Integrated

Image: Detailed measurements for the deadbolt and handle, including door thickness (1-3/8" to 2"), hole diameter (2-1/8"), backset (2-3/8" or 2-3/4"), and minimum distance (4"). Also shows compatibility with single cylinder doors and incompatibility with mortise/integrated systems.

2. Installation Process

Installation typically requires only a screwdriver. The process involves fitting the deadbolt and handle components into the pre-drilled holes on your door. Ensure all components are aligned correctly for smooth operation.

Quick Installation, No Door Damage

 **Left**
Handed Door

 **Right**
Handed Door



*(2 lever handles included)



Front Door



Garage Door



Apartments

Image: A visual guide demonstrating the quick installation of the Veise door lock on both left and right-handed doors using a screwdriver. Examples of suitable door types like front doors, garage doors, and apartment doors are also shown.

3. Initial Programming

After physical installation, you will need to program your initial user codes. Refer to the included quick start guide for specific steps on setting up master codes and user codes.

OPERATING INSTRUCTIONS

Your Veise Door Lock offers multiple convenient ways to secure and access your property.

1. Keyless Entry Options

The lock supports various keyless entry methods:

- **User Codes:** Store up to 20 unique password codes for regular access.
- **One-Time Password:** Generate a temporary code that automatically deletes after a single use, ideal for visitors or service personnel.
- **Physical Keys:** Two spare keys are provided for traditional manual unlocking.

Unlock the Way You Like




Image: The Veise door lock highlighting its versatile unlocking methods, including one-time codes, up to 20 user codes, and traditional key access.

2. Auto-Lock and One-Touch Lock

- **Auto-Lock:** Configure the lock to automatically re-lock after a set period, ranging from 10 to 99 seconds. This feature ensures your door is always secured after entry or exit.
- **One-Touch Lock:** For quick locking from the outside, simply press any button on the keypad for 2 seconds. This is convenient when you are in a hurry.

Lock It Instantly, Your Way



10-99s Auto Lock



One-touch Lock

Any Button
for 2s



Image: A visual explanation of the auto-lock feature, which can be set for 10-99 seconds, and the one-touch lock feature, activated by pressing any button for 2 seconds.

3. Special Modes and Features

The Veise door lock includes several smart features for enhanced usability:

- **Mute Mode:** Silence keypad beeps for quiet operation.

- **Vacation Mode:** A security feature designed for extended absences, disabling normal user code entry.
- **Backlit Keypad:** The keypad illuminates for easy visibility in low-light conditions.
- **Low Battery Alert:** Notifies you when the batteries are running low.
- **Water Resistant:** Rated IP54 for protection against splashes.

Classic Look Smart Features




Image: Icons depicting the smart features of the Veise door lock, including Silent Mode, Vacation Mode, Low Battery Alert, Backlit Keypad, ANSI Grade 3 certification, and IP54 Waterproof rating.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your Veise Door Lock.

1. Battery Replacement

The lock is powered by 4 AA batteries, which typically last for over one year. Replace batteries promptly when the low battery alert is activated to avoid interruption of service.

2. Cleaning

Clean the keypad and lock body with a soft, dry cloth. Avoid using abrasive cleaners or solvents, as these can damage the finish or electronic components.

TROUBLESHOOTING

If you encounter issues with your Veise Door Lock, refer to the following common problems and solutions.

- **Lock not responding:** Check battery level. Replace batteries if low.
- **Keypad not lighting up:** Ensure batteries are correctly installed and charged.
- **Codes not working:** Verify that the correct code is being entered. Ensure the lock is not in Vacation Mode.
- **Auto-lock not engaging:** Check the auto-lock settings and ensure the door is fully closed.

For persistent issues, consult the full product manual or contact customer support.

SPECIFICATIONS

Feature	Description
Brand	Veise
Special Feature	Keyless Entry
Lock Type	Keypad Deadbolt
Style	Veise Door Lock with Handle Set Bundle
Color	Satin Nickel
Controller Type	Hand Control, Mechanical knob
Control Method	Touch
Item Model Number	KS02A and KS01B
ASIN	B0CTHT7T1S
Date First Available	July 5, 2023
Power Source	4 AA Batteries
Security Rating	ANSI Grade 3
Water Resistance	IP54

WARRANTY INFORMATION

For detailed warranty information, please refer to the documentation included with your product or visit the official Veise website. Keep your proof of purchase for warranty claims.

CUSTOMER SUPPORT

If you require assistance with your Veise Door Lock, please contact Veise customer support through their official website or the contact information provided in your product packaging. When contacting support, please have your model number (KS02A and KS01B) and purchase details ready.

© 2024 Veise. All rights reserved.