

Garden Winds LCM2033B-RS

Garden Winds Replacement Canopy for Aecojoy Ss16087gr 8' x 5' Grill Gazebo - RipLock 350 Fabric Instruction Manual

Model: LCM2033B-RS

1. PRODUCT OVERVIEW


This document provides instructions for the Garden Winds RipLock 350 Replacement Canopy Top Cover, designed specifically for the Aecojoy Ss16087gr 8' x 5' Grill Gazebo. This replacement canopy features upgraded RipLock 350 fabric for enhanced durability and performance.

Key Features:

- **RipLock 350 Fabric:** 350 Denier Polyester with double RipLock Technology, featuring double-walled high tensile strength gridlines to prevent rips from spreading.
- **Ultra Stitch:** Reinforced 4-ply thread stitching for superior seam strength.
- **Dura Pockets:** Dual-layer pockets with two rows of Ultra Stitch at each hem to prevent bursting.
- **UPF 50+ Protection:** Provides excellent protection against harmful UVA and UVB rays.
- **Water Resistant:** Designed to repel water.
- **CPAI-84 Fire Retardant:** Meets fire safety standards.
- **Color:** Beige Whisper.



Image 1.1: The Garden Winds RipLock 350 Replacement Canopy, folded for packaging.





DOUBLE RIPLOCK TECHNOLOGY

anti-rip performance fabric

Double walled gridlines designed to provide double the strength and durability



ULTRA STITCH

superior seam strength

Reinforced 4 ply thread stitching gives seams superior pull strength



DURA POCKETS

high performance pockets

Dual layer pockets include two rows of Ultra Stitch at each hem to prevent pocket from bursting



UPF 50 +

highest ultraviolet protection factor

Harmful UVA and UVB rays cause premature skin aging, sunburn and potential skin cancer

Our fabrics are rated UPF 50+ to provide you with excellent protection from the sun

Image 1.2: Detailed diagram showcasing the advanced features of the RipLock 350 fabric, including double RipLock technology, Ultra Stitch seams, Dura Pockets, and UPF 50+ sun protection.

2. SETUP INSTRUCTIONS

This replacement canopy is designed to fit the Aeocjoy Ss16087gr 8' x 5' Grill Gazebo frame. Ensure you have the correct gazebo model before proceeding. The metal structure, netting, and privacy curtains are not included with this replacement canopy.

Preparation:

1. **Inspect Contents:** Carefully unpackage the replacement canopy and inspect for any damage or missing components.
2. **Clear Area:** Ensure the area around your gazebo frame is clear of obstructions.
3. **Remove Old Canopy:** If an old canopy is present, carefully remove it from the gazebo frame. Note how it was

attached to assist with the new installation.

4. **Inspect Frame:** Check the gazebo frame for any damage, rust, or loose connections. Repair as necessary before installing the new canopy.

Installation Steps:

1. **Unfold Canopy:** Carefully unfold the new canopy top. Identify the top and bottom layers, and the corners.
2. **Position Canopy:** Drape the canopy over the gazebo frame. It is often easiest to start by aligning one corner and then working around the frame.
3. **Secure Corners:** Attach the canopy to the frame at each corner. The Dura Pockets are designed to fit over the frame's corner supports.
4. **Stretch and Secure:** Gradually stretch the canopy over the remaining frame sections, ensuring a snug fit. Secure any additional attachment points, such as ties or hooks, if present on your gazebo frame.
5. **Adjust for Tension:** Ensure the canopy is evenly tensioned across the entire frame to prevent water pooling and wind damage.



Image 2.1: Underside view of a gazebo frame with the canopy fabric properly installed and stretched.



Image 2.2: Detail of the central frame connection point, illustrating how the canopy attaches to the gazebo structure.

3. USAGE GUIDELINES

To ensure the longevity and safety of your replacement canopy, adhere to the following guidelines:

- **Stable Surface:** Always ensure the gazebo is assembled on a stable, level surface.
- **Weather Conditions:** Do not use the gazebo in windy conditions or during thunderstorms. High winds can cause significant damage to the canopy and frame. Remove the canopy during severe weather to prevent damage.
- **Snow Accumulation:** In snowy conditions, regularly clear any accumulated snow from the canopy to prevent structural collapse due to excessive weight.

- **Fire Safety:** Keep the canopy clean and dry to maintain its fire retardant properties. Keep all flame and heat sources away from the canopy fabric.
- **Children and Pets:** Keep children and pets away from the gazebo when it is being assembled or disassembled.

4. CARE AND MAINTENANCE

Proper care and maintenance will extend the life of your Garden Winds replacement canopy.

- **Cleaning:** Clean the canopy regularly with mild soap and water. Avoid harsh chemicals or abrasive cleaners, which can damage the fabric's protective coatings. Rinse thoroughly and allow to air dry completely before folding or storing.
- **Drying:** Ensure the canopy is completely dry before storing to prevent mildew and mold growth.
- **Storage:** When not in use for extended periods or during off-season, remove the canopy from the frame, clean it, and store it in a cool, dry place away from direct sunlight.
- **Inspection:** Periodically inspect the canopy for any signs of wear, tear, or damage. Address minor issues promptly to prevent them from worsening.

5. TROUBLESHOOTING

Canopy Does Not Fit:

- **Verify Model Number:** Confirm that your gazebo frame is indeed the Aecojoy Ss16087gr model. This replacement canopy is custom-fit for this specific model. The manufacturer's model number for this canopy is LCM2033B-RS.
- **Check Orientation:** Ensure the canopy is oriented correctly on the frame. Sometimes rotating it can resolve fit issues.
- **Even Stretching:** Make sure the canopy is stretched evenly across all frame sections. Uneven stretching can make it appear too small or too large in certain areas.

Water Pooling on Canopy:

- **Proper Tension:** Ensure the canopy is installed with adequate tension to allow water to run off. Sagging areas can collect water.
- **Frame Integrity:** Check if the gazebo frame itself is level and not bent or damaged, which could create low spots.

Minor Rips or Tears:

- While RipLock technology is designed to prevent spreading, minor damage can still occur. Small tears can often be repaired with a suitable fabric repair kit designed for outdoor materials.

6. PRODUCT SPECIFICATIONS

Brand:	Garden Winds
Model Number:	LCM2033B-RS
Compatible Gazebo Model:	Aejoy Ss16087gr 8' x 5' Grill Gazebo
Material:	RipLock 350 Denier Polyester Fabric
Color:	Beige Whisper

Product Dimensions (L x W):	96"L x 60"W (8 ft x 5 ft)
Water Resistance Level:	Water Resistant
UV Protection:	UPF 50+
Fire Retardant:	CPAI-84 Certified
Assembly Required:	Yes (for installation on existing frame)
UPC:	717964080138

7. WARRANTY INFORMATION

Garden Winds replacement canopies are designed for durability and performance. Specific warranty details may vary. For information regarding potential manufacturer warranties or guarantees, please refer to the product packaging or contact Garden Winds customer support directly. This replacement canopy is guaranteed to fit the Aecojoy Ss16087gr model number.

Extended protection plans may be available for purchase separately through retailers. These plans are not provided by Garden Winds directly.

8. CUSTOMER SUPPORT

For further assistance, questions regarding installation, or product inquiries, please contact Garden Winds customer support.

- **Brand:** Garden Winds
- **Online Store:** [Visit the Garden Winds Store on Amazon](#)

When contacting support, please have your product model number (LCM2033B-RS) and the compatible gazebo model (Aecojoy Ss16087gr) available for quicker service.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question