

[Manuals.plus](#) /

› [CAPHAUS](#) /

› CAPHAUS 44-Inch Portable Closet Wardrobe Instruction Manual

CAPHAUS FBDW-CH4406-DKGY CH

CAPHAUS 44-Inch Portable Closet Wardrobe Instruction Manual

Model: FBDW-CH4406-DKGY CH

1. INTRODUCTION

Thank you for choosing the CAPHAUS 44-Inch Portable Closet Wardrobe. This instruction manual provides essential information for the safe assembly, operation, and maintenance of your new clothing rack. Please read this manual thoroughly before assembly and retain it for future reference.



Image 1.1: The CAPHAUS 44-Inch Portable Closet Wardrobe, fully assembled and in use, showcasing its covered design and internal storage capabilities for various clothing items and accessories.

2. SAFETY INFORMATION

To ensure safe use of this product, please observe the following precautions:

- **Weight Capacity:** Do not exceed the maximum load capacity of 230 lbs (104 kg) for the entire unit. The hanging area supports up to 55 lbs (25 kg), and each shelf supports up to 20 lbs (9 kg). Overloading can cause structural failure and injury.
- **Anti-Tip Kit:** Always install the provided Anti-Tip Kit to prevent accidental tipping, especially in households with children or pets. Wall-attached safety kit is recommended for enhanced stability.
- **Assembly:** Assemble the unit on a flat, stable surface. Ensure all connections are securely fastened before use.
- **Placement:** Place the wardrobe on a level surface to prevent instability. Avoid placing it in high-traffic areas where it could be easily bumped.
- **Children and Pets:** Keep children and pets away from the unit during assembly. Do not allow children to climb on or play with the wardrobe.
- **Maintenance:** Regularly check all connections and components for signs of wear or damage. Replace any damaged parts immediately.



ORGANIZE YOUR STYLE,
UNVEIL YOUR SPACE.



Wall Attachment
Safety Kit



Water-repellent
Cover



High Quality
Zipper

Image 2.1: Key safety and design features, including the wall attachment safety kit for stability, the water-repellent cover, and the high-quality zipper for durability and protection.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact CAPHAUS customer support.

Part	Description	Quantity
Metal Pipes (various lengths)	Main structural components of the frame.	Varies
PP Resin Connectors	Joints for connecting metal pipes.	Varies
Non-Woven Fabric Shelves	Fabric panels for creating shelves.	6
Hanging Rods	Rods for hanging clothes.	Varies
Water-Repellent Cover	Outer fabric cover with zipper and side pockets.	1
Anti-Tip Kit	Components for securing the wardrobe to a wall.	1 Set
Instruction Manual	This document.	1

Note: The exact number of metal pipes and connectors will vary based on the specific design of the 44-inch model. Refer to the included parts list in your package for precise quantities.

4. ASSEMBLY INSTRUCTIONS

Assembly typically requires one person and takes approximately 30-60 minutes. No additional tools are required beyond what is provided or your hands.

4.1. Preparation

- Unpack all components and lay them out on a clean, flat surface.
- Identify each part using the package contents list.
- Ensure you have enough space for assembly.

4.2. Step-by-Step Assembly

1. **Assemble the Base Frame:** Connect the shortest metal pipes to the base connectors to form the bottom rectangular frame. Ensure all pipes are fully inserted into the connectors for a secure fit.
2. **Install Vertical Supports:** Attach the vertical metal pipes to the base frame connectors. Pay attention to the height differences for the hanging and shelving sections.
3. **Add Lower Shelves:** Slide the non-woven fabric shelves onto the designated pipe sections for the lower shelf levels. Ensure they are taut and flat.
4. **Construct Middle Frame:** Connect the next set of horizontal pipes to the vertical supports to form the middle frame, which will support the upper shelves and hanging rods.
5. **Install Upper Shelves and Hanging Rods:** Place the remaining non-woven fabric shelves and insert the hanging rods into their respective connectors.

6. **Complete Top Frame:** Attach the final set of vertical pipes and connect them with horizontal pipes to form the top frame.
7. **Attach the Cover:** Carefully drape the water-repellent fabric cover over the assembled metal frame. Ensure the zipper aligns correctly and the side pockets are accessible.
8. **Secure with Anti-Tip Kit:** Using the provided Anti-Tip Kit, secure the wardrobe to a wall following the instructions included with the kit. This is crucial for stability.



Image 4.1: Detailed product dimensions of the 44-inch closet wardrobe, including width (44"), depth (19.7"), and height (65.7"), along with internal shelf and hanging area measurements.



Image 4.2: Illustrates the superior quality of CAPHAUS components, including thickened non-woven fabric, high-quality PP resin connectors, and sturdy 16mm metal pipes, compared to thinner, lower-quality alternatives.

5. OPERATING INSTRUCTIONS

The CAPHAUS Portable Closet Wardrobe is designed for versatile storage of clothing and accessories.

- **Hanging Clothes:** Use the hanging rods for garments that require hanging, such as shirts, dresses, and pants. Distribute weight evenly across the rod.
- **Shelf Storage:** Utilize the six shelves for folded items like sweaters, t-shirts, and linens. They are also suitable for shoes, hats, handbags, and storage boxes.
- **Side Pockets:** The four side pockets on the cover provide convenient storage for smaller items such as scarves, ties, socks, or small accessories.
- **Cover Usage:** The removable water-repellent cover protects your clothes from dust and moisture. Use the high-quality zipper to open and close the wardrobe. The cover can be removed for an open-rack style if desired.



CAPHAUS®



HEAVY DUTY CLOSET ORGANIZER 230 lbs

Max Load Capacity



Image 5.1: Illustrates the robust load capacities of the CAPHAUS closet organizer, with a total maximum capacity of 230 lbs, individual hanging sections supporting 55 lbs, and shelves supporting 20 lbs each.

Adaptable Elegance

C
CAPHAUS®

Effortless customization: adjustable shelves, removable covers.
Tailor your wardrobe to your lifestyle.



Shirt



Dress



T-Shirt



Pants



Shoes



Pillow



Box



Image 5.2: Demonstrates the adaptable design of the wardrobe, showing both the covered configuration for protection and the open-rack configuration for easy access and display, accommodating various clothing types and accessories.

6. MAINTENANCE AND CARE

- **Cleaning the Frame:** Wipe the metal frame with a dry cloth to remove dust. For stubborn marks, use a slightly damp cloth and dry immediately. Do not use abrasive cleaners or solvents.
- **Cleaning the Cover:** The water-repellent non-woven fabric cover can be wiped clean with a damp cloth. For deeper cleaning, it can be removed and hand-washed with mild soap and water, then air-dried completely before reattaching. Do not machine wash or tumble dry.
- **Regular Inspection:** Periodically check all pipe connections and connectors to ensure they remain tight and secure. Re-tighten if necessary. Inspect the fabric shelves and cover for any tears or damage.
- **Storage:** If disassembling for storage, ensure all parts are clean and dry. Store in a cool, dry place away from direct sunlight.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Wardrobe is wobbly or unstable.	Pipes not fully inserted into connectors; uneven surface; overloaded.	Ensure all pipes are pushed firmly into connectors. Move to a level surface. Reduce load to within specified weight limits. Install Anti-Tip Kit if not already done.
Fabric shelves sag.	Overloaded shelf; fabric not tautly installed.	Reduce weight on the shelf. Re-install the fabric shelf, ensuring it is pulled tight across the frame.
Zipper on cover sticks or breaks.	Misalignment; excessive force; defect.	Ensure the cover is properly aligned on the frame. Apply gentle, even pressure when zipping. If broken, contact customer support for replacement parts.
Missing or damaged parts upon arrival.	Shipping damage; packaging error.	Do not proceed with assembly. Contact CAPHAUS customer support immediately with your purchase details.

8. SPECIFICATIONS

- Model:** FBDW-CH4406-DKGY CH
- Dimensions (L x W x H):** 44 x 19.7 x 65 inches (111.76 x 50.04 x 165.1 cm)
- Material:** Metal (16mm steel pipes), Non-Woven Fabric, PP Resin Connectors
- Color:** Dark Grey
- Total Load Capacity:** 230 lbs (104 kg)
- Hanging Rod Capacity:** Up to 55 lbs (25 kg) per rod
- Shelf Capacity:** Up to 20 lbs (9 kg) per shelf
- Number of Shelves:** 6
- Special Features:** Portable, Heavy Duty, Removable Water-Repellent Cover, Side Pockets, Anti-Tip Kit
- Installation Method:** Free standing (with wall attachment safety kit recommended)
- Product Care:** Wipe with Dry Cloth (for frame), Hand wash and air dry (for cover)

9. WARRANTY AND SUPPORT

CAPHAUS stands behind the quality of its products. For warranty information, replacement parts, or technical assistance, please contact CAPHAUS customer support through the retailer where you purchased the product or visit the official CAPHAUS website.

Please have your model number (FBDW-CH4406-DKGY CH) and purchase date ready when contacting support.

Note: Specific warranty terms may vary by region and retailer. Refer to your purchase documentation for details.

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question