

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [EasyKeys](#) /

› [EasyKeys Supreme J249 File Cabinet Replacement Key Instruction Manual](#)

EasyKeys J249

EasyKeys Supreme J249 File Cabinet Replacement Key Instruction Manual

Model: J249

1. INTRODUCTION

This manual provides essential information for the proper use and care of your EasyKeys Supreme J249 replacement key. This key is specifically designed for file cabinets, desks, and cubicles that utilize the Supreme J200 - J500 series lock system, identified by the J249 code.

2. PRODUCT OVERVIEW

The EasyKeys Supreme J249 replacement key is a custom-cut key made from an IN86 key blank, ensuring compatibility and reliable operation with Supreme series locks requiring the J249 code. It is constructed from durable brass material.



Image 1: EasyKeys Supreme J249 Replacement Key. This image displays the general appearance of the brass key, similar to the J249 model, which is custom-cut for specific Supreme series locks.

Key Features:

- Custom Cut: Precisely cut to match the J249 lock code.
- Durable Material: Made from brass for longevity.
- Compatibility: Designed for Supreme J200 - J500 series locks.

3. IDENTIFYING YOUR LOCK CODE

Before ordering or using a replacement key, it is crucial to correctly identify the code on your existing key or lock. The J249 key is specifically for locks marked with "J249".

Where to Find Your Lock Code




On the Key



On the Lock Face



**On a Label Inside/
Behind the Lock**



**On the
Cabinet/Door Label**



Important Notes

- Order by Manufacturer → Lock codes are manufacturer-specific.
- Key Cuts Differ → Even if codes look similar, they vary by brand.

Image 2: Locations to Find Your Lock Code. This diagram illustrates common places where lock codes can be found, including directly on the key, on the lock cylinder face, on a label inside or behind the lock mechanism, or on a label affixed to the cabinet or door itself. Ensure the code matches "J249" for this replacement key.

Common Locations for Lock Codes:

1. **On the Existing Key:** If you have an original key, the code is often stamped directly on the key head.

2. **On the Lock Face:** The code may be engraved or printed on the visible part of the lock cylinder.
3. **Inside/Behind the Lock:** For some furniture, the code is on a label or stamped on the lock mechanism itself, which may require opening the cabinet or removing a drawer.
4. **On the Cabinet/Door Label:** Occasionally, the lock code is provided on a sticker or plate located on the furniture itself, near the lock.

Important Note:

- Lock codes are manufacturer-specific. Always verify the manufacturer (Supreme/Hudson) and the exact code (J249).
- Key cuts differ even if codes appear similar across different brands. This key is for Supreme/Hudson J249 locks only.

4. COMPATIBILITY

This replacement key is compatible with the following:

- **Manufacturers:** Hudson / Supreme (GCODE)
- **Lock Series:** Supreme J200 - J500 series furniture cabinet locks.
- **Key Code:** J249

It is designed for use with file cabinets, desks, and cubicles equipped with the specified lock type.

5. OPERATING INSTRUCTIONS

To use your EasyKeys Supreme J249 replacement key:

1. **Insert the Key:** Gently insert the key into the lock cylinder of your file cabinet, desk, or cubicle. Do not force the key.
2. **Turn to Lock/Unlock:** Turn the key clockwise or counter-clockwise, depending on the lock mechanism, to engage or disengage the locking bolt.
3. **Remove the Key:** Once the lock is engaged or disengaged, return the key to its original insertion position (usually vertical) before removing it.

Caution:

- Avoid excessive force when inserting or turning the key, as this can damage the key or the lock mechanism.
- Ensure the key is fully inserted before attempting to turn it.

6. MAINTENANCE

Proper maintenance can extend the life of your key and ensure smooth operation of your lock:

- **Keep Clean:** Periodically wipe the key with a soft, dry cloth to remove dirt or debris.
- **Storage:** Store the key in a dry place, away from extreme temperatures or corrosive substances.
- **Lubrication (Optional):** If the lock mechanism becomes stiff, a small amount of graphite lubricant (powdered graphite) can be applied to the key or directly into the keyway. Avoid oil-based lubricants, as they can attract dust and grime.
- **Avoid Bending:** Do not use the key for purposes other than its intended function, such as prying, as this can bend or break the key.

7. TROUBLESHOOTING

If you encounter issues with your replacement key, consider the following:

- **Key Does Not Insert Fully:**
 - Check for obstructions in the keyway.
 - Ensure the key is oriented correctly.
 - Verify that the key code (J249) matches the lock.
- **Key Inserts but Does Not Turn:**
 - Confirm the key code (J249) matches the lock.
 - Apply gentle, consistent pressure while turning. Do not force.
 - The lock mechanism might be jammed or require lubrication (refer to Maintenance section).
 - The lock may be damaged or worn.
- **Key Feels Loose or Wobbly:**
 - This could indicate a worn lock cylinder or a slightly incorrect key cut. Double-check the lock code.

If troubleshooting steps do not resolve the issue, contact EasyKeys customer support for further assistance.

8. SPECIFICATIONS

Feature	Detail
Brand	EasyKeys
Model Name	J249
Part Number	J249-supreme-key-628441
Manufacturer	Supreme
Material	Brass
Lock Type	Cam
Special Features	Adjustable Fit, Custom Cut Key, Durable
Item Dimensions (L x W x H)	0.5 x 0.5 x 1 inches
Item Weight	4 ounces
Included Components	Key

9. WARRANTY AND SUPPORT

For information regarding warranty coverage or to obtain customer support, please contact EasyKeys directly. Details are typically available on the EasyKeys official website or through your purchase documentation.

For general inquiries or assistance, you may visit the [EasyKeys Store on Amazon](#).

