

Kapbom KA-8506

Kapbom KA-8506 Waterproof Bluetooth Speaker User Manual

Model: KA-8506

INTRODUCTION


Thank you for choosing the Kapbom KA-8506 Waterproof Bluetooth Speaker. This portable speaker is designed to deliver quality sound in various environments, including home, beach, travel, and office settings. Its waterproof design ensures durability, and the integrated microphone allows for convenient hands-free calls and audio messages.

WHAT'S IN THE BOX

Please check the package contents to ensure all items are present:

- 1x Kapbom KA-8506 Waterproof Bluetooth Speaker
- 1x Auxiliary Cable (P2 to P2)
- 1x USB Charging Cable
- 1x User Manual (this document)

KAPBOM



A caixa enviada pode ser de uma cor diferente da foto.



Image: Packaging box for the Kapbom KA-8506 speaker, illustrating its dimensions (13.5 cm height, 13 cm width, 6 cm depth) and a weight of 420 grams.

PRODUCT OVERVIEW

The Kapbom KA-8506 speaker features a compact, rugged design with intuitive controls. Familiarize yourself with the speaker's components:



Image: Top and side views of the Kapbom KA-8506 speaker in black. The top view shows the speaker grille, while the side view displays the control buttons (+, -, and a central button) and the rugged rubberized casing.

- **Speaker Grille:** Front-facing audio output.
- **Control Buttons:** Located on the side, typically for Power/Play/Pause, Volume Up/Next Track, and Volume Down/Previous Track.
- **Charging Port:** USB input for charging.
- **Auxiliary Input:** 3.5mm jack for wired audio connection.
- **Microphone:** Integrated for hands-free communication.

SETUP

1. Charging the Speaker

1. Connect the supplied USB charging cable to the speaker's charging port.
2. Connect the other end of the USB cable to a 5V DC power source (e.g., a USB wall adapter or computer USB port).
3. The charging indicator light will illuminate.
4. A full charge takes approximately 2 hours. The indicator light will change or turn off once charging is complete.

Note: Ensure the charging port cover is securely closed after charging to maintain the speaker's waterproof integrity.

2. Bluetooth Pairing

1. **Power On:** Press and hold the Power button (usually the central button) for a few seconds until you hear an audible prompt or see an indicator light flash, indicating it's in pairing mode.
2. **Activate Bluetooth:** On your smartphone, tablet, or other Bluetooth-enabled device, go to the Bluetooth settings and ensure Bluetooth is turned on.
3. **Search for Devices:** Your device will scan for available Bluetooth devices.
4. **Select Speaker:** Locate "KA-8506" (or similar name) in the list of available devices and select it to pair.
5. **Confirmation:** Once paired, you will hear a confirmation sound from the speaker, and the indicator

light will typically stop flashing and remain solid.

Tip: If pairing fails, turn off the speaker and your device's Bluetooth, then repeat the steps.

OPERATING INSTRUCTIONS

Power On/Off

- **To Power On:** Press and hold the central Power button for approximately 3 seconds.
- **To Power Off:** Press and hold the central Power button for approximately 3 seconds.

Music Playback (Bluetooth Mode)

- **Play/Pause:** Press the central Power button once.
- **Volume Up:** Press the '+' button.
- **Volume Down:** Press the '-' button.
- **Next Track:** Press and hold the '+' button.
- **Previous Track:** Press and hold the '-' button.

Call Functions

With the integrated microphone, you can manage calls directly through the speaker when connected via Bluetooth.

- **Answer Call:** Press the central Power button once when an incoming call rings.
- **End Call:** Press the central Power button once during a call.
- **Reject Call:** Press and hold the central Power button for 2 seconds when an incoming call rings.

Auxiliary Input (Wired Connection)

To play audio from devices without Bluetooth, use the auxiliary cable:

1. Connect one end of the auxiliary cable to the speaker's AUX-in port.
2. Connect the other end to the audio output of your device (e.g., headphone jack).
3. The speaker will automatically switch to AUX mode or may require a mode button press (if available).
4. Control playback and volume from your connected device.

Waterproof Feature

The Kapbom KA-8506 is designed to be waterproof. This makes it suitable for use in environments where it may be exposed to water, such as by the pool, beach, or in the shower. Ensure all port covers are securely sealed before exposing the speaker to water to maintain its waterproof integrity.

MAINTENANCE

- **Cleaning:** Wipe the speaker with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures when not in use for extended periods.
- **Water Exposure:** After exposure to water, ensure the speaker is dry before charging. Do not charge a wet speaker.

TROUBLESHOOTING

- **Speaker will not turn on:**

- Ensure the battery is charged. Connect the speaker to a power source using the USB cable.
- Press and hold the Power button for a longer duration (e.g., 5 seconds).

- **Cannot pair with Bluetooth device:**

- Ensure the speaker is in pairing mode (indicator light flashing).
- Make sure Bluetooth is enabled on your device and it is within range (typically 10 meters).
- Forget "KA-8506" from your device's Bluetooth list and try pairing again.
- Restart both the speaker and your Bluetooth device.

- **No sound:**

- Check the volume levels on both the speaker and your connected device.
- Ensure the speaker is properly paired via Bluetooth or the auxiliary cable is fully inserted.
- Try playing a different audio source.

- **Poor sound quality:**

- Move the speaker closer to your Bluetooth device to reduce interference.
- Ensure there are no obstructions between the speaker and your device.
- Check the audio quality of the source material.

SPECIFICATIONS

Model Name	KA-8506
Brand	Kapbom (Generic)
Connectivity Technology	Bluetooth 4.2
Speaker Type	Outdoor / Portable
Output Power	5W
Impedance	4 Ohm
Power Supply	5V DC via USB
Battery Capacity	3.7V / 1200mAh
Charging Time	Approximately 2 hours
Usage Time	Approximately 12 hours
Material	Rubber, Metal, Electronic Circuit
Dimensions (Diameter x Height)	113 mm x 50 mm (approx. 4.45 in x 1.97 in)
Weight	420 Grams (approx. 0.93 lbs)
Waterproof	Yes
Control Method	Touch (Buttons)

Compatible Devices	Notebook, Smartphone, Tablet
Included Components	Auxiliary cable, Charging cable, Manual

WARRANTY AND SUPPORT

The Kapbom KA-8506 speaker comes with a limited warranty of 30 days from the date of purchase. This warranty covers manufacturing defects. Please retain your proof of purchase for warranty claims.

For technical support, warranty inquiries, or further assistance, please contact your retailer or the manufacturer directly using the contact information provided at the point of purchase.