

KOBI FOCUS KASZMIR

KOBI Focus TV Cabinet User Manual

Brand: KOBI | Model: FOCUS KASZMIR

PRODUCT OVERVIEW

The KOBI Focus TV cabinet is a functional, yet original and eye-catching element for your living room. The FOCUS model is equipped with a shelf and lockable cabinets where you can store books, newspapers, or remote controls for audio equipment. The cabinet is made of high-quality furniture panels laminated on both sides in trendy colors. The advantage of our cabinets is their durability. The FOCUS model is lightweight, allowing you to quickly move it and change its arrangement when you get tired of your living room decor.



Figure 1: An assembled KOBI Focus TV cabinet in cashmere finish, featuring two closed cabinets on the sides and an open central shelf with two compartments. The cabinet stands on four elegant gold-colored metal legs.

ASSEMBLY INSTRUCTIONS

The KOBI Focus TV Cabinet is designed for self-assembly. Please ensure all components are present before beginning.

The package includes all necessary elements and detailed instructions.

1. **Unpack Components:** Carefully unpack all parts and hardware from the packaging. Verify against the included parts list to ensure nothing is missing or damaged.
2. **Assemble Cabinet Body:** Follow the step-by-step diagrams in the provided assembly manual to connect the laminated furniture panels to form the main body of the cabinet. Ensure all connections are secure.
3. **Install Hinges and Doors:** Attach the high-quality hinges to the cabinet body and then mount the side doors. Adjust as necessary for smooth operation.
4. **Attach Legs:** The steel legs (13 cm height) can be screwed into place as desired. Ensure they are firmly attached and provide stable support for the cabinet.
5. **Final Checks:** Once assembled, gently test the stability of the cabinet and the operation of the doors.




Figure 2: A technical diagram illustrating the key dimensions of the KOBI Focus TV cabinet. It shows an overall length of 135 cm, a depth of 40 cm, and a total height of 48 cm, including the 13 cm leg height. Internal shelf dimensions are also indicated, with side cabinet width of 36 cm and central open section width of 63 cm, and shelf height of 14.8 cm.



Figure 3: The Kobi Focus TV cabinet with its side doors open, revealing the internal storage compartments. The central open shelf area is also visible, demonstrating the cabinet's functional design for organizing media devices and other items.

USAGE GUIDELINES

The Kobi Focus TV Cabinet is designed to enhance your living space with both style and functionality. Here are some guidelines for optimal use:

- **Placement:** Position the TV cabinet on a flat, stable surface in your living room or desired area. Ensure there is adequate space around it for ventilation of electronic devices.
- **Storage:** Utilize the central open shelf for media devices such as set-top boxes, gaming consoles, or soundbars. The two lockable side cabinets provide discreet storage for books, magazines, remote controls, or other personal items, helping to keep your living area tidy.
- **Weight Capacity:** While durable, avoid placing excessively heavy items on the cabinet, especially on the open shelf, to prevent damage or instability. Refer to the specifications for weight limits if available in the detailed assembly manual.
- **Cable Management:** Consider using cable ties or management solutions to keep wires from electronic devices neat and out of sight, enhancing the aesthetic appeal.



Figure 4: The KOBİ Focus TV cabinet integrated into a modern living room. It is positioned beneath a wall-mounted television, accompanied by a matching tall shelving unit to its left. The room features a green accent wall, a light-colored rug, and a potted plant, showcasing the cabinet's aesthetic appeal in a home environment.

CARE AND MAINTENANCE

Proper care will ensure the longevity and appearance of your KOBİ Focus TV Cabinet:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. For stubborn marks, use a mild, non-abrasive cleaner specifically designed for laminated furniture. Dry immediately with a clean, soft cloth.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, strong solvents, or polishes containing silicone, as these can damage the laminated finish.
- **Protect from Heat and Moisture:** Avoid placing hot items directly on the surface. Use coasters or protective pads under drinks. Promptly wipe up any spills to prevent water damage.
- **Sunlight Exposure:** Prolonged exposure to direct sunlight can cause fading. Position the cabinet away from direct sunlight or use curtains/blinds to protect it.
- **Moving the Cabinet:** When moving the cabinet, always lift it rather than dragging it to prevent damage to the legs and floor.

TROUBLESHOOTING

If you encounter any issues with your KOBİ Focus TV Cabinet, refer to the following common troubleshooting tips:

- **Wobbly Cabinet:**
 - Ensure the cabinet is placed on a level surface.
 - Check that all assembly screws and fasteners are tightened securely. Do not overtighten.
 - Verify that the legs are evenly screwed in and making full contact with the floor.
- **Doors Not Closing Properly:**
 - Inspect the hinges for any loose screws or misalignment. Adjust the hinges as per the assembly manual if

necessary.

- Ensure nothing is obstructing the door's path inside the cabinet.

• **Scratches or Minor Damage:**

- For minor scratches on the laminated surface, furniture repair kits or touch-up pens matching the cashmere color may be used.

For issues not covered here, please refer to the original assembly manual or contact customer support.

PRODUCT SPECIFICATIONS

| | |
|------------------------|---|
| Brand | KOBI |
| Model Number | FOCUS KASZMIR |
| Color | Focus_135/K/Prof-zo/16 (Cashmere) |
| Dimensions (L x W x H) | 135 x 40 x 48 cm |
| Weight | 30 kg |
| Material | Laminated Furniture Panels, Steel Legs |
| Leg Height | 13 cm |
| Special Features | Equipped with shelf and lockable cabinets, high-quality hinges, ABS edge banding, adjustable leg placement. |
| Assembly Required | Yes (Self-assembly) |

WARRANTY AND SUPPORT

Warranty Information: Specific product warranty details are not explicitly provided in the product listing. Please refer to your purchase documentation or contact the seller directly for any warranty-related inquiries.

Customer Support: For any questions regarding assembly, missing parts, or product issues, please contact the seller, MEBLEKO, through the platform where you made your purchase. They will be able to provide the most accurate and timely assistance.

