Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > PETKIT /
- > PETKIT YumShare Dual Hopper Automatic Pet Feeder and Eversweet Solo SE Water Fountain User Manual

PETKIT YumShare Dual Hopper Automatic Pet Feeder and Eversweet Solo SE Water Fountain

PETKIT YumShare Dual Hopper Automatic Pet Feeder and Eversweet Solo SE Water Fountain User Manual

Model: PETKIT YUMSHARE DUAL-HOPPER + EVERSWEET SOLO SE

INTRODUCTION

Welcome to the PETKIT YumShare Dual Hopper Automatic Pet Feeder and Eversweet Solo SE Water Fountain. This manual provides detailed instructions for the setup, operation, and maintenance of your new pet care system. Please read thoroughly before use to ensure proper function and safety.

SAFETY INFORMATION

- For indoor use only.
- · Keep out of reach of children and pets during assembly and when not in use.
- Use only original power adapters provided with the product.
- Do not immerse the main feeder unit in water. Clean with a damp cloth only.
- Ensure the water fountain is filled to the appropriate level to prevent dry burning of the pump.
- Regularly clean all components to maintain hygiene and prevent bacterial growth.

PACKAGE CONTENTS

Verify that all items are present in the package:

- PETKIT YumShare Dual Hopper Automatic Pet Feeder
- PETKIT Eversweet Solo SE Water Fountain
- Power Adapter for Feeder
- USB Cable for Water Fountain
- User Manual

PRODUCT OVERVIEW

PETKIT YumShare Dual Hopper Automatic Pet Feeder

The YumShare feeder features a dual-hopper system for dispensing different types of food, a 1080P camera with night vision and two-way audio, and smart app control for convenient pet feeding management.



This image displays the complete PETKIT pet feeding and watering system. On the left is the white automatic pet feeder with two transparent food hoppers visible at the top, labeled '01' and '02'. The feeder has a dispensing tray at the bottom filled with pet food.

On the right is the white Eversweet Solo SE Water Fountain, also with a minimalist design.



This image shows the PETKIT YumShare feeder with a smartphone positioned next to it. The phone screen displays a live video feed from the feeder's integrated camera, showing a dog. This illustrates the remote monitoring capability of the feeder.

PETKIT Eversweet Solo SE Water Fountain

The Eversweet Solo SE Water Fountain provides fresh, filtered water for your pet with a wireless pump design for enhanced safety and ease of cleaning.



This image features the PETKIT Eversweet Solo SE Water Fountain next to a white cat. The cat is shown licking its lips, indicating satisfaction with the water. The fountain is a compact, white square unit.

SETUP GUIDE

Step 1: Unpacking and Initial Inspection


Carefully remove all components from the packaging. Inspect for any visible damage before proceeding with assembly.

Step 2: Assembling the YumShare Feeder

- 1. Place the main feeder unit on a flat, stable surface.
- 2. Ensure the food dispensing tray is securely attached to the base of the feeder.
- 3. Open the top lid and fill the hoppers with dry pet food. The dual hoppers allow for separate food types or mixing.
- 4. Close the lid securely to maintain food freshness and prevent spills.
- 5. Connect the power adapter to the feeder and plug it into a wall outlet.



This image shows a cutaway view of the PETKIT YumShare feeder's internal mechanism, highlighting the dual dispense system. It illustrates how food from two separate hoppers (labeled 01 and 02) can be dispensed, with a cat observing the process. A graphic overlay indicates setting 3 portions from hopper 1 and 0 portions from hopper 2.



This image provides a detailed internal view of the feeder's dispensing mechanism, labeled "PRECISE PORTION CONTROL WITHOUT BEING STUCK". It points out the "Larger dispensing container", "Advanced impeller", and "Wide dispensing chute". Below, examples of compatible food types are shown: Freeze-dried Food, Mixed Food, Dry Food, and Air-dried Food, with a note about kibble size not exceeding 12mm (0.47in).

Step 3: Assembling the Eversweet Solo SE Water Fountain

- 1. Disassemble the fountain components for initial cleaning. Wash all parts (except the wireless pump and power adapter) with water and mild soap.
- 2. Reassemble the fountain. Place the wireless pump into its designated slot at the bottom of the water tank.
- 3. Fill the water tank with clean water up to the maximum fill line.

- 4. Place the filter tray and filter element into position.
- 5. Connect the USB cable to the fountain and a power source.



This image highlights the "WIRELESS WATER PUMP" feature of the Eversweet Solo SE Water Fountain. It shows a transparent view of the fountain's base with a blue glowing wireless pump mechanism. Text indicates "Eliminates any exposed wires" and "Magnetic induction power supply". A cat is shown in the background.

Step 4: App Download and Connection

- 1. Download the "PETKIT" app from your smartphone's app store (available for iOS and Android).
- 2. Create an account or log in to your existing PETKIT account.
- 3. Follow the in-app instructions to add your YumShare Feeder and Eversweet Solo SE Water Fountain. Ensure your Wi-Fi network is 2.4GHz for successful connection.

OPERATING INSTRUCTIONS

Feeder Operation via PETKIT App

The PETKIT app provides comprehensive control over your YumShare Feeder's functions:

- Setting Feeding Schedules: Create customized feeding plans, including specific meal times, precise portion sizes, and selection of which hopper (01 or 02) to dispense from. You can also mix percentages from both hoppers.
- Manual Feeding: Dispense food instantly with a tap in the app for immediate feeding.
- 1080P HD Camera: Access live video streaming of your pet. The 140° wide-angle lens and IR night vision provide clear views day and night.
- **Two-Way Audio:** Use the built-in microphone and speaker to communicate with your pet remotely, offering comfort and interaction.
- **Meal Call Recording:** Record a personalized 20-second voice message to play automatically at meal times, reminding your pet to eat.
- **Notifications:** Receive real-time alerts for low food levels, Wi-Fi disconnection, or other operational issues directly on your smartphone.

DUAL-HOPPER, LARGE CAPACITY



Cat & Dog universal




21 Cups of food storage



This image focuses on the feeder's camera module, labeled "PET CAMERA EF/2.7mm F/2.0". Surrounding icons indicate "Two-way audio", "Infrared night vision", "1080P HD", and "140° wide-angle", emphasizing the advanced monitoring capabilities.

AI CAPTURING

Auto-capture pet motion and present it as a picture



This infographic, titled "AI CAPTURING", illustrates how the feeder automatically captures pet motion and presents it as pictures. A timeline shows events like "Breakfast has been dispensed", "The pet comes to eat", and "The pet appeared", accompanied by corresponding images of a cat interacting with the feeder.

Water Fountain Operation

The Eversweet Solo SE Water Fountain operates continuously when powered, providing a constant supply of fresh, filtered water.

- Wireless Pump: The upgraded wireless pump 3.0 ensures stable operation without exposed wires, enhancing safety and simplifying cleaning.
- **Dry Burning Prevention:** The pump automatically stops if water levels are too low, preventing damage to the device and ensuring pet safety.
- Filter System: A foam filter at the water inlet intercepts impurities, extending pump life and ensuring clean

MAINTENANCE

Feeder Cleaning

Regularly clean the feeder components to ensure hygiene and proper function:

- Disconnect the feeder from power before cleaning.
- Remove the food hoppers and dispensing tray. Wash these parts with mild soap and water.
- Wipe the main unit with a damp cloth. Do not immerse the main unit in water.
- Ensure all parts are completely dry before reassembly and refilling with food.

Water Fountain Cleaning and Filter Replacement

Regular cleaning and filter replacement are crucial for maintaining optimal water quality:

- Disconnect the fountain from power.
- Disassemble all removable parts (water tank, filter tray, pump).
- Wash all parts (except the wireless pump) with mild soap and water.
- Clean the wireless pump by rinsing it under running water.
- Replace the filter element every 2-4 weeks, or as indicated by the app or fountain's indicator light.
- Reassemble all components and refill with fresh, clean water.

Troubleshooting

Problem	Possible Cause	Solution
Feeder not dispensing food	Food jammed; Low food level; Power issue	Check food path for blockages; Refill hoppers; Ensure power is connected and stable
App cannot connect to feeder/fountain	Wi-Fi issue; Incorrect password; Device offline	Ensure 2.4GHz Wi-Fi network is active; Re-enter Wi-Fi password; Restart device and router
Camera feed is blurry or dark	Lens dirty; Insufficient ambient light	Clean camera lens gently; Night vision should activate automatically in low light conditions
Water fountain not flowing	Low water level; Pump blockage; Power issue	Refill water tank; Clean pump and filter thoroughly; Check power connection
Fountain pump stops working	Water level too low (dry burning prevention activated)	Refill water tank. The pump will resume operation once sufficient water is detected.

SPECIFICATIONS

PETKIT YumShare Dual Hopper Automatic Pet Feeder

• Camera: 1080P HD, 140° Wide-angle, IR Night Vision

· Audio: Two-Way Audio, 20-second Voice Recording

• Connectivity: 2.4GHz Wi-Fi

• Food Capacity: Dual Hoppers (Total approx. 21 cups / 5L)

· Material: Plastic

• **Recommended Food:** Dry food, Freeze-dried food, Mixed food, Air-dried food (kibble size ≤ 12mm)

PETKIT Eversweet Solo SE Water Fountain

• Capacity: 1.85L (60oz)

• Pump: Wireless Pump 3.0

· Material: Plastic

• Care: Hand Wash Only (for removable parts)

• **Dimensions:** Approximately 6.3 x 6.3 x 6.1 inches

WARRANTY AND SUPPORT

PETKIT products come with a limited warranty. For specific warranty details, please refer to the warranty card included in your package or visit the official PETKIT website.

For technical support, troubleshooting assistance, or to purchase replacement parts, please contact PETKIT customer service through the PETKIT app or their official website.

Official Website: www.petkit.com

© 2024 PETKIT. All rights reserved.

Related Documents - YumShare Dual Hopper Automatic Pet Feeder and Eversweet Solo SE Water Fountain



PETKIT Yumshare Dual-Hopper Smart Pet Feeder User Manual



Comprehensive user manual for the PETKIT Yumshare Dual-Hopper Smart Pet Feeder with Camera, covering product features, installation, usage, app functions, cleaning, maintenance, specifications, and safety guidelines.



PETKIT Yumshare Dual-Hopper Smart Pet Feeder User Manual



User manual for the PETKIT Yumshare Dual-Hopper Smart Pet Feeder with Camera, detailing product features, installation, operation, app integration, cleaning, maintenance, and safety quidelines.

