

Jocca 2184N

JOCCA Nature Line Electric Citrus Juicer

Model: 2184N

IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using the appliance. Retain this manual for future reference.

- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Do not immerse the motor unit, cord, or plug in water or any other liquid.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Unplug the appliance from the outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer service for examination, repair, or adjustment.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Always ensure the appliance is properly assembled before operation.
- Do not use the appliance for anything other than its intended use.

PRODUCT COMPONENTS

Familiarize yourself with the parts of your JOCCA Nature Line Electric Citrus Juicer:

- Small Juicing Cone
- Large Juicing Cone
- Filter/Strainer
- Juice Jug (0.7 Liters capacity)
- Lid
- Motor Unit/Base



Image: The JOCCA Nature Line Electric Citrus Juicer showing its main parts: the base with the juice jug, two interchangeable juicing cones, and a clear lid.



Image: Assembled view of the juicer, highlighting the large juicing cone and the measurement markings on the jug.

SETUP

1. **Unpack:** Carefully remove all packaging materials and labels from the appliance.
2. **Clean Before First Use:** Wash all removable parts (cones, filter, jug, lid) in warm, soapy water. Rinse thoroughly and dry. The motor unit should be wiped with a damp cloth.
3. **Assemble:**
 - Place the juice jug onto the motor unit base.
 - Insert the filter/strainer into the jug.
 - Select the appropriate juicing cone (small for lemons/limes, large for oranges/grapefruits) and place it onto the filter.
 - Place the lid on top of the assembled juicer.
4. **Position:** Place the assembled juicer on a stable, flat, and dry surface.
5. **Connect Power:** Plug the power cord into a suitable electrical outlet (220-240V, 50/60Hz).

OPERATING INSTRUCTIONS

The JOCCA Nature Line Electric Citrus Juicer features automatic activation and bidirectional rotation for efficient juicing.

1. **Prepare Fruit:** Cut citrus fruits (oranges, lemons, grapefruits, limes) in half.
2. **Start Juicing:** Place a fruit half onto the juicing cone. Press down firmly. The motor will automatically start and the cone will rotate.
3. **Extract Juice:** Apply gentle, consistent pressure to extract the juice. The cone will rotate bidirectionally to ensure maximum juice extraction.
4. **Stop Juicing:** Release pressure from the fruit, and the motor will automatically stop.
5. **Monitor Juice Level:** The transparent jug has measurement markings up to 700ml. Do not exceed the MAX fill line.



Image: A user demonstrating the juicing process by pressing an orange half onto the cone.



Image: Detailed view of the juice jug's capacity markings.

6. **Serve:** Once juicing is complete, unplug the appliance. Remove the lid, cone, and filter. Pour the fresh juice from the jug.

MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the life of your juicer.

1. **Unplug:** Always unplug the appliance from the power outlet before cleaning.
2. **Disassemble:** Remove the lid, juicing cone, filter, and juice jug from the motor unit.
3. **Wash Removable Parts:** The cones, filter, lid, and jug are dishwasher safe. Alternatively, wash them by hand in warm, soapy water. Rinse thoroughly and dry completely before reassembly or storage.
4. **Clean Motor Unit:** Wipe the exterior of the motor unit with a soft, damp cloth. Do not immerse the motor unit in water or any other liquid. Do not place it in a dishwasher.
5. **Storage:** Store the clean and dry appliance in a cool, dry place, away from direct sunlight and moisture.

TROUBLESHOOTING

If you encounter issues with your juicer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not start.	Not plugged in. No pressure applied to the cone.	Ensure the power cord is securely plugged into a working outlet. Apply firm pressure to the juicing cone with the fruit.
Motor stops during operation.	Pressure released. Overheating.	Reapply pressure to the juicing cone. Unplug the appliance and let it cool down for at least 15 minutes before resuming use.
Low juice yield.	Insufficient pressure. Fruit not cut properly. Filter clogged.	Apply more consistent pressure. Ensure fruit halves are cut evenly. Clean the filter during juicing if necessary.
Juice leaks from the base.	Jug not properly seated. Jug overfilled.	Ensure the juice jug is correctly placed on the motor unit. Do not exceed the MAX fill line (700ml).

SPECIFICATIONS

Feature	Specification
Brand	Jocca
Model	2184N (Nature Line Electric Citrus Juicer)
Color	Black
Power	40 Watts
Voltage	220-240 Volts (AC), 50/60 Hz
Capacity	0.7 Liters (700 ml)
Product Dimensions (L x W x H)	15 x 15 x 20 cm
Item Weight	790 g
Material	Polypropylene (PP)
Special Features	Press-activated function, Bidirectional rotation, Two interchangeable cones, BPA-Free
Care Instructions	Removable parts are dishwasher safe. Motor unit is not dishwasher safe; wipe clean.

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official JOCCA website. Keep your proof of purchase for any warranty claims.

