

Unicozin UZ-TL145

Unicozin Table Lamp User Manual

Model: UZ-TL145

1. IMPORTANT SAFETY INFORMATION

Please read these instructions carefully before assembly and use. Retain this manual for future reference.

- Ensure the lamp is unplugged before cleaning or performing any maintenance.
- Do not expose the lamp to water or excessive moisture.
- This lamp is designed for indoor use only.
- The integrated LED light source is not replaceable. Do not attempt to open or modify the lamp.
- Keep out of reach of children.

2. PACKAGE CONTENTS

Verify that all components are present:

- Unicozin Table Lamp (Base with integrated LED and stem)
- Fabric Lampshade
- Securing Ring

3. SETUP INSTRUCTIONS

Follow these steps to assemble your Unicozin Table Lamp:

1. Carefully unpack all components from the packaging.
2. Locate the securing ring, which may be pre-installed on the lamp holder. Unscrew and remove this ring from the lamp holder.
3. Place the fabric lampshade onto the lamp holder, ensuring it sits flush with the base.
4. Screw the securing ring back onto the lamp holder to firmly secure the lampshade in place. Do not overtighten.
5. Plug the lamp's power cord into a standard 120V AC electrical outlet.

Before install lamp shade, please take the ring out of the lamp holder, and then screw the lamp shade with ring.



Image 3.1: Lamp shade installation. Unscrew the ring, place the shade, then re-screw the ring to secure.

4. OPERATING INSTRUCTIONS

The Unicozin Table Lamp features intuitive touch controls located on its base.



TOUCH CONTROL

Easy to use

Just tap to adjust the brightness and color



ON/OFF Switch



Short tap to change 3CCT.
Long tap to dimmable.



Short tap to change 7 colors.
Long tap to gradient mode.

Image 4.1: Touch control panel on the lamp base.

4.1 Power On/Off

- **Power Button ():** Tap this button to turn the lamp on or off.

4.2 Brightness Adjustment (Stepless Dimming)

- The lamp offers stepless dimming from 10% to 100% brightness for both CCT and RGB modes.
- **To Adjust Brightness:** Long press the active CCT or RGB button. The brightness will gradually increase or decrease. Release the button when the desired brightness level is reached.

10%-100% Stepless Dimming Brightness

Both 3 CCT and RGB can be dimmable




Image 4.2: Stepless dimming capability for various light modes.

4.3 Color Temperature (CCT) Selection

- **CCT Button:** Short tap this button to cycle through three color temperatures:
 - **3000K Warm Light:** Soft, cozy illumination.
 - **4500K Natural Light:** Balanced, neutral illumination.
 - **6500K White Light:** Bright, cool illumination.



3 Color Temperatures

Suitable for Normal Home Lighting



Image 4.3: The three available CCT modes for daily lighting.

4.4 RGB Color Changing Modes

- **RGB Button:**
 - **Short Tap:** Cycles through 7 distinct RGB colors.
 - **Long Press:** Activates a dynamic RGB gradient mode, where colors smoothly transition.



Image 4.4: RGB color changing and gradient modes for ambient lighting.

4.5 USB & Type-C Charging Ports

The lamp base includes convenient charging ports:

- **USB-A Port (5V/2A)**
- **USB Type-C Port (5V/2A)**
- These ports can charge mobile phones, tablets, and other electronic devices.
- **Note:** When charging two devices simultaneously, the output current is 1A per charging port.



Image 4.5: USB and Type-C charging ports on the lamp base.

5. MAINTENANCE

5.1 Cleaning

- Always unplug the lamp before cleaning.
- Wipe the lamp base and stem with a soft, dry cloth.
- For the fabric lampshade, use a lint roller or a soft brush to remove dust. Do not use liquid cleaners on the lampshade.

5.2 Light Source

The Unicozin Table Lamp uses an integrated 9W LED light source. This LED is designed for long-term use and **cannot be removed or replaced**. Do not attempt to disassemble the lamp to access the LED.



Image 5.1: The integrated LED light source is not user-replaceable.

6. TROUBLESHOOTING

If you encounter issues with your lamp, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Lamp does not turn on.	Not plugged in; power outlet issue; power button not pressed.	Ensure the power cord is securely plugged into a working outlet. Press the power button. Test the outlet with another device.
Brightness adjustment not working.	Button not long-pressed; lamp in fixed brightness mode.	Ensure you are long-pressing the CCT or RGB button to activate stepless dimming.
Colors not changing in RGB mode.	RGB button not tapped/long-pressed correctly.	Short tap the RGB button to cycle colors. Long press for gradient mode.
USB/Type-C charging ports not working.	Lamp not powered on; device cable issue; device not compatible.	Ensure the lamp is powered on. Try a different charging cable or device. Verify device compatibility with 5V/2A output.
Lamp flickers when charging two devices.	Overload on charging ports.	This is expected behavior as output current is 1A per port when two devices are connected. If flickering is severe, charge one device at a time.

7. PRODUCT SPECIFICATIONS

Feature	Specification
Model	UZ-TL145
Brand	Unicozin
Dimensions	14.5 inches (Height)

Feature	Specification
Light Source	Integrated 9W LED
Brightness	800 Lumens
Color Temperatures (CCT)	3000K (Warm), 4500K (Natural), 6500K (White)
RGB Modes	7 Static Colors + Dynamic Gradient Mode
Dimming	Stepless (10%-100%)
Control Method	Touch Control
Charging Ports	1x USB-A (5V/2A), 1x USB Type-C (5V/2A)
Input Voltage	100-265V AC
Material	Metal Base, Fabric Shade
Indoor/Outdoor Use	Indoor Only

8. WARRANTY AND SUPPORT

Unicozin products are manufactured with quality and performance in mind. This product is covered by a standard manufacturer's warranty against defects in materials and workmanship from the date of purchase. Please refer to your purchase documentation for specific warranty terms and duration.

For technical support, troubleshooting assistance, or warranty claims, please contact Unicozin customer service through the retailer where the product was purchased or visit the official Unicozin website for contact information.

Please have your model number (UZ-TL145) and proof of purchase ready when contacting support.