

[Manuals.plus](#) /

› [Jojoka](#) /

› Jojoka 6-Drawer Wide Dresser with LED Lights and Charging Station User Manual

Jojoka 6 Drawer Dresser with LED Lights

Jojoka 6-Drawer Wide Dresser with LED Lights and Charging Station

Model: B0CTKMDN8T

Brand: Jojoka

1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

- **Anti-Tip Device:** Always install the included anti-tip device to prevent serious injury from furniture tip-over. Securely fasten the dresser to a wall stud.
- **Assembly:** Assembly requires two adults. Do not attempt to assemble alone. Ensure all hardware is tightened securely before use.
- **Electrical Safety:** The built-in charging station contains electrical components. Do not expose to water or excessive moisture. Do not overload the outlets. Disconnect power before cleaning or if any damage occurs.
- **Weight Capacity:** Do not exceed the recommended weight capacity for drawers or the top surface. Distribute weight evenly.
- **Children:** Keep small parts and packaging materials away from children during assembly. Do not allow children to climb on or play with the dresser.

2. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- Dresser Panels (Top, Sides, Back, Bottom)
- 6 Drawer Components
- Drawer Slides and Hardware
- LED Light Strip with Controller
- Built-in Charging Station (4 AC Outlets, 2 USB Ports)
- Power Cord (6.6 feet)
- Anti-Tip Device Kit
- Assembly Hardware (screws, dowels, cam locks, etc.)
- Instruction Manual

3. ASSEMBLY INSTRUCTIONS

Follow these steps carefully for proper assembly. It is recommended to have two people for assembly.

1. **Unpack and Identify Parts:** Lay out all components on a clean, soft surface to prevent scratches. Refer to the parts list in your separate assembly guide to identify each piece.
2. **Assemble the Main Frame:** Connect the side panels to the bottom and back panels using the provided hardware. Ensure all connections are secure.
3. **Install Drawer Slides:** Attach the drawer slides to the inner sides of the dresser frame according to the markings.
4. **Assemble Drawers:** Construct each of the six drawers. Attach the drawer fronts, sides, and backs, then insert the drawer bottoms. Install the drawer pulls.
5. **Insert Drawers:** Carefully slide the assembled drawers onto the installed drawer slides.
6. **Install Charging Station:** Place the built-in charging station into its designated slot on the top surface of the dresser. Connect its power cord.
7. **Attach LED Light Strip:** Adhere the LED light strip to the designated area within the open compartments. Connect the LED controller.
8. **Secure Anti-Tip Device:** Attach the anti-tip device to the back of the dresser and then securely fasten it to a wall stud using the provided hardware. This step is crucial for safety.



Figure 3.1: Essential Anti-Fall Device, Round Metal Handle, and Smooth Slide Drawer Mechanism.

Note: For detailed step-by-step diagrams, please refer to the separate assembly instruction booklet included in your package.

4. OPERATING INSTRUCTIONS

4.1 LED Light System

The dresser features a multifunctional LED light strip with various control options.

- **Power On/Off:** Use the manual control button or the smartphone application to turn the LED lights on or off.
- **Color Selection:** Choose from over 60,000 colors via the smartphone app. Manual control offers a selection of preset colors.
- **Brightness Adjustment:** Adjust the light intensity to your preference using either the app or manual controls.
- **Modes:** Explore various lighting modes, including static colors, dynamic effects, music sync, and microphone mode (via app).

- **Timing Function:** Set schedules for the lights to turn on or off automatically using the smartphone application.



APP Control



Custom Style



Over 60,000 Colors



Mic Mode




Music Mode



Timing Function



Light Off Status



Light On Status













Figure 4.1: RGBW Adjustable Light Strips with App Control and Multiple Functions.

4.2 Built-in Charging Station

The integrated charging station provides convenient power access for your electronic devices.

- **AC Outlets:** The station includes 4 standard 120V/12A AC outlets for powering larger devices.
- **USB Ports:** Two 5V/2A USB ports are available for charging smartphones, tablets, and other USB-powered devices.
- **Power Connection:** Ensure the dresser's main power cord (6.6 feet) is securely plugged into a functional wall outlet.
- **Usage:** Simply plug your devices into the appropriate outlets or USB ports.

BUILT-IN CHARGING STATION



120V /12A
4AC Outlets



5V/2A
2 USB Ports



6.6-FEET
Power Cord

Figure 4.2: Built-in Charging Station with AC Outlets and USB Ports.

4.3 Drawer Usage

The dresser features six spacious drawers designed for organized storage.

- **Opening/Closing:** Gently pull the round metal handles to open drawers and push to close. The smooth slide mechanism ensures easy operation.
- **Storage Capacity:** Utilize the deep drawers for clothing, linens, or other personal items. The top surface and open compartments can display decorative items or frequently accessed essentials.
- **Weight Distribution:** Distribute items evenly within drawers to prevent strain on the slides and maintain stability.

6 SPACIOUS WOOD DRAWERS

Keep Your Room Tidy and Orderly



Figure 4.3: Six Spacious Wood Drawers for Storage.

5. MAINTENANCE

Proper care will extend the life and appearance of your dresser.

- **Cleaning:** Wipe the dresser surfaces with a dry, soft cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **LED Strip:** If the LED strip adhesive weakens, re-secure it with appropriate adhesive tape designed for electronics.
- **Hardware:** Periodically check all assembly hardware and tighten if necessary to maintain structural integrity.
- **Charging Station:** Keep the charging station free of dust and debris. Do not attempt to disassemble or repair the electrical components.

6. TROUBLESHOOTING

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
LED lights not turning on.	Power cord disconnected; LED strip not properly connected to controller; controller malfunction.	Ensure the dresser's main power cord is plugged in. Check the connection between the LED strip and its controller. If using the app, ensure Bluetooth is enabled and the app is paired.
Charging station not providing power.	Dresser power cord unplugged; device not properly inserted; charging station malfunction.	Verify the dresser's main power cord is securely plugged into a live outlet. Ensure devices are fully inserted into the AC outlets or USB ports. Test with a different device.
Drawers are stiff or do not slide smoothly.	Drawer slides misaligned; excessive weight; debris in slides.	Remove the drawer and inspect the slides for proper alignment. Ensure drawers are not overloaded. Clean any debris from the drawer slides.
Dresser feels unstable.	Hardware loose; anti-tip device not installed or secured.	Check and tighten all assembly hardware. Ensure the anti-tip device is correctly installed and securely fastened to a wall stud.

7. SPECIFICATIONS

Key technical details for the Jojoka 6-Drawer Wide Dresser.

Feature	Detail
Brand	Jojoka
Model Name	6 Drawer Dresser with LED Lights
Material	Wood (Premium Particle Board)
Finish Type	Lacquered
Overall Dimensions (W x D x H)	47.2" x 15.8" x 36.2"
Number of Drawers	6
Item Weight	90 Pounds
Color	Black
Charging Station	4 Standard AC Outlets, 2 USB Ports (5V/2A)
Power Cord Length	6.6 feet
LED Lights	Multi-color RGB, App/Manual Control, Timing Function
Mounting Type	Freestanding (with anti-tip device)




Figure 7.1: Product Dimensions Overview.

8. WARRANTY AND SUPPORT

For any questions, missing parts, or assistance, please contact the seller directly.

- **Returns:** This product typically includes a 30-day return policy. Refer to your purchase platform for specific details.
- **Customer Support:** For technical support or warranty claims, please reach out to the seller, Luyiwei, through your purchase order details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CTKMDN8T>

More documents and user manuals: <https://manuals.plus/>