



Manuals.plus /

› Samsung /

› Samsung HW-S700D 3.1ch Soundbar User Manual

Samsung HW-S700D

Samsung HW-S700D 3.1ch Soundbar User Manual

Model: HW-S700D | Brand: Samsung

1. INTRODUCTION

Thank you for purchasing the Samsung HW-S700D 3.1ch Soundbar. This ultra-slim soundbar is designed to deliver a powerful and immersive audio experience, featuring Wireless Dolby Atmos, Q-Symphony, SpaceFit Sound Pro, Adaptive Sound, and Game Mode Pro. This manual provides detailed instructions for setting up, operating, maintaining, and troubleshooting your new soundbar to ensure optimal performance and enjoyment.

1.1 Key Features

- **Ultra-Slim Design:** A sleek, low-profile design that blends seamlessly with your home decor.
- **Wireless Dolby Atmos:** Experience captivating, three-dimensional audio without the need for HDMI cables.
- **3.1ch Sound:** Delivers rich, clear sound for movies, music, and games.
- **Q-Symphony:** Synchronizes with compatible Samsung TVs to create a harmonious, optimized sound experience.
- **SpaceFit Sound Pro:** Automatically calibrates audio to fit your room's acoustics for an accurate and clear sound.
- **Adaptive Sound:** Intelligently optimizes audio in real-time, enhancing dialogue clarity even at low volumes.
- **Game Mode Pro:** Provides an immersive gaming experience with powerful up-firing speakers and optimized 3D sound.
- **Smart Integration:** Built-in support for voice assistants like Alexa, Chromecast, and AirPlay 2.
- **Active Voice Analyzer (AVA):** Ensures dialogue is clear by breaking down room noise.

2. WHAT'S IN THE BOX


Please check that all components are present in the packaging:



Image: The Samsung HW-S700D Soundbar, its wireless subwoofer, and the included remote control.

- Soundbar (HW-S700D)
- Wireless Subwoofer
- Remote Controller
- Battery for Remote Controller (AAA x 2)
- HDMI Cable
- Power Adapter
- Wallmount Kit

Model: HW-S700D



Dimensions:

(INCHES W x H x D):

- Soundbar: 35 x 1.4 x 1.5
- Subwoofer: 8 x 13.8 x 11.8

What's in the box:

- Soundbar
- Subwoofer
- HDMI Cable
- Wall Mount Kit
- Remote Controller with batteries



Image: A visual representation of the soundbar, subwoofer, and remote, along with a list of contents and their dimensions.

3. SETUP

3.1 Physical Placement

Place the soundbar centrally below your television. Ensure there is clear space in front of the soundbar for optimal sound projection. The wireless subwoofer can be placed anywhere in the room, ideally within 30 feet (9 meters) of the soundbar, for best bass response. Avoid placing the subwoofer directly against a wall or in a corner, as this can cause excessive bass resonance.





Image: The ultra-slim soundbar positioned neatly on a TV stand, demonstrating its discreet design.

If wall-mounting, use the included wallmount kit and follow the instructions provided with the kit. Ensure the wall can support the weight of the soundbar and that it is securely fastened.

3.2 Connections

Connect the soundbar to your television using the supplied HDMI cable. For optimal audio quality, connect the HDMI cable to the HDMI (eARC) port on your soundbar and the corresponding eARC/ARC port on your TV.

1. Connect one end of the HDMI cable to the **HDMI (eARC)** port on the back of the soundbar.
2. Connect the other end of the HDMI cable to the **HDMI (eARC/ARC)** port on your television.
3. Connect the power adapter to the **DC 19V** port on the soundbar and then plug it into a wall outlet.
4. Plug the wireless subwoofer's power cord into a wall outlet. The subwoofer will automatically pair with the soundbar.



* Images are simulated and for illustration purposes only.

Image: Detailed view of the soundbar's rear connections, highlighting the HDMI eARC and power input ports.

3.3 Initial Power On and Pairing

After connecting all cables, power on your television and then the soundbar. The soundbar should automatically detect the TV connection. If you have a compatible Samsung TV, ensure Q-Symphony is enabled in your TV's sound settings for integrated audio output.

4. OPERATING INSTRUCTIONS

4.1 Basic Controls (Remote Controller)

Use the included remote controller to manage your soundbar's functions. Insert the two AAA batteries into the remote before use.

- **Power Button:** Turns the soundbar on or off.
- **Volume (+/-):** Adjusts the master volume level.
- **Mute Button:** Mutes or unmutes the sound.
- **Source Button:** Cycles through input sources (e.g., HDMI, Bluetooth, Wi-Fi).
- **Sound Mode Button:** Selects different sound modes (e.g., Adaptive Sound, Game Mode Pro).
- **Woofers (+/-):** Adjusts the subwoofer's bass level.

4.2 Sound Modes

- **Adaptive Sound:** This mode analyzes the content in real-time and optimizes the audio for clarity, especially for dialogue. It ensures voices are heard clearly even at low volumes.
- **Game Mode Pro:** Designed for gamers, this mode enhances the soundstage with powerful up-firing speakers and acoustic beam technology, providing a more immersive 3D audio experience. The soundbar automatically activates this mode when connected to a compatible gaming console or TV's Gaming Hub.




Image: The soundbar dynamically optimizing audio for clear dialogue during TV viewing.



Dynamically optimized audio

Tired of missing dialogue? Hear voices better, even at low volume, with intelligently optimized audio. Scenes are analyzed in real time to pull out the most important audio based on the type of content.

Image: A user enjoying an enhanced gaming experience with the soundbar's Game Mode Pro.


4.3 Smart Integration

The HW-S700D Soundbar offers seamless integration with various smart services and voice assistants.

- **Built-in Alexa:** Control your soundbar and other smart home devices using voice commands.
- **Chromecast:** Stream audio content directly from your mobile devices or compatible apps.
- **AirPlay 2:** Stream audio from Apple devices (requires iOS 11.4 or later).

Smart ways to connect

Connect your devices and control everything with our soundbar that integrates your favorite voice assistants and smart services like Built-in Alexa¹, Chromecast², Airplay 2³ and more.



¹ Content Services may vary by region & are subject to change without notification. Amazon, Alexa, and all related logos are trademarks of Amazon.com, Inc. or its affiliates.
² This service is provided by Google and can be terminated at any time. Some features and functions provided by connected devices may be limited or not be supported to use. Content Services may vary by region & are subject to change without notification.
³ This Samsung Soundbar supports AirPlay2 and requires iOS 11.4 or later. Apple, and AirPlay are trademarks of Apple Inc., registered in the U.S. and other countries.

Image: Visual representation of the soundbar's compatibility with various smart home ecosystems and streaming protocols.

4.4 Q-Symphony

Q-Symphony allows your Samsung Soundbar to synchronize with compatible 2020-2024 Samsung TVs. When enabled, the soundbar and TV speakers work together to create a more expansive and immersive soundstage, optimizing all audio channels to operate as one unified system.

TV and soundbar in sync

Pair a Samsung TV with a Samsung Soundbar to unlock a new level of powerful audio. Experience content like never before only with Samsung products. With Q-Symphony, your speakers work together to optimize all the audio channels to operate as one.*



Image: A diagram demonstrating how Q-Symphony integrates the soundbar and TV speakers for a richer audio experience.

4.5 SpaceFit Sound Pro

SpaceFit Sound Pro analyzes your room's environment and automatically optimizes the audio output of the soundbar. This ensures that the sound is calibrated to your specific space, providing an accurate and clear sound profile tailored to your listening area.

4.6 Active Voice Analyzer (AVA)

The Active Voice Analyzer (AVA) feature helps ensure that dialogue and commentary are not drowned out by background noise. AVA detects and analyzes ambient room noise in real-time, then optimizes onscreen voices so they remain clear and prominent, making movies, shows, and sports more enjoyable.




Image: The soundbar's Active Voice Analyzer working to clarify dialogue over ambient room noise, such as a robot vacuum.

5. MAINTENANCE

Proper maintenance ensures the longevity and performance of your Samsung Soundbar.

- **Cleaning:** Use a soft, dry cloth to clean the exterior surfaces of the soundbar and subwoofer. Do not use

liquid cleaners, sprays, or abrasive materials, as they may damage the finish.

- **Ventilation:** Ensure that the ventilation openings on the soundbar and subwoofer are not blocked. Adequate airflow prevents overheating.
- **Storage:** If storing the soundbar for an extended period, disconnect it from the power outlet and store it in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Replacement:** Replace the remote control batteries (2 x AAA) when the remote's range decreases or it stops responding.

6. TROUBLESHOOTING

If you encounter issues with your soundbar, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No sound from soundbar.	Power not connected, incorrect input source, muted, or volume too low.	Check power connection. Select correct input source (e.g., HDMI). Unmute soundbar and increase volume.
Subwoofer not producing sound.	Subwoofer not paired or power issue.	Ensure subwoofer is powered on. If not paired, refer to the full manual for manual pairing instructions.
Remote control not working.	Batteries depleted or incorrect orientation, obstruction.	Replace batteries. Ensure line of sight to the soundbar's sensor.
Sound is distorted or unclear.	Incorrect sound mode, poor source quality, or speaker placement.	Try different sound modes (e.g., Adaptive Sound). Check audio source quality. Adjust soundbar/subwoofer placement.
Q-Symphony not working.	Incompatible TV or setting not enabled.	Ensure your Samsung TV is compatible (2020-2024 models). Enable Q-Symphony in your TV's sound settings.

If the problem persists after trying these solutions, please contact Samsung customer support for further assistance.

7. SPECIFICATIONS

Detailed technical specifications for the Samsung HW-S700D Soundbar.

Feature	Description
Model Name	E1SAMHWS700DRB
Speaker Type	Soundbar
Surround Sound Channel Configuration	3.1
Special Feature	Dolby Atmos
Color	Black
Material	Aluminum or high-strength plastic
Product Dimensions (Soundbar)	35"W x 1.5"D x 1.4"H
Item Weight	14.9 Pounds
Wireless Communication Technology	Bluetooth, Wi-Fi
Subwoofer Connectivity Technology	Wireless
Control Method	Remote
Power Source	Corded Electric
Recommended Uses For Product	For Televisions
Compatible Devices	Television, Gaming Console
Included Components	Battery for Remote Controller, HDMI Cable, Power Adapter, Remote Controller, Wallmount Kit
UPC	887276824239
Manufacturer	SAMSUNG
Date First Available	March 5, 2024

8. WARRANTY AND SUPPORT

8.1 Limited Warranty

The Samsung HW-S700D Soundbar comes with a limited warranty. Please refer to the warranty card included in your product packaging for specific terms, conditions, and duration of coverage. Keep your proof of purchase for warranty claims.

8.2 Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty service, please contact Samsung

customer support. You can find contact information and additional resources on the official Samsung website:

Samsung Support Website

When contacting support, please have your product model number (HW-S700D or E1SAMHWS700DRB) and serial number ready.