

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Playmobil](#) /

› Playmobil 71620 Vespa Garage 60s Playset Instruction Manual

Playmobil 71620

Playmobil 71620 Vespa Garage 60s Playset Instruction Manual

Model: 71620 | Brand: Playmobil

INTRODUCTION

Welcome to the instruction manual for your Playmobil 71620 Vespa Garage 60s Playset. This manual provides essential information for assembly, operation, maintenance, and safety to ensure a complete and enjoyable experience with your new playset. Please read all instructions carefully before beginning assembly or play.

SAFETY INFORMATION

WARNING: Not suitable for children under the age of 3 years. Small parts may present a choking hazard. Adult supervision is recommended during assembly and play.

PACKAGE CONTENTS

Your Playmobil 71620 Vespa Garage 60s Playset includes an 88-piece set. Please verify all components are present before beginning assembly.

- 2 Playmobil characters
- 1 Vespa scooter
- 2-part garage wall structure
- Mobile lift platform
- Various accessories (e.g., tools, oil bottles, spare parts, compressor, swivel sign, saddle variants)
- Instruction manual

ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your Playmobil Vespa Garage playset. Refer to the included visual instructions for detailed diagrams.

1. **Unpack Components:** Carefully remove all pieces from the packaging.
2. **Assemble Garage Walls:** Connect the two-part garage wall structure. Ensure all connections are secure.
3. **Position Workbench and Shelves:** Place the workbench and shelves in their designated spots within the

garage.

4. **Set Up Lift Platform:** Assemble the mobile lift platform. This platform is designed to raise and lower the Vespa for maintenance.
5. **Arrange Accessories:** Distribute the tools, oil bottles, spare parts, and compressor as desired within the garage.
6. **Prepare Vespa:** Attach the wheels to the Vespa. The wheels are designed to be removable for simulating tire changes.
7. **Install Swivel Sign:** Attach the swivel sign to indicate the garage's open or closed status.



Image Description: A fully assembled Playmobil 71620 Vespa Garage playset, featuring two characters, a red Vespa scooter on a lift, a workbench with tools, and various garage accessories. The garage walls are grey with blue accents.

OPERATING INSTRUCTIONS

This section details how to interact with the various features of your Playmobil Vespa Garage.

Using the Mobile Lift Platform

The mobile lift platform allows you to simulate vehicle maintenance. Place the Vespa onto the platform, then use the mechanism to raise or lower it.

Performing Tire Changes

The Vespa's wheels are designed to be removable. Gently detach the wheels to simulate a tire change. Reattach them by pressing firmly until they click into place.



Image Description: A Playmobil character in blue overalls is shown changing a tire on the red Vespa scooter. The wheel is detached, illustrating the removable wheel feature.

Customizing the Vespa

The playset includes different saddle variants for the Vespa. You can swap these saddles to customize the scooter's appearance or to accommodate a Playmobil character.

Swivel Sign Operation

The garage sign can be manually swiveled to display "OPEN" or "CLOSED," adding to the realistic play experience.

MAINTENANCE AND CARE

To ensure the longevity of your Playmobil playset, follow these simple care instructions:

- **Cleaning:** Parts (without stickers) can be easily cleaned under running water. Avoid using harsh chemicals, which may damage the plastic.
- **Storage:** Store the playset in a clean, dry place away from direct sunlight to prevent discoloration and material degradation.
- **Inspection:** Periodically inspect all parts for wear or damage. Replace any broken components to maintain

safety and playability.

TROUBLESHOOTING

This section addresses common issues you might encounter.

- **Missing Parts:** If you believe a part is missing, carefully re-check the packaging and all components. Refer to the package contents list.
- **Difficulty Assembling:** Ensure you are following the visual instructions provided with the set. Apply gentle, even pressure when connecting parts. Do not force components together.
- **Loose Parts (e.g., handlebars):** Some smaller parts, like the Vespa handlebars, may come off during play. Reattach them by gently pressing them back into their designated slots.

SPECIFICATIONS

- **Model Number:** 71620
- **Brand:** Playmobil
- **Product Dimensions:** 13.7 x 9.76 x 2.76 inches (approx. 34.8 x 25 x 7 cm)
- **Item Weight:** 1.19 pounds (approx. 580 g)
- **Recommended Age:** 5 years and up
- **Material:** Plastic
- **Number of Pieces:** 88
- **Release Date:** August 30, 2024

WARRANTY AND SUPPORT

Playmobil products are manufactured to high-quality standards. For specific warranty information or support regarding your Playmobil 71620 Vespa Garage 60s Playset, please visit the official Playmobil website or contact their customer service department.

Official Playmobil Website: www.playmobil.com

Customer Service: Refer to the Playmobil website for regional contact information.