

Lumisky 4X FARELY

Lumisky 4X FARELY Solar Flame Effect LED Torches User Manual

Model: 4X FARELY

1. PRODUCT OVERVIEW

The Lumisky 4X FARELY is a set of four solar-powered LED torches designed to provide a warm, flame-effect illumination for outdoor spaces. These torches are ideal for enhancing the ambiance of gardens, pathways, and terraces. They operate using solar energy, offering an eco-friendly and convenient lighting solution.

- **Flame Effect LED:** Features 12 warm white LEDs per torch, creating a realistic flickering flame effect.
- **Solar Powered:** Equipped with solar panels for automatic charging during the day.
- **Long Autonomy:** Provides up to 16 hours of illumination after a full charge.
- **Automatic Operation:** Includes a dusk detector to activate automatically at nightfall.
- **Durable Design:** IP65 splash-proof and UV-resistant, suitable for outdoor use.
- **Easy Installation:** Designed to be planted directly into the ground.



Figure 1: Lumisky 4X FARELY solar torches providing ambient lighting.

2. SETUP INSTRUCTIONS

Follow these steps to assemble and install your Lumisky 4X FARELY solar torches:

1. **Unpack Components:** Carefully remove all components from the packaging. Ensure you have the torch heads (with solar panels), extension poles, and ground stakes.
2. **Assemble the Torch:**
 - Connect the extension pole to the bottom of the torch head.
 - Attach the ground stake to the bottom of the extension pole. Ensure all connections are secure.
3. **Select Location:** Choose an outdoor location that receives direct sunlight for at least 6-8 hours daily. This ensures optimal charging and maximum illumination time. Avoid shaded areas or locations near other strong light sources,

as this may interfere with the dusk sensor.

4. **Install in Ground:** Gently push the assembled torch into soft ground, such as a garden bed or lawn. Do not force the torch into hard ground, as this may damage the stake or internal components. If the ground is hard, pre-dig a small hole.



Figure 2: Torches installed in a garden setting.

3. OPERATING INSTRUCTIONS

The Lumisky 4X FARELY solar torches are designed for simple, automatic operation:

1. **Initial Charge:** Before first use, allow the torches to charge in direct sunlight for a full day (approximately 6-8 hours). This ensures the internal battery is adequately charged.
2. **Automatic Activation:** The torches are equipped with a light sensor. They will automatically turn on at dusk when

ambient light levels are low and turn off at dawn when light levels increase.

3. **Illumination Duration:** A full charge provides up to 16 hours of continuous flame effect illumination. Performance may vary based on sunlight exposure and weather conditions.

4. MAINTENANCE

To ensure optimal performance and longevity of your solar torches, follow these maintenance guidelines:

- **Clean Solar Panels:** Periodically wipe the solar panels with a soft, damp cloth to remove dust, dirt, and debris. A clean panel ensures efficient charging.
- **Inspect for Damage:** Regularly check the torches for any signs of physical damage, especially after severe weather.
- **Clear Obstructions:** Ensure no foliage or other objects are blocking the solar panel's exposure to sunlight.

5. TROUBLESHOOTING

If your solar torches are not functioning as expected, consider the following:

Problem	Possible Cause	Solution
Torch does not light up at night.	◦ Insufficient sunlight exposure during the day. ◦ Solar panel is dirty or obstructed. ◦ Torch is placed near another light source (e.g., street light), causing the sensor to detect light. ◦ Battery is depleted or faulty.	◦ Relocate the torch to an area with maximum direct sunlight. ◦ Clean the solar panel. ◦ Move the torch away from other light sources. ◦ Allow several days of full charge. If the problem persists, the battery may need replacement (if accessible) or the unit may be faulty.
Short illumination duration.	◦ Inadequate charging due to cloudy weather or insufficient sunlight. ◦ Aging battery.	◦ Ensure the torch receives full, direct sunlight for 6-8 hours. ◦ Consider replacing the battery if it's accessible and the torch is old.

6. SPECIFICATIONS

Feature	Detail
Model Number	4X FARELY

Feature	Detail
Brand	Lumisky
Light Source	12 Warm White LEDs (per unit)
Light Output	20 lumens (per unit)
Power Source	Solar Powered
Charging Time	6-8 hours (direct sunlight)
Autonomy	Up to 16 hours
Material	Plastic
Color	Black (torch body), Warm White (light)
Dimensions (L x W x H)	7.5L x 7.5W x 64.5H cm (per unit)
Water Resistance	IP65 (Splash-proof)
Special Features	UV Resistant, Dusk Detector
Number of Items	4 torches




Figure 3: Energy efficiency label for FARELY torches. For more details, visit eprel.ec.europa.eu/qr/2614881.

7. WARRANTY AND SUPPORT

Specific warranty details for the Lumisky 4X FARELY solar torches are typically provided at the point of purchase or within the product packaging. Please refer to your purchase documentation for information regarding warranty coverage and duration.

For technical support or further inquiries, please contact Lumisky customer service through their official website or the retailer from whom the product was purchased.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question