

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [KINGTORO](#) /
- › [KINGTORO 44-inch Chandelier Ceiling Fan User Manual](#)

KINGTORO F491BK-12

KINGTORO 44-inch Chandelier Ceiling Fan User Manual

Model: F491BK-12 | Brand: KINGTORO

1. INTRODUCTION AND OVERVIEW

Thank you for choosing the KINGTORO 44-inch Black Chandelier Ceiling Fan. This innovative 2-in-1 design combines the elegance of a chandelier with the functionality of a ceiling fan, featuring 12 E26 base lights, 5 reversible blades, and 6 adjustable speeds. Designed for quiet operation and energy efficiency, this fandelier is perfect for living rooms, kitchens, dining rooms, and bedrooms, providing both illumination and comfortable airflow year-round.



Figure 1.1: The KINGTORO 44-inch Chandelier Ceiling Fan.

44 IN

CLASSIC WAGON WHEEL CHANDELIER WITH FAN

Innovative **2-in-1** Design

- Remote Control
- 1/2/4H Timing
- Ultra-Quiet
- Reverse Function
- 6 Wind Speeds
- Energy Saving

Figure 1.2: Overview of key features including remote control, 6 wind speeds, timer settings, reversal function, low energy consumption, and powerful motor.

2. SAFETY INFORMATION

Please read all safety instructions carefully before installation and use. Failure to follow these instructions may result in electric shock, fire, or personal injury.

- **Electrical Safety:** Ensure the power supply is disconnected at the circuit breaker before installation or maintenance. This fan operates on 120 Volts (AC).
- **Installation:** Installation should be performed by a qualified electrician. Ensure the mounting structure can support the weight of the fan (approximately 18.21 pounds).
- **Bulbs:** Use only E26 medium base bulbs. Do not exceed the maximum wattage specified for the light sockets.
- **Clearance:** Maintain adequate clearance between the fan blades and any obstacles.
- **Water Resistance:** This product is not water resistant. Do not install in damp or wet locations.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged before beginning installation. If any parts are missing or damaged, contact KINGTORO customer support.

- Chandelier Fan Body (with integrated motor)
- Fan Blades (5x)
- Remote Control
- Downrods (various lengths for adjustable height)
- Mounting Bracket and Hardware
- Wire Nuts and Electrical Connectors
- Instruction Manual

4. SETUP AND INSTALLATION

Assembly is required for this product. Follow these general steps for installation. Refer to the detailed diagrams in the included paper manual for specific wiring and mounting instructions.

1. **Prepare for Installation:** Turn off power at the main circuit breaker. Clear the installation area.
2. **Mounting Bracket Installation:** Secure the mounting bracket to the ceiling junction box. Ensure it is firmly attached and can support the fan's weight.
3. **Assemble Downrod:** Attach the chosen downrod (19.5 inch or 31.5 inch total length options available) to the fan motor assembly.
4. **Wiring:** Connect the fan's electrical wires to the household wiring according to local electrical codes. Ensure all connections are secure.
5. **Hang Fan:** Carefully lift and hang the fan assembly onto the mounting bracket.
6. **Attach Blades:** Securely attach the 5 fan blades to the motor housing.
7. **Install Light Bulbs:** Screw 12 E26 medium base bulbs (not included) into the light sockets.
8. **Final Checks:** Double-check all connections and ensure the fan is securely mounted. Restore power at the circuit breaker.




Figure 4.1: Component details including ABS blades, metal texture, and downrod options for installation.

SIMPLE REMOTE CONTROL

You can easily use remote control lighting, wind speed adjustment, timing function, easy to use.



Dimension:



44 inch Large Fandelier ceiling fan
Lower Sound Level Better Efficiency More Powerful Wind

Reversible	Blades	Fan Speeds
Yes	5 Blades	6 Speeds

Figure 4.2: Product dimensions and remote control overview for installation planning.

5. OPERATING INSTRUCTIONS

Your KINGTORO ceiling fan is controlled by the included remote. Ensure batteries are installed correctly in the

remote control.

Remote Control Functions:

- **Light On/Off:** Press the 'LIGHT ON/OFF' button to toggle the lights.
- **Fan On/Off:** Press the 'ALL OFF' button to turn off both fan and lights.
- **Fan Speed:** Buttons '1' through '6' adjust the fan speed from lowest (1) to highest (6).
- **Timer Setting:** Buttons '1H', '2H', '4H' set the fan to automatically turn off after 1, 2, or 4 hours, respectively.
- **Reversal Function (Summer/Winter Mode):** The 'R' button controls the blade rotation direction.
 - **Summer Mode (Clockwise Rotation):** Creates a downward airflow, providing a cooling effect.
 - **Winter Mode (Counter-Clockwise Rotation):** Creates an upward airflow, circulating warm air trapped near the ceiling to help balance room temperature.




Figure 5.1: Remote control features for fan and light operation.



Figure 5.2: Understanding Summer and Winter dual-use modes for optimal air circulation.



Figure 5.3: The 6-speed adjustable wind settings and 1/2/4 hour timing options.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your ceiling fan.

- **Cleaning:** To clean the fan, wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents as they may damage the finish. Ensure power is off before cleaning.
- **Bulb Replacement:** Always turn off power before replacing bulbs. Allow bulbs to cool before touching. Replace with E26 medium base bulbs.
- **Blade Care:** Periodically check the blade screws for tightness. Loose blades can cause wobbling and noise.
- **Motor:** The DC pure copper inverter motor is designed for long-term, quiet operation and requires no lubrication.

7. TROUBLESHOOTING

If you encounter issues with your fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Remote control battery low/dead.	Check circuit breaker; Verify all wire connections are secure; Replace remote control batteries.
Lights do not work	Bulbs are loose or burnt out; Wiring issue; Light switch on remote is off.	Tighten or replace bulbs; Check light kit wiring; Press the 'LIGHT ON/OFF' button on the remote.
Fan wobbles	Loose blade screws; Unbalanced blades; Loose mounting bracket.	Tighten all blade screws; Use a balancing kit (not included) if necessary; Ensure mounting bracket is securely fastened.
Excessive noise	Loose screws; Motor housing rubbing; Incorrect installation.	Check and tighten all screws; Ensure no parts are touching the ceiling or other components; Re-check installation steps.
Remote control not responding	Low/dead batteries; Remote out of range; Interference.	Replace batteries; Ensure you are within effective range; Minimize other electronic device interference.

If the problem persists after attempting these solutions, please contact KINGTORO customer support.

8. SPECIFICATIONS

Brand	KINGTORO
Model Number	F491BK-12
Product Dimensions	43 x 43 x 31 inches (Diameter x Diameter x Height, with longest downrod)
Item Weight	18.21 pounds
Color	Black
Installation Type	Flush Mount
Control Method	Remote Control
Light Source Type	LED (Bulbs not included)
Bulb Base	E26 Medium
Number of Light Sources	12
Voltage	120 Volts (AC)
Finish Type	Painted
Shade Material	Glass




Number of Blades	5
Fan Speeds	6
Reversible Blades	Yes
Assembly Required	Yes


9. WARRANTY AND SUPPORT

For warranty information, technical support, or any inquiries regarding your KINGTORO 44-inch Chandelier Ceiling Fan, please contact KINGTORO customer service directly. Refer to the product packaging or the official KINGTORO website for contact details.

© 2024 KINGTORO. All rights reserved.


Related Documents - F491BK-12

	<p>Modern Black Chandelier Installation Guide - LED 12-Light Linear Fixture</p> <p>Detailed installation and assembly instructions for a Modern Black Chandelier, featuring an LED 12-Light Linear Dining Room Fixture. Includes a parts list and sequence diagram.</p>
<p>INSTALLATION MANUAL CHANDELIER</p> 	<p>Chandelier Installation Manual</p> <p>Comprehensive installation manual for a chandelier, covering safety rules, preparation, parts list, step-by-step assembly instructions, wiring, bulb installation, troubleshooting, and care.</p>
	<p>Emmalynn 12-Light Dimmable Wagon Wheel Chandelier Assembly Instructions</p> <p>Detailed assembly instructions for the Emmalynn 12-Light Dimmable Wagon Wheel Chandelier, covering installation, wiring, and placement guidelines.</p>
<p>USE AND CARE MANUAL 12 LIGHT PENDANT MODEL NUMBER: 21515</p> 	<p>Bay Isle Home 12-Light Pendant Use and Care Manual (Model 21515)</p> <p>This manual provides essential safety information, installation instructions, care guidelines, and troubleshooting tips for the Bay Isle Home 12-Light Pendant, Model 21515.</p>



[12-Light Frosted Glass Sputnik Chandelier Installation Guide](#)

Detailed installation instructions, product features, and assembly guide for the 12-Light Frosted Glass Sputnik Chandelier, including wiring and component descriptions.



[Crystorama 3812-AG Zodiac Chandelier Assembly Instructions and Specifications](#)

Detailed assembly instructions, parts list, dimensions, and safety warnings for the Crystorama 3812-AG Zodiac 12-light chandelier.