

[Manuals.plus](#) /

> [Aysiofdy](#) /

> Aysiofdy RV Stairs 6 Step Ladder with Handrail Instruction Manual

## Aysiofdy step

# Aysiofdy RV Stairs 6 Step Ladder with Handrail Instruction Manual

MODEL: STEP (6 HANDRAILS STYLE)

Brand: Aysiofdy

## 1. INTRODUCTION

---

This manual provides essential information for the safe and effective assembly, operation, and maintenance of your Aysiofdy 6-Step RV Ladder with Handrails. Please read all instructions carefully before use and retain this manual for future reference.

### Safety Information

- Always ensure all components are securely fastened before use.
- Do not exceed the maximum load capacity of 660 pounds.
- Ensure the steps are placed on a stable, level surface to prevent tipping.
- Use handrails for added stability, especially for children and the elderly.
- Regularly inspect the steps for any signs of wear or damage. Do not use if damaged.

## 2. SETUP AND ASSEMBLY

---

The Aysiofdy 6-Step RV Ladder is designed for straightforward assembly. All necessary tools (wrenches and screws) are included in the package.

### Components Included

- Step platforms (6 units)
- Side frames (2 units)
- Handrails (2 units)

- Assembly hardware (screws, nuts, washers)
- Wrenches

## Assembly Instructions

1. Unpack all components and verify against the components list.
2. Attach the step platforms to the side frames using the provided hardware. Ensure the anti-slip surface of each step is facing upwards. The triangular bar structure should be positioned for optimal stability.
3. Securely tighten all screws. Proper tightening is crucial for the ladder's load-bearing capacity and stability.
4. Install the handrails. The handrails can be installed on either the left or right side of the steps, depending on your preference and the entry point. Ensure they are firmly attached.



Figure 2.1: Handrail installation can be customized to either side.

Video 2.1: Demonstration of the RV stairs in use, highlighting stability and ease of access. This video shows the product being used to access a truck bed, demonstrating its robust construction and the benefit of the handrails for safe ascent and descent.

### 3. OPERATION

The Aysiofdy 6-Step RV Ladder is designed for safe and convenient access to elevated entry points.

#### Placement

Position the steps directly in front of the entry point (e.g., RV door, hot tub edge, mobile home entrance). Ensure the base of the steps is on a firm, level surface to prevent wobbling. The steps are suitable for various applications including RVs, campervans, travel trailers, hot tubs, above-ground pools, and porch access.



Figure 3.1: Examples of wide application for the Aysiofdy 6-Step RV Ladder.

#### Using the Steps

- Always use the handrails when ascending or descending the steps for enhanced safety and balance.
- The steps feature an anti-slip iron plate surface to reduce the risk of falls, even in wet conditions.
- Step onto the center of each step for maximum stability.

Video 3.1: A person demonstrating walking up and down the 6-step RV ladder, showcasing its stability and the utility of the handrails. This video illustrates the practical use of the steps for safe entry and exit.

## 4. MAINTENANCE

---

Proper maintenance ensures the longevity and safety of your RV steps.

### Cleaning

- Wipe down the metal surfaces with a damp cloth and mild detergent as needed.
- Avoid abrasive cleaners or harsh chemicals that could damage the electrostatic spray coating.
- Ensure the anti-slip surfaces are free from debris, mud, or ice before use.

### Inspection

- Periodically check all screws and bolts for tightness. Retighten if necessary.
- Inspect the metal frame for any signs of rust, cracks, or structural damage.
- Examine the handrails for secure attachment and any bending or damage.
- If any significant damage is found, discontinue use and contact customer support.

### Storage

The steps feature a detachable design, allowing for easy disassembly and compact storage when not in use. Store in a dry place to prevent corrosion.

## 5. TROUBLESHOOTING

---

This section addresses common issues you might encounter.

Problem	Possible Cause	Solution
Steps feel wobbly or unstable.	Loose fasteners; uneven ground.	Tighten all screws and bolts. Ensure steps are on a flat, stable surface.
Handrails are not secure.	Handrail attachment screws are loose.	Ensure handrail screws are fully tightened.
Difficulty assembling.	Incorrect component orientation; fasteners not aligned.	Refer to the assembly instructions and diagrams. Ensure parts are oriented correctly before tightening.

## 6. SPECIFICATIONS

---

Key technical details for the Aysiofyd 6-Step RV Ladder.

# UPGRADED PRODUCT SIZE

TOTAL HEIGHT: 190CM/74.8"  
 TOTAL WIDTH: 155.8CM/61.33"  
 STEP LENGTH: 66.5CM/26.18"  
 6 STEP HEIGHT: 101.8CM/40.07"




Figure 6.1: Product dimensions and load capacity.

Feature	Detail
Material	Metal
Color	Black
Special Feature	Anti-Slip
Load Capacity	660 Pounds
Number of Steps	6
Maximum Height	42 Inches (106.68 cm)
Product Dimensions	43.1 x 27 x 74.8 inches (109.47 x 68.58 x 189.99 cm)

Feature	Detail
Step Thickness	2mm (anti-slip iron plate)

## 7. WARRANTY AND SUPPORT

---

For any questions, concerns, or warranty claims regarding your Aysiofdy RV Stairs, please contact our customer support team.

### Customer Support

Please refer to your purchase documentation or the retailer's website for specific contact information. When contacting support, please have your product model number (Step) and purchase date available.

