

[Manuals.plus](#) /

› [Bellemave](#) /

› Bellemave Twin Over Twin Bunk Bed with Desk, Storage, Wardrobe - Instruction Manual

Bellemave bed-frames

Bellemave Twin Over Twin Bunk Bed with Desk, Storage, Wardrobe - Instruction Manual

Model: bed-frames

[Setup](#)

[Operating Instructions](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

1. SETUP INSTRUCTIONS

This section provides guidance for the initial assembly and setup of your Bellemave Twin Over Twin Bunk Bed. Please ensure all components are present before beginning assembly.

1.1 Unpacking and Component Check

The bunk bed is shipped in **3 separate packages**, which may arrive at different times. Carefully unpack all boxes and verify that all parts listed in the included assembly guide are present and undamaged. Keep all packaging materials until assembly is complete.

1.2 Assembly Recommendations

- **Partial Assembly:** This product requires partial assembly.
- **Suggested Number of People:** Two individuals are recommended for assembly to ensure safety and ease.
- **Tools:** All necessary tools are included with the product.
- **Avoid Power Tools:** Do not use power tools during assembly. Manual tools are sufficient and help prevent overtightening or damage to components.
- **Follow Instructions:** Refer to the detailed assembly instruction guide provided in the packaging for step-by-step instructions.



Image 1.2.1: Overall view of the assembled Bellemave Twin Over Twin Bunk Bed, showcasing the loft bed, lower bed, desk, and wardrobe components.



Image 1.2.2: The bunk bed with the stand-alone lower bed positioned in front, demonstrating its flexible placement.

2. OPERATING INSTRUCTIONS

This section details the functional aspects and usage guidelines for your Bellemave Bunk Bed.

2.1 Bunk Bed Features

- **Loft Bed:** The upper bunk provides a sleeping area. It is equipped with comprehensive guardrails for safety.
- **Stand-Alone Lower Bed:** The twin-size lower bed is designed to be separate and can be placed anywhere in the room, offering flexibility in room arrangement.
- **Integrated Desk:** A functional desk area is built into the structure, suitable for study or work.
- **Storage Shelves:** Multiple shelves are available for storing books, displaying decorations, or organizing personal items.
- **Wardrobe:** A wardrobe compartment with a hanging pole provides space for clothes storage.



Image 2.1.1: Close-up view of the integrated desk and shelving units, highlighting the workspace and storage options.



Image 2.1.2: Interior view of the wardrobe compartment, showing the hanging pole for clothing.



Image 2.1.3: The desk area with drawers pulled out, illustrating additional storage for small items.

2.2 Safety Guidelines

- **Weight Capacity:** The upper bed has a weight capacity of 400 LBS. The lower bed also has a weight capacity of 400 LBS. Do not exceed these limits.
- **Mattress Thickness:** A mattress thickness of 6 inches is recommended for both the upper and lower beds.
- **Guardrails:** Always ensure guardrails are securely in place on the upper bunk to prevent falls.
- **Ladder Use:** Use the ladder safely when accessing the upper bunk. Ensure it is stable before climbing.

3. MAINTENANCE

Proper maintenance ensures the longevity and safety of your bunk bed.

3.1 Cleaning

- **Surface Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.

- **Spills:** Clean spills immediately to prevent staining or damage to the wood.

3.2 Structural Integrity

- **Regular Inspection:** Periodically check all bolts, screws, and connections to ensure they are tight. Retighten as necessary to maintain stability and prevent wobbling.
- **Material Care:** The bed is constructed from Plywood, MDF, and Pinewood. Protect the wood from excessive moisture and extreme temperature changes.

4. TROUBLESHOOTING

This section addresses common issues you might encounter with your bunk bed.

4.1 Common Issues and Solutions

- **Wobbling Bed:** If the bed feels unstable or wobbles, check all assembly bolts and screws. Retighten any loose connections. Ensure the bed is placed on a level surface.
- **Missing Parts:** If you find any parts missing upon unpacking, refer to the warranty and support section to contact customer service for assistance.
- **Difficulty Assembling:** Review the assembly instruction guide carefully. Ensure all pieces are oriented correctly. Do not force parts together. If issues persist, contact support.
- **Squeaking Noises:** Squeaking can often be resolved by tightening all bolts. Applying a small amount of lubricant (e.g., paraffin wax) to metal-on-metal or wood-on-wood contact points can also help.

5. SPECIFICATIONS

Detailed product specifications for the Bellemave Twin Over Twin Bunk Bed.

Feature	Detail
Product Type	Loft Bed
Size	Twin (Upper and Lower)
Color	White
Overall Product Dimensions	87.6"L x 78.7"W x 65"H
Product Material	Plywood + MDF + Pinewood
Overall Product Weight	228.3 LBS
Weight Capacity (Upper Bed)	400 LBS
Weight Capacity (Lower Bed)	400 LBS
Recommended Mattress Thickness	6 inches
Number of Slats (Loft Bed)	14
Number of Slats (Lower Bed)	10
Level of Assembly	Partial Assembly
Box Spring Required	No

customer service. We are committed to assisting you promptly.

If you encounter any problems, please do not hesitate to reach out. We will help you to solve the problem as soon as possible.

© 2023 Bellemave. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CTLWL27Q>

More documents and user manuals: <https://manuals.plus/>