

[Manuals.plus](#) /

> [IBOWZ](#) /

> IBOWZ Modern Salon Chair Instruction Manual (Model a39271af-68d1-4796-a5f6-adceb21cad1a)

IBOWZ a39271af-68d1-4796-a5f6-adceb21cad1a

IBOWZ Modern Salon Chair Instruction Manual

Model: a39271af-68d1-4796-a5f6-adceb21cad1a

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your IBOWZ Modern Salon Chair. Please read this manual thoroughly before use to ensure proper function and longevity of your product.

PRODUCT OVERVIEW

The IBOWZ Modern Salon Chair is designed for professional use in salons, barber shops, beauty studios, and home dressing rooms. It features a hydraulic pump for adjustable height, a 360-degree swivel mechanism, and a sturdy galvanized steel frame. The chair is upholstered with high-quality PVC leather and filled with high-density sponge for comfort.




Figure 1: Front view of the IBOWZ Modern Salon Chair in pink. This image shows the overall design, including the square base and T-shaped footrest.

SAFETY INSTRUCTIONS

- Ensure all components are securely fastened before use.
- Do not exceed the maximum weight capacity of 300 pounds (approximately 136 kg).
- Keep hands and feet clear of moving parts during height adjustment.
- Avoid using abrasive cleaners on the PVC leather upholstery.
- Place the chair on a stable, level surface.

SETUP AND ASSEMBLY

The IBOWZ Salon Chair is designed for easy assembly. All necessary accessories and detailed installation steps are included in the package. Please follow the instructions provided in the included user manual for a smooth setup process.

1. Unpack all components and verify against the parts list in the included manual.
2. Assemble the base and hydraulic pump according to the diagram.
3. Attach the seat and backrest assembly to the hydraulic column.
4. Secure all bolts and connections firmly.
5. Test the hydraulic lift and swivel functions before initial use.



Figure 2: Close-up view highlighting the backrest and armrest design, showing the tufted details and decorative buttons. This image illustrates the "Exquisite design with exquisite workmanship" mentioned in the product features.

OPERATING INSTRUCTIONS

Adjusting Height

The chair is equipped with a convenient hydraulic pump that allows you to adjust the seat height. To raise the chair, repeatedly press the foot pedal downwards. To lower the chair, lift the foot pedal upwards while applying slight downward pressure on the seat. The seat height can be adjusted within a 6-inch range.

Swivel Mechanism

The chair can rotate 360 degrees. To lock the swivel function, lift the foot pedal upwards. To unlock and allow rotation, push the foot pedal downwards.

Footrest Usage

The integrated T-shaped footrest provides a comfortable resting position for clients' feet.

WEIGHT: 20KG

SIZE: 90X65X93CM



Figure 3: Side view of the IBOWZ Salon Chair, illustrating its approximate dimensions (90x65x93cm) and weight (20kg). This provides a clear perspective of the chair's profile and scale.

MAINTENANCE AND CARE

Cleaning the Upholstery

The chair's PVC leather upholstery is waterproof and easy to clean. Wipe spills immediately with a soft, damp cloth. For general cleaning, use a mild soap solution and a soft cloth, then wipe dry. Avoid harsh chemicals, abrasive cleaners, or solvents, as these can damage the material.

Frame Care

The galvanized steel frame can be wiped clean with a damp cloth. Ensure the frame remains dry to prevent rust or corrosion.

Hydraulic System

Periodically check the hydraulic pump for smooth operation. If any issues arise, consult the troubleshooting section or contact customer support.



Figure 4: Side profile of the IBOWZ Salon Chair, showcasing the hydraulic column and the extended T-shaped footrest. This view emphasizes the chair's sturdy construction and functional design.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Chair does not raise/lower	Hydraulic pump issue or pedal not engaged correctly.	Ensure the pedal is fully engaged. Check for obstructions. If problem persists, contact support.
Chair wobbles	Loose connections or uneven floor.	Check and tighten all assembly bolts. Ensure the chair is on a flat, stable surface.
Swivel function is stiff	Lack of lubrication or debris in the mechanism.	Clean around the swivel mechanism. A small amount of silicone lubricant may be applied if necessary (avoiding upholstery).



Figure 5: Close-up image demonstrating the "Rebound Sponge" material used in the chair's cushioning, with a hand pressing into it. This highlights the comfortable seating experience.

SPECIFICATIONS

Feature	Detail
Brand	IBOWZ
Model Number	a39271af-68d1-4796-a5f6-adceb21cad1a
Color	Pink
Material	Alloy Steel (Frame), PVC Leather (Upholstery), High-Density Sponge (Fill)
Maximum Weight Recommendation	300 Pounds (approx. 136 kg)
Item Weight	44 pounds (approx. 20 kg)
Adjustable Height Range	6 inches (via hydraulic pump)
Swivel	360-degree rotation with lock function
Dimensions (approx.)	90cm (Height) x 65cm (Width) x 93cm (Depth)
Recommended Uses	Hair salons, tattoo parlors, beauty studios, home dressing rooms

WARRANTY INFORMATION

This product comes with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms, conditions, and duration. Keep your proof of purchase for warranty claims.

CUSTOMER SUPPORT

If you encounter any problems with your IBOWZ Salon Chair or require assistance with assembly or operation, please do not hesitate to contact our customer support team. Contact information can be found on the packaging or the official IBOWZ website.

