

[manuals.plus](#) /

› [SIAGO](#) /

› [SIAGO Electric Standing Desk Adjustable User Manual](#)

SIAGO Electric Standing Desk (48 x 24 Inch Black)

SIAGO Electric Standing Desk Adjustable User Manual

Model: 48 x 24 Inch Black Electric Standing Desk

1. INTRODUCTION

Thank you for choosing the SIAGO Electric Standing Desk. This manual provides essential information for the safe assembly, operation, and maintenance of your new adjustable height desk. Please read this manual thoroughly before assembly and retain it for future reference.



Figure 1.1: The SIAGO Electric Standing Desk, 48 x 24 Inch Black model.

2. IMPORTANT SAFETY INFORMATION

To ensure safe operation and prevent damage, please adhere to the following safety guidelines:

- The maximum weight capacity for this desk is **200 pounds (90.7 kg)**. Do not exceed this limit.
- Assembly requires caution. It is recommended to assemble the desk with the assistance of another person.
- The desk features an electric lifting mechanism. Handle with care and ensure no obstructions are present during height adjustments.
- Always ensure the desk is stable and secure before use.
- Exercise caution when adjusting the height to prevent injury to yourself or others, and to avoid damage to objects placed on or near the desk.

- Keep children and pets away from the desk during operation. The control panel includes a child lock feature for added safety.
- Do not sit or stand on the desk surface.
- Only use the provided power adapter and components.
- Disconnect power before cleaning or performing any maintenance.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Desktop (48 x 24 Inch, Black)
- Desk Legs (Alloy Steel)
- Motor and Lifting Mechanism
- Control Panel with LED Display
- Cable Management Tray
- Headphone/Bag Hooks (2)
- Assembly Hardware (screws, bolts, tools if included)
- Power Adapter and Cable
- User Manual (this document)

4. SETUP AND ASSEMBLY

The SIAGO Electric Standing Desk is designed for quick and straightforward assembly, typically completed within 30 minutes. All holes are pre-drilled, and accessories are clearly labeled.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface. Check against the package contents list.
2. **Attach Legs to Desktop:** Position the desktop upside down. Align the desk legs with the pre-drilled holes on the underside of the desktop. Secure them using the provided screws. Ensure the connection area is firm for stability.
3. **Install Motor and Control Panel:** Follow the specific instructions in the included assembly guide to attach the motor and the control panel to the desk frame. Ensure all cables are securely connected.
4. **Install Cable Management and Hooks:** Attach the cable management tray and the headphone/bag hooks to the designated areas on the underside of the desk. These help maintain an organized workspace.
5. **Connect Power:** Once fully assembled, connect the power adapter to the desk and then to a power outlet.
6. **Initial Setup:** Before first use, perform an initial calibration as per the detailed assembly manual to ensure proper height adjustment functionality.

30 MINUTES QUICK INSTALLATION

All holes are pre-drilled and all accessories are pre-labelled clearly



- 1 Screws insert easily by hand
- 2 Highly convenient for re-assembly

Figure 4.1: Illustration of the quick 30-minute installation process.




Figure 4.2: Details of the desk's sturdy T-shaped legs, integrated hooks, and cable management system.

5. OPERATING INSTRUCTIONS

Your SIAGO Electric Standing Desk features an intuitive control panel for effortless height adjustments and memory presets.

5.1 Control Panel Functions



Figure 5.1: The Smart Multifunction Keypad.

- **Up/Down Buttons (+/-):** Press and hold to smoothly raise or lower the desk to your desired height. The desk operates quietly (under 45 dB).
- **LED Display:** Shows the current height of the desk in inches.
- **Memory Presets (1, 2, 3):**
 - To save a height: Adjust the desk to the desired height, then press the 'M' button followed by the desired preset number (1, 2, or 3). The display will confirm the save.

- To recall a height: Simply press the corresponding preset number (1, 2, or 3). The desk will automatically move to the saved position.
- **Child Lock (M & +/-):** To activate the child lock, press and hold the 'M' button and the '+' button simultaneously for a few seconds until the display indicates the lock is active. To deactivate, repeat the process. This prevents accidental adjustments.

5.2 Height Adjustment Range

The desk offers an adjustable height range from **27.95 inches (71 cm)** to **45.67 inches (116 cm)**, allowing for comfortable sitting and standing positions.

ERGONOMIC STANDING DESK



Figure 5.2: Ergonomic height adjustment for sitting and standing.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your SIAGO Electric Standing Desk.

- **Cleaning:** Wipe the desktop and frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish. Ensure the desk is unplugged before cleaning.
- **Cable Management:** Periodically check and organize cables using the integrated cable management tray to prevent tangles and damage.
- **Fastener Check:** Every few months, inspect all screws and bolts to ensure they are tight. Re-tighten if necessary to maintain stability.
- **Motor Inspection:** Listen for any unusual noises during operation. If you notice any issues, discontinue use and contact customer support.

7. TROUBLESHOOTING

If you encounter any issues with your SIAGO Electric Standing Desk, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Desk does not move.	Power cable disconnected; Child lock activated; Overload.	Check power connection; Deactivate child lock (M + '+'); Reduce weight on desk (max 200 lbs).
Desk moves unevenly or makes unusual noise.	Loose connections; Obstruction; Motor issue.	Check all assembly connections; Remove any obstructions; Contact customer support if issue persists.
Height presets not working.	Presets not saved correctly.	Re-save your desired height presets (adjust to height, press 'M', then 1/2/3).
Desk stops mid-adjustment.	Overload protection activated; Thermal protection activated.	Reduce weight; Allow motor to cool down for 20 minutes before resuming operation.

If the problem persists after attempting these solutions, please contact SIAGO customer support for further assistance.

8. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	SIAGO
Model Name	Electric Standing Desk
Product Dimensions (D x W x H)	24"D x 48"W x 46"H (Max Height)
Color	Black
Minimum Height	27.95 Inches
Maximum Height	45.67 Inches
Maximum Weight Recommendation	200 Pounds (90.7 kg)
Base Material	Alloy Steel
Top Material Type	Wood (Eco-friendly P2-Grade)

Feature	Detail
Lifting Mechanism	Electric
Noise Level	Under 45 dB
Memory Presets	3
Assembly Required	Yes (Recommended 2 people)
Included Components	Cable Management Tray, Integrated Hooks
UPC	768523980512



Figure 8.1: Detail of the desk's robust construction for unshakable stability.



WARRANTY

2 YEAR

WARRANTY

200 LBS

50,000

OUTLIFT OUTLAST OUTPERFORM

Industrial-grade lifting power and rock-solid frame deliver stability&durability what others can't match

Figure 8.2: The desk's lifting capacity and durability testing.




Figure 8.3: Features of the high-quality desktop material.

9. WARRANTY AND CUSTOMER SUPPORT

SIAGO is committed to providing quality products and excellent customer service.

9.1 Warranty Information

The SIAGO Electric Standing Desk comes with a **1-Year Limited Warranty** covering manufacturing defects and machine service. For detailed warranty terms, please refer to the documentation included with your purchase or contact customer support.

9.2 Customer Support

For any questions, concerns, or technical support regarding your SIAGO standing desk, please contact us through Amazon:

- Login to your Amazon Account.

- Navigate to "Your Orders".
- Find the order ID for your SIAGO Electric Standing Desk.
- Click "Contact Seller".

SIAGO aims to reply within 24 hours and offers 30-day free returns.



Figure 9.1: SIAGO's commitment to customer service and support.

© 2025 SIAGO. All rights reserved.

Related Documents - Electric Standing Desk (48 x 24 Inch Black)

 <p>Electric Standing Desk User Guide</p> <p>Contact info: Email: support@siago.com Contact us or scan the QR code to get support 24/7 via messaging.</p> <p>Scan me</p>	<p>Electric Standing Desk User Guide</p> <p>User guide for the Electric Standing Desk, covering component identification, hardware assembly, and controller operation.</p>
 <p>SIAGO Electric Standing Desk Model SD55L</p>	<p>SIAGO Electric Standing Desk SD55L Installation and User Guide</p> <p>Comprehensive guide for the SIAGO Electric Standing Desk, Model SD55L. Includes assembly instructions, component identification, hardware details, controller guidelines, and troubleshooting error codes.</p>

 <p>Electric Standing Desk User Guide</p> <p>Contact info: Email: support@furmax.com QR code: </p> <p>How to:</p>	<p>Electric Standing Desk User Guide</p> <p>User guide for the Electric Standing Desk, covering component identification, hardware assembly, and controller operation.</p>
 <p>Instruction Manual</p> <p>Press the 'Reset' button until it is complete, the installation progress done.</p> <p>Notes:</p> <ul style="list-style-type: none"> 1. Power supply voltage: AC 100-240V, Frequency 50/60Hz 2. Before use, please check whether all parts are present and correctly assembled. 3. Please use the correct power supply and do not exceed the rated power. 4. Please use the correct power supply and do not exceed the rated power. 5. This product is not to be used by children. Adult supervision is required. 6. Do not use the product in a wet environment. 7. The product is not a medical device. If you have any concerns, please consult a medical professional. 8. It is normal for a computer monitor to have some static noise when being adjusted. 	<p>Furmax Electric Height Adjustable Standing Desk Instruction Manual</p> <p>Comprehensive instruction manual for the Furmax Electric Height Adjustable Standing Desk, detailing assembly, operation, and features for home and office use. Includes parts list and step-by-step assembly guide.</p>
 <p>L Shaped Standing Desk</p>	<p>L-Shaped Standing Desk Assembly Instructions</p> <p>Comprehensive guide for assembling an L-shaped electric height-adjustable standing desk, including parts list and step-by-step instructions.</p>
 <p>LSD136 Standing Desk</p> <p>SONGMICS</p>	<p>SONGMICS Standing Desk Assembly and Operation Manual</p> <p>Comprehensive guide for assembling and operating the SONGMICS electric height-adjustable standing desk (Model LSD136). Includes parts list, assembly steps, operating instructions for the control panel, memory functions, child lock, energy saving mode, charging, menu options, troubleshooting, and fault/alarm codes.</p>