

[Manuals.plus](#) /

› [hofstein](#) /

› Hofstein Bauro Ceiling Fan with Light Instruction Manual

hofstein H3691120

Hofstein Bauro Ceiling Fan with Light Instruction Manual

Model: H3691120

INTRODUCTION

Thank you for choosing the Hofstein Bauro Ceiling Fan with Integrated Light. This manual provides essential information for the safe installation, operation, and maintenance of your new ceiling fan. Please read these instructions thoroughly before installation and keep them for future reference.

The Bauro ceiling fan combines modern design with practical functionality, featuring a quiet fan with three speed levels, a summer and winter mode, and an integrated light with four E27 bulb sockets. It is controlled conveniently via a remote control.

SAFETY INSTRUCTIONS

- Always disconnect power at the main circuit breaker before installation, maintenance, or cleaning.
- Installation must be performed by a qualified electrician in accordance with all local and national electrical codes.
- Ensure the mounting structure can support the weight of the fan (refer to specifications for weight).
- Do not connect the fan to a dimmer switch unless specifically designed for fan control. This model supports dimmable bulbs if the bulbs themselves are dimmable.
- Keep hands, clothing, and other objects clear of the fan blades when the fan is operating.
- Do not attempt to repair or modify the fan. Contact qualified service personnel for repairs.
- Use only E27 bulbs as specified. Bulbs are not included.

PACKAGE CONTENTS

Verify that all components are present and undamaged before beginning installation.

- Ceiling Fan Unit (with integrated light and motor)
- Mounting Bracket
- Remote Control

- Remote Control Holder (optional, if included)
- Hardware Pack (screws, wire nuts, etc.)
- Instruction Manual



Figure 1: Overview of the Hofstein Bauro Ceiling Fan components, including the main unit, mounting bracket, and remote control.

SETUP AND INSTALLATION

Follow these steps carefully for proper installation. Professional installation is recommended.

1. Preparation:

- Turn off power at the circuit breaker to the fan location.
- Ensure the ceiling joist or support structure is strong enough to hold the fan's weight.

2. Mounting Bracket Installation:

- Attach the mounting bracket securely to the ceiling electrical box using the provided screws. Ensure it is firmly

fixed.



Figure 2: Diagram showing the dimensions of the Bauro ceiling fan and the mounting area. The fan has a diameter of 50 cm and a height of 18 cm.

3. Wiring Connections:

- Connect the household electrical wires to the fan's wires according to the wiring diagram provided in the packaging. Typically, this involves connecting live, neutral, and ground wires. Use wire nuts to secure connections.
- Ensure all connections are tight and insulated.

4. Attaching the Fan Unit:

- Carefully lift the fan unit and align it with the mounting bracket. Secure the fan unit to the bracket using the designated screws.

5. Installing Bulbs:

- Screw four E27 bulbs (not included) into the lamp holders.



Figure 3: A detailed view of the small fan blades and the four E27 bulb sockets within the bamboo shade of the Bauro ceiling fan.

6. Final Check:

- Double-check all connections and ensure the fan is securely mounted.
- Restore power at the circuit breaker.

OPERATING INSTRUCTIONS

Your Hofstein Bauro ceiling fan is controlled by the included remote control.

Remote Control Functions:

- **Power On/Off:** Press the power button to turn the fan and/or light on or off.
- **Fan Speed Control:** Cycle through 3 fan speed levels (Low, Medium, High) using the dedicated speed buttons.
- **Light On/Off:** Independently control the light function.
- **Dimming (if applicable):** If dimmable E27 bulbs are installed, the remote control may offer dimming functionality. Refer to the remote's specific buttons for this feature.

- **Summer/Winter Mode:** Switch between summer mode (downward airflow for cooling) and winter mode (upward airflow for heat distribution). This function helps optimize air circulation throughout the year.
- **Timer Function (if applicable):** Some remote controls may include a timer function to automatically turn off the fan after a set period.



Figure 4: The Hofstein Bauro ceiling fan installed, showing its elegant design and the included remote control for convenient operation.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your ceiling fan.

- **Cleaning:**
 - Before cleaning, ensure the power is turned off at the circuit breaker.
 - Wipe the fan housing and bamboo shade with a soft, damp cloth. Do not use abrasive cleaners or solvents.
 - Dust the fan blades regularly to prevent dust buildup, which can affect performance.
- **Bulb Replacement:**

- Ensure the power is off and bulbs have cooled before attempting to replace them.
- Replace with E27 bulbs of the specified wattage (check product specifications or original bulbs).

• **Tightening Fasteners:**

- Periodically check and tighten all screws and fasteners on the fan and mounting bracket to ensure secure operation.

TROUBLESHOOTING

If you encounter issues with your fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not start.	No power supply; Loose wiring; Remote control battery dead.	Check circuit breaker; Verify all wire connections; Replace remote control batteries.
Light does not turn on.	Bulb faulty or loose; Wiring issue; Remote control battery dead.	Check/replace bulbs; Verify light wiring; Replace remote control batteries.
Fan makes excessive noise.	Loose screws; Mounting bracket not secure; Blades unbalanced.	Tighten all screws; Ensure mounting bracket is firm; Check for balanced blades (though this model has small internal blades, less prone to imbalance).
Remote control not working.	Dead batteries; Obstruction between remote and receiver; Remote not paired.	Replace batteries; Remove obstructions; Refer to remote pairing instructions (if applicable, usually automatic).

SPECIFICATIONS

Feature	Detail
Model Number	H3691120
Brand	hofstein
Dimensions	Diameter: 50 cm, Height: 18 cm
Material	Metal, Bamboo
Color	Black (metal), Natural (bamboo shade)
Light Sockets	4 x E27 (bulbs not included)
Fan Speeds	3 levels
Control Type	Remote Control
Special Features	Summer/Winter Mode, Quiet Operation, Dimmable (with compatible bulbs)
Power Source	Electric Cable
Country of Origin	China

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or contact Hofstein customer service directly. Keep your proof of purchase for warranty claims.

For further assistance, you may visit the Hofstein brand store on Amazon:[Hofstein Brand Store](#)