

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [wavytalk](#) /

› [Wavytalk 1875W Ionic Hair Dryer with Diffuser and Concentrator \(Model 3003\) User Manual](#)

## wavytalk 3003

# Wavytalk 1875W Ionic Hair Dryer (Model 3003) User Manual



## 1. INTRODUCTION AND OVERVIEW

Thank you for choosing the Wavytalk 1875W Ionic Hair Dryer. This powerful and lightweight hair dryer is designed for fast drying and versatile styling, featuring ionic technology to reduce frizz and enhance hair's natural shine. It comes with a concentrator nozzle for precise styling and a diffuser for gentle drying of curls and waves.

Key features include:

- **1875W High-Performance Motor:** Delivers strong, steady airflow for quick drying.
- **Adjustable Settings:** Offers 3 speed and 2 heat settings to customize your drying experience.
- **Lightweight Design:** Ensures comfortable use, reducing arm fatigue during extended styling.
- **Ionic Technology:** Helps to reduce frizz and static, leaving hair smoother and shinier.
- **Included Attachments:** Comes with a styling concentrator and a diffuser for various hair types and styles.

## 2. IMPORTANT SAFETY INFORMATION

Please read all instructions before using this appliance. When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

- **DANGER:** Keep away from water. Do not use while bathing or near water.
- Always unplug the appliance immediately after use.
- Do not place or store appliance where it can fall or be pulled into a tub or sink.
- Do not place in or drop into water or other liquid.
- If an appliance falls into water, unplug it immediately. Do not reach into the water.
- Keep the power plug and cord away from heated surfaces.
- Keep out of reach of children.
- Do not operate any appliance with a damaged cord or plug, or if the appliance malfunctions or has been dropped or damaged in any manner.

**Legal Disclaimer:** Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition. This product is a hair styling appliance and should be used as intended.

## 3. PRODUCT COMPONENTS

Your Wavytalk hair dryer package includes the following items:

- Wavytalk 1875W Ionic Hair Dryer (Model 3003)
- Styling Concentrator Nozzle
- Diffuser Nozzle



**1875W**  
**High-Powered**

*Image: The Wavytalk 1875W Ionic Hair Dryer shown with its concentrator and diffuser attachments.*



*Image: Close-up of the Styling Concentrator Nozzle. This attachment directs airflow for precise styling.*



# Expeditious Drying



*Image: Close-up of the Diffuser Nozzle. This attachment helps to maintain natural curls and waves.*

## 4. SETUP INSTRUCTIONS

- 1. Unpack:** Carefully remove all components from the packaging.
- 2. Inspect:** Check the hair dryer and all accessories for any signs of damage. Do not use if damaged.
- 3. Attach Nozzle (Optional):** To attach the concentrator or diffuser, align the attachment with the front of the hair dryer and twist gently until it locks into place. Ensure it is securely fastened before use.
- 4. Power Connection:** Plug the hair dryer into a standard electrical outlet. Ensure the outlet voltage matches the

appliance's requirements (125V AC, 60Hz).



*Image: Illustration showing how to attach the concentrator nozzle to the hair dryer.*

## 5. OPERATING INSTRUCTIONS

---

The Wavytalk hair dryer features intuitive controls for easy operation.



*Image: Close-up of the hair dryer's control panel, showing the speed and heat settings, and the cool shot button.*

## Powering On/Off

- Slide the main power switch to the 'I' position to turn on the dryer.
- Slide the main power switch to the 'O' position to turn off the dryer.

## Adjusting Speed and Heat

Use the dedicated switches on the handle to adjust airflow speed and heat level:

- **Speed Settings:** Choose from Low (I), Medium (II), or High (III) airflow.

- **Heat Settings:** Select between Warm (I) and Hot (II) air.

## Using the Cool Shot Button

Press and hold the snowflake button for a burst of cool air. This helps to set your style and add shine.

## Using Attachments

- **Concentrator Nozzle:** Ideal for precise drying and styling, directing airflow to specific sections of hair.
- **Diffuser Nozzle:** Use for gentle drying of curly or wavy hair to enhance natural texture and reduce frizz. Hold the diffuser close to your scalp and move it in circular motions.

## Demonstration Videos

Your browser does not support the video tag.

*Video: Demonstrates the lightweight design and fast drying capabilities of the Wavytalk hair dryer.*

Your browser does not support the video tag.

*Video: Showcases the Wavytalk hair dryer with its diffuser and concentrator attachments.*

## 6. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your hair dryer.

### Cleaning the Air Filter

1. Ensure the hair dryer is unplugged and completely cool.
2. Gently twist and remove the rear air filter cover.
3. Use a soft brush or cloth to remove any dust, lint, or hair accumulated on the filter.
4. Replace the filter cover by aligning and twisting it back into place.



*Image: View of the rear air filter on the Wavytalk hair dryer, which should be cleaned regularly.*

### Storage

- Allow the appliance to cool down completely before storing.
- Do not wrap the cord around the appliance. This can cause premature wear and breakage of the cord.
- Store the appliance in a cool, dry place, out of reach of children.

## 7. TROUBLESHOOTING

If you encounter any issues with your Wavytalk hair dryer, please refer to the following common troubleshooting

steps:

- **No Power:** Ensure the hair dryer is securely plugged into a working electrical outlet. Check if the circuit breaker has tripped.
- **Overheating:** The hair dryer may automatically shut off if it overheats. Unplug it, allow it to cool down for a few minutes, and clean the air filter.
- **Weak Airflow:** Check the rear air filter for blockages (dust, lint, hair). Clean the filter as described in the Maintenance section.
- **Unusual Noise:** If the dryer makes unusual noises, unplug it immediately and check the air filter for any obstructions. If the noise persists, discontinue use and contact customer support.

If the problem persists after trying these steps, please contact Wavytalk customer support for assistance.

## 8. SPECIFICATIONS

Feature	Detail
Brand	wavytalk
Model Number	3003
Product Dimensions	9.84 x 5.51 x 2.83 inches
Item Weight	1.01 Pounds
Color	White
Material	Metal, Plastic
Wattage	1875 watts
Power Source	Corded Electric

## 9. WARRANTY AND CUSTOMER SUPPORT

For warranty information or customer support, please refer to the documentation included with your product or visit the official Wavytalk website. Keep your purchase receipt as proof of purchase for any warranty claims.

For further assistance, you may contact Wavytalk customer service through their official channels.

